


INSTRUCTION MANUAL



Thermcraft
incorporated

P.O. Box 12037
3950 Overdale Road
Winston-Salem, NC 27117-2037 USA

Telephone (336) 784-4800
Fax (336) 784-0634
Email: tcj@thermcraftinc.com
Website: www.thermcraftinc.com

WE APPRECIATE YOUR BUSINESS

Thank you for purchasing a Thermcraft, Inc. heat treating furnace. Since our establishment in 1971, Thermcraft, Inc. has manufactured reliable, high quality, electric resistance equipment. Our products have been used in a variety of applications both domestically and around the world.

Thermcraft, Inc. has manufactured this furnace to comply with predetermined specifications. This furnace has been completely checked for mechanical and electrical compliance prior to shipment.

We trust you have received your furnace in acceptable condition and that you will find it meets or exceeds your expectations and requirements.

Prior to installation and operation of your new Thermcraft, Inc. furnace, we strongly urge you to read this manual in its entirety and comply with all instructions herein.

If you have any questions, feel free to contact us.

Sincerely,

Thermcraft, Inc.
P.O. Box 12037
3950 Overdale Road
Winston-Salem, NC 27117-2037, U.S.A.
Telephone (336) 784-4800
Fax (336) 784-0634
Email: tcj@thermcraftinc.com
Web: www.thermcraftinc.com

THERMCRAFT, INC.

INSTRUCTION MANUAL

CONTENTS

1. Furnace Specifications
2. Inspection and Damaged Instructions
3. Assembly
4. Installation and Power Connection
5. Operational Safety
6. Furnace Start-Up Procedure and Preventive Maintenance
7. Thermocouple
8. Ceramic Fiber Insulation Safety
9. Recommended Safe Handling Procedures For Ceramic Fiber Products
10. Replacement Vestibule Blocks
11. Replacement Vacuum Formed Ceramic Fiber Heaters
12. Replacement Parts List
13. Fibercraft MSDS sheet
14. Furnace Trouble-Shooting
15. Furnace Assembly Drawing
16. Furnace Heater Wiring Diagram
17. Electrical Specifications (if applicable)
18. Electrical Wiring Diagram (if applicable)
19. Controller Manual (if applicable)

1.) FURNACE SPECIFICATIONS

(using Vacuum Formed Fiber Heating Elements)

| | |
|--------------------|--|
| Single Zone Model | XST-6-0-24-1V |
| Three Zone Model | XST-6-0-24-3V |
| Description | 6" heated ID x 24" L |
| Heating Element(s) | FH-8256 (same for both models) |
| Max Temp | 1100°C / 2012°F |
| Incoming Power | 6800 Watts, 230 Volts, 29.60 Amps, 60 Hz, 1 Ph |

| | |
|--------------------|---|
| Single Zone Model | XST-6-0-36-1V |
| Three Zone Model | XST-6-0-36-3V |
| Description | 6" heated ID x 36" L |
| Heating Element(s) | FH-8257 (same for both models) |
| Max Temp | 1100°C / 2012°F |
| Incoming Power | 10200 Watts, 230 Volts, 44.35 Amps, 60 Hz, 1 Ph |

2.) INSPECTION AND DAMAGED INSTRUCTIONS

INSPECTION

Upon receipt of your new Thermcraft, Inc. furnace, inspect for visible exterior damage. If any damage has been found, be sure to note and describe it on the freight bill and file a claim with the carrier.

Once unpacked, carefully inspect for concealed damage on the furnace itself, both interior and exterior. If necessary, the carrier will arrange for official inspection to substantiate your claim.

The vertical mounting legs, guide tabs and associated hardware have been included with, but are packed separately from, your Thermcraft, Inc. furnace. Please locate these parts prior to disregarding packaging materials.

RETURN SHIPMENT

Be sure to save the shipping materials until you are sure all is well.

If for any reason you must return the unit, first contact our Sales Department at 336-784-4800. When you call, please have available the unit's serial-number and model number (located on the rating plate).

Note: All returns MUST have a Return Authorization Number.

3.) ASSEMBLY

NOTE: These furnaces are heavy and care should be taken to use lifting devices which are sufficiently rated for these loads. Doors, handles and knobs are not adequate for lifting or stabilization. The unit should be completely restrained to prevent tipping during lifting and transport.

Before proceeding with installation, review all of drawings and diagrams included in this manual. Make sure the terminal box cover(s) and backstops are in place and secure.

The furnace is pre-assembled with the exception of the guide tabs and optional vertical mounting legs. Based upon how the furnace will be used, follow the appropriate procedure listed below:

If the furnace is to be used horizontally on a bench top surface, no further assembly required.

1. The furnace is ready to be grounded then connected to power.
2. Proceed to Section 4.) Installation and Power Connection.

If the furnace is to be vertically mounted to a fixture, such as a wall or a self-supported stand (not included), the vertical mounting legs need installed as follows:

1. Be sure to have someone available to assist you while handling the furnace.
2. **Make certain the latches are firmly closed before moving the furnace to avoid injury and to avoid having the hinged half of the shell open unexpectedly.**
3. Instructions to install the vertical mounting legs.
 - a. Gently roll the furnace onto either side or stand it on either end.
 - b. Locate and remove the six (6) rubber bumpers located on the base of the unit by unscrewing the bolts. **Do not discard these bolts.**
 - c. Firmly attach the vertical mounting legs to each edge of the backside / underside of the furnace with the bolts from step 4b by placing the bolts through the row of smaller slots (5/16" x 1/2" long). Use a socket wrench to tighten the bolts into place. Do not use pliers as this will strip the bolt heads. [The other row of slots is to attach the furnace to a fixture using mounting bolts or mechanical anchors (not included).]
 - d. Choose the desired orientation of the furnace (i.e. opening from left to right or vice versa). Now attach the guide-tab on the bottom endplate of the furnace to the mounted half of the furnace shell using the button-head bolts (included).
 - e. With the vertical legs securely in place and the latches secured shut, the furnace can now be mounted to the desired fixture. Use a forklift or other hydraulic lift and adequate shoring/bracing to lift and hold the furnace in place while anchoring. Never work above your head when attaching any heavy object to a wall or other fixture. If you are uncertain where or how to safely mount your furnace, please employ a licensed contractor.
 - f. If any further questions arise concerning assembly of the furnace, please contact Thermcraft, Inc. at 336-784-4800.

4.) INSTALLATION AND POWER CONNECTION

After the above assembly procedures have been completed, the furnace is ready for connection to incoming power as follows:

1. Open the furnace and remove the protective packing covering the heating elements.
2. Consult an electrical professional and the NEC (National Electric Code) specifications to select wiring of size to adequately carry the line amperage shown in section 1.) Furnace Specifications. Connect electrical service to a fused power source.

5.) OPERATIONAL SAFETY

Safe operation of your new furnace is mandatory. As manufacturer of your furnace, we at Thermcraft, Inc. have adhered to all known safety standards and strongly suggest you install your furnace in accordance with national electric and fire protection codes.

It is important to pay particular attention to those regulations that are applicable to the specific governing operations entities including, but not limited to,; i.) legislated and accredited national and local industry standards and ii.) the type of facility in which the furnace will be employed, including zoning requirements, local building codes, and local electrical codes.

CAUTION: If this equipment is used in a manner other than described in this manual, protection provided by the equipment may be compromised or impaired.

SYMBOLS USED ON THE EQUIPMENT



Caution: risk of electric shock.



Caution: hot surface.



Caution: refer to accompanying documents.

The potential for electric shock is always present when electrically operated equipment is in use. The following suggestions are recommended for your protection:

1. Before beginning service / maintenance procedures on your furnace, the power source must be locked out and tagged out per Occupational Safety and Health Administration (OSHA) regulations.
2. Insure the furnace is properly grounded and electrically protected. Grounding lugs and ground wires have been installed prior to shipment. The ground wire will terminate within the external terminal box and is visible to the installer / operator. If unsure of the grounding status of the equipment, consult the NEC (National Electric Code) or a licensed professional.
3. If electrically conductive material is to be heat treated, the operator must be protected from becoming a conductor to the ground. To avoid electric shock observe the following operating practices:
 - a. Wear insulated gloves specific to the task that guard against electric shock if the operator will be in contact with an electric current.
 - b. When using any metallic instrument to introduce items into the furnace, insure the handle is properly insulated and the instrument is adequately grounded.
 - c. Install rubber mats in front of and behind the equipment to protect the operator.

Periodically disconnect power from the equipment and allow it to cool completely. Once cool, inspect for loose or broken heaters and for worn wire coils on the inside of the heated chamber. Heaters may have to be replaced if damage is severe. Avoid contact with any exposed heater coils / elements. Do not touch elements with bare hands or oily gloves. Contact Thermcraft, Inc. if unsure of the safety of the heating elements in the conditions you have observed.

Only qualified electrical professionals should remove the upper and lower terminal covers of the terminal boxes. Keep all guards (guide-tabs, backstops, upper and lower terminal covers) provided with the equipment in place while the furnace is in operation. Observe all safety labels. **If questions arise concerning the operation of your furnace, contact Thermcraft, Inc. at 336-784-4800.**

6.) FURNACE START UP PROCEDURE AND PREVENTIVE MAINTENANCE

Follow your company's lock-out/tag-out procedures before beginning any work on the heaters or heated chamber of your furnace.

The following procedures should be performed by a trained electrical professional due to potential hazard.

DRYING OUT PROCEDURE

1. In a well-ventilated area separate the two furnace halves 1-2 inches apart. Allow the furnace to heat slowly up to 200°F. This will dry out any moisture in the refractory lining.
2. Keep the furnace at 200°F for four to six hours.
3. After closing the hinged half of the furnace, allow the furnace to heat up to normal operating temperature. If steaming occurs at any time during this part of the procedure, discontinue heat up by turning off the power until steaming stops.
4. If moving the furnace after performing the drying out procedure, use caution as the heating elements are fragile and may break or become damaged.

PREVENTIVE MAINTENANCE

1. Inspect the electrical connections for looseness due to expansion during the heat-up/cool-down cycle.
2. One of the common causes of heating element burnout is the build up of scale and dirt on the element inside the mounted (when oriented vertically) or lower (when oriented horizontally) half of the furnace. Do not allow build up of foreign material on the element. Oil should be cleaned off of any part of the furnace prior to heating. Use caution not to displace the heating elements as the wire may be brittle and break easily.

7.) THERMOCOUPLE

A thermocouple is used to measure the voltage that is generated as the temperature increases. It provides an input signal for the control system that monitors the temperature of the heated chamber.

At high temperatures, the elements within the thermocouple may undergo some oxidation or corrosion causing the signals to be read incorrectly by the control system.

To monitor temperature, the tip of the thermocouple must be inside the heated chamber. Also, the thermocouple tip must not be blocked or shielded by items being heat treated.

If the control system indicates that a thermocouple is no longer functioning, it is important to replace the malfunctioning thermocouple with the same PlatineI Type II model thermocouple that was originally provided with the furnace. Replacement extension wires and connectors must also be compatible with the thermocouple and the controller.

NOTE: Polarity of the thermocouple extension wires is the OPPOSITE of the polarity of typical electrical wiring. The red leg is always negative for thermocouples while the black leg is always positive.

8.) CERAMIC FIBER INSULATION SAFETY

Dear Valued Customer:

Please keep in mind that your Thermcraft, Inc. furnace is completely safe when used for its intended purpose and with the precautions listed herein. The following information is to make you aware of the potential health effects of the ceramic and insulation components incorporated into your furnace.

Thermcraft, Inc. manufactures a broad range of high temperature furnace systems. These systems incorporate various ceramic materials. Airborne particulates produced in the handling of these materials should be considered nuisance dust. Always wear a dust mask and safety glasses to avoid such irritation due to inhalation of, or eye contact with, this or any other ceramic dust.

Chronic Effect – there has been no increased incidence of respiratory disease in the Refractory Ceramic Fiber Coalition's studies examining occupationally exposed workers. In their animal testing, long-term laboratory exposure to doses hundreds of times higher than normal occupational exposures has produced fibrosis, lung cancer, and mesothelioma in rats or hamsters. The fibers used in those studies were specially sized to maximize rodent respirability. Please go to the Refractory Ceramic Fiber Coalition's website at www.rcfc.net for up-to-date information.

The recommended handling procedures for these ceramic materials are outlined on the next page (Section 9) as well as in the Fibercraft Material Safety Data Sheets (MSDS) included in this manual. Please make sure this information is available to all personnel who may be operating, handling or repairing this furnace.

As always, if you have any questions or concerns, please feel free to contact Thermcraft, Inc at 336-784-4800.

9.) RECOMMENDED SAFE HANDLING PROCEDURES FOR CERAMIC FIBER PRODUCTS

1. Minimize presence of airborne fiber at all times by avoiding applications of pressurized air from air canisters or pneumatic systems to any fibers that have already been heated.
2. Wear an appropriate NIOSH – or MSHA-approved high efficiency air purifying respirator mask when handling any ceramic fiber products.
3. Wear long-sleeved, loose-fitting clothing when handling ceramic fiber products. Use protective coveralls over clothing. Do not wear contact lenses and always wear safety glasses. Do not allow employees to take soiled clothing, or any clothing in which fibers have become embedded from the facility where the furnace is employed to his/her dwelling. Have employees store, maintain and wash work clothing on site separately from other clothing. Rinse washing machine thoroughly after washing clothing worn when handling ceramic fibers.
4. Wear eye protection (safety glasses or goggles) and protective gloves at all times.
5. Wash exposed skin areas gently with soap and **cold** water immediately after handling ceramic fiber product.
6. Particular care should be taken when working with "used" material which has been in service at elevated temperatures (greater than 1600° F). Such products may undergo partial conversion to Cristobalite, a form of crystalline silica that can cause respiratory disease.

10.) REPLACEMENT VESTIBULE BLOCKS

Your furnace has been manufactured with the size and number of vestibule blocks per your request. Additional or replacement vestibules may be purchased using the information listed below. Two vestibule blocks per furnace is typical.

| <u>Part number</u> | <u>Description</u> |
|--------------------|---------------------------------|
| XVB-8621-6-3.00 | vestibule block with 3.00" bore |
| XVB-8621-6-3.50 | vestibule block with 3.50" bore |
| XVB-8621-6-4.00 | vestibule block with 4.00" bore |
| XVB-8621-6-4.50 | vestibule block with 4.50" bore |
| XVB-8621-6-5.00 | vestibule block with 5.00" bore |
| XVB-8621-6-5.50 | vestibule block with 5.50" bore |
| XVB-8621-6-S | solid vestibule (zero bore) |

11.) REPLACEMENT VACUUM FORMED CERAMIC FIBER HEATERS

VACUUM FORMED HEATERS

Thermcraft, Inc. recommends returning the furnace to our factory for replacement of the vacuum formed heating elements. Please locate the model number and serial number on the furnace rating plate prior to calling. Upon receipt of your call, our Sales Department will provide a Return Authorization Number. All returns MUST have a Return Authorization Number.

However, if you, the customer, wish to replace the heating elements, please call us for further information and instructions. Part numbers for the replacement vacuum formed heating elements can be found in section 1.) Furnace Specifications (using Vacuum Formed Heating Elements). Please have the replacement part number, along with the model number and serial number of the furnace, available prior to calling Thermcraft, Inc.


12.) Furnace Mechanical Replacement Parts List

Everything needed for operation of your new Thermcraft, Inc. furnace has been included with the furnace. Should the need arise, available replacement mechanical parts are per shown below. Please provide both the description and item number when ordering.


| Description | Item Number | Quantity included |
|---------------------------|-------------|-------------------|
| Vertical mounting leg | 36 | 2 |
| Backstop | 601 | 1 |
| Backstop shoulder bolt | 611 | 2 |
| Stand-off / striker plate | 81 | 2 |
| Guide tab | 83 | 1 |
| Guide tab screw | 84 | 4 |

14.) TROUBLE SHOOTING FOR FURNACE / OVEN PROBLEMS

1. THERMOCOUPLE PROBLEMS



2. HEATER PROBLEMS



MATERIAL SAFETY DATA SHEET

MSDS No. 1

Effective Date: 03/19/2010

1. CHEMICAL PRODUCT AND COMPANY IDENTIFICATION

Trade Names: *Fibercraft*

Product Group: REFRACTORY CERAMIC FIBER PRODUCT
Chemical Name: VITROUS ALUMINOSILICATE FIBER
Synonym(s): RCF, ceramic fiber, synthetic vitreous fiber (SVF), man-made vitreous fiber (MMVF), man-made mineral fiber (MMMf)

Manufacturer/Supplier: Thermcraft, Inc.
3950 Overdale road
Winston-Salem, N.C. 27107
336-784-4800

Product Stewardship Information Hotline
1-800-322-2293 (Monday - Friday 8:00 a.m. - 4:30 p.m. EST)

CHEMTREC Assist: CHEMTREC will provide assistance for chemical emergencies. Call 1-800-424-9300

2. COMPOSITION / INFORMATION ON INGREDIENTS

| <u>COMPONENTS</u> | <u>CAS NUMBER</u> | <u>% BY WEIGHT</u> |
|--|-------------------|--------------------|
| Refractories, Fibers, Aluminosilicate (See Section 8 "Exposure Controls / Personal Protection" for exposure guidelines) | 142844-00-6 | 100 |

3. HAZARDS IDENTIFICATION

EMERGENCY OVERVIEW

WARNING!
POSSIBLE CANCER HAZARD BY INHALATION.
(See Section 11 for more information)

CHRONIC EFFECT

There has been no increased incidence of respiratory disease in studies examining occupationally exposed workers. In animal studies, long-term laboratory exposure to doses hundreds of times higher than normal occupational exposures has produced fibrosis, lung cancer, and mesothelioma in rats or hamsters. The fibers used in those studies were specially sized to maximize rodent respirability.

OTHER POTENTIAL EFFECTS

TARGET ORGANS:

Respiratory Tract (nose & throat), Eyes, Skin

RESPIRATORY TRACT (nose & throat) IRRITATION:

If inhaled in sufficient quantity, may cause temporary, mild mechanical irritation to respiratory tract. Symptoms may include scratchiness of the nose or throat, cough or chest discomfort.

EYE IRRITATION:

May cause temporary, mild mechanical irritation. Fibers may be abrasive; prolonged contact may cause damage to the outer surface of the eye.

SKIN IRRITATION:

May cause temporary, mild mechanical irritation. Exposure may also result in inflammation, rash or itching.

GASTROINTESTINAL IRRITATION:

Unlikely route of exposure.

MEDICAL CONDITIONS AGGRAVATED BY EXPOSURE:

Pre-existing medical conditions, including dermatitis, asthma or chronic lung disease may be aggravated by exposure; individuals who have a history of allergies may experience greater amounts of skin and respiratory irritation.

HAZARD CLASSIFICATION

Although studies, involving occupationally exposed workers, have not identified any increased incidence of respiratory disease, results from animal testing have been used as the basis for hazard classification. In each of the following cases, the conclusions are qualitative only and do not rest upon any quantitative analysis suggesting that the hazard actually may occur at current occupational exposure levels.

In October 2001, the **International Agency for Research on Cancer (IARC)** confirmed that Group 2b (possible human carcinogen) remains the appropriate IARC classification for RCF.

The Seventh Annual Report on Carcinogens (1994); prepared by the **National Toxicology Program (NTP)**, classified respirable RCF as "reasonably anticipated" to be a carcinogen.

The **American Conference of Governmental Industrial Hygienists (ACGIH)** has classified RCF as "A2-Suspected Human Carcinogen."

The **Commission of The European Communities (DG XI)** has classified RCF as a substance that should be regarded as if it is carcinogenic to man.

The **State of California**, pursuant to Proposition 65, The Safe Drinking Water and Toxic Enforcement Act of 1986, has listed "ceramic fibers (airborne fibers of respirable size)" as a chemical known to the State of California to cause cancer.

The **Canadian Environmental Protection Agency (CEPA)** has classified RCF as "probably carcinogenic" (Group 2).

The **Canadian Workplace Hazardous Materials Information System (WHMIS)** – RCF is classified as Class D2A – Materials Causing Other Toxic Effects

The **Hazardous Materials Identification System (HMIS)** –

Health 1* Flammability 0 Reactivity 0 Personal Protection Index: X (Employer Determined)
(* denotes potential for chronic effects)

4. FIRST AID MEASURES**FIRST AID PROCEDURES****RESPIRATORY TRACT (nose & throat) IRRITATION:**

If respiratory tract irritation develops, move the person to a dust free location. Get medical attention if the irritation continues. See Section 8 for additional measures to reduce or eliminate exposure.

EYE IRRITATION:

If eyes become irritated, flush immediately with large amounts of lukewarm water for at least 15 minutes. Eyelids should be held away from the eyeball to ensure thorough rinsing. Do not rub eyes. Get medical attention if irritation persists.

SKIN IRRITATION:

If skin becomes irritated, remove soiled clothing. Do not rub or scratch exposed skin. Wash area of contact thoroughly with soap and water. Using a skin cream or lotion after washing may be helpful.

GASTROINTESTINAL IRRITATION:

If gastrointestinal tract irritation develops, move the person to a dust free environment.

NOTES TO PHYSICIANS:

Skin and respiratory effects are the result of temporary, mild mechanical irritation; fiber exposure does not result in allergic manifestations.

5. FIRE FIGHTING MEASURES

NFPA Codes: Flammability: 0 Health: 1 Reactivity: 0 Special: 0

NFPA Unusual Hazards: None
Flammable Properties: None
Flash Point: None
Hazardous Decomposition Products: None
Unusual Fire and Explosion Hazard: None
Extinguishing Media: Use extinguishing media suitable for type of surrounding fire.

6. ACCIDENTAL RELEASE MEASURES

SPILL PROCEDURES

Minimize creating airborne dust. Dust suppressing cleaning methods such as wet sweeping or vacuuming should be used to clean the work area. If vacuuming, the vacuum must be equipped with a HEPA filter. Compressed air or dry sweeping should not be used for cleaning.

7. HANDLING AND STORAGE

STORAGE

Store in original container in a dry area. Keep container closed when not in use.

HANDLING

Handle ceramic fiber carefully. Limit use of power tools unless in conjunction with local exhaust. Use hand tools whenever possible. Frequently clean the work area with HEPA filtered vacuum or wet sweeping to minimize the accumulation of debris. Do not use compressed air for clean-up.

EMPTY CONTAINERS

Product packaging may contain residue. Do not reuse.

8. EXPOSURE CONTROLS/PERSONAL PROTECTION

EXPOSURE GUIDELINES

| COMPONENTS | OSHA PEL | MANUFACTURER REG |
|---------------------------------------|-------------------|-----------------------|
| Refractories, Fibers, Aluminosilicate | None Established* | 0.5 f/cc, 8-hr. TWA** |

* There is no specific regulatory standard for RCF in the U.S. OSHA's "Particulate Not Otherwise Regulated (PNOR)" standard [29 CFR 1910.1000, Subpart Z, Air Contaminants] applies generally; Total Dust 15 mg/m³; Respirable Fraction 5 mg/m³.

** The Refractory Ceramic Fibers Coalition (RCFC) has sponsored comprehensive toxicology and epidemiology studies to identify potential RCF-related health effects [see Section 11 for more details], consulted experts familiar with fiber and particle science, conducted a thorough review of the RCF-related scientific literature, and further evaluated the data in a state-of-the-art quantitative risk assessment. Based on these efforts and in the absence of an OSHA PEL, RCFC has adopted a recommended exposure guideline, as measured under NIOSH Method 7400 B. The manufacturers' REG is intended to promote occupational health and safety through prudent exposure control and reduction and it reflects relative technical and economic feasibility as determined by extensive industrial hygiene monitoring efforts undertaken pursuant to an agreement with the U.S. Occupational Safety and Health Administration (OSHA).

OTHER OCCUPATIONAL EXPOSURE LEVELS (OEL)

RCF-related occupational exposure limits vary internationally. Regulatory OEL examples include: Canada – 0.2 to 1.0 f/cc; Non-regulatory OEL examples include: ACGIH TLV 0.2 f/cc; RCFC REG 0.5 f/cc. The objectives and criteria underlying each of these OEL decisions also vary. The evaluation of occupational exposure limits and determining their relative applicability to the workplace is best performed, on a case-by-case basis, by a qualified Industrial Hygienist.

ENGINEERING CONTROLS

Use engineering controls such as local exhaust ventilation, point of generation dust collection, down draft work stations, emission controlling tool designs, and materials handling equipment designed to minimize airborne fiber emissions.

PERSONAL PROTECTION EQUIPMENT

Respiratory Protection – RCF:

When engineering and/or administrative controls are insufficient to maintain workplace concentrations within the 0.5 f/cc REG, the use of appropriate respiratory protection, pursuant to the requirements of OSHA Standards 29 CFR 1910.134 and 29 CFR 1926.103, is recommended. The following information is provided as an example of appropriate respiratory protection for aluminosilicate fibers. The evaluation of workplace hazards and the identification of appropriate respiratory protection is best performed, on a case by case basis, by a qualified Industrial Hygienist.

| MANUFACTURER'S RESPIRATORY PROTECTION RECOMMENDATIONS WHEN HANDLING RCF PRODUCTS | |
|--|--|
| Respirable Airborne Fiber Concentration (levels are 8-hr. time-weighted averages) | Respirator Recommendation[†] |
| Not yet determined but expected to be below 5.0 f/cc based on operation | A respirator with a filter efficiency of at least 95% |
| "Reliably" less than 0.5 f/cc | Optional |
| 0.5 f/cc to 5.0 f/cc | A single use respirator or half-face, air purifying respirator with a filter efficiency of at least 95% |
| 5.0 f/cc to 25 f/cc | Full-facepiece, air purifying respirator equipped with a NIOSH certified particulate filter cartridge with a filter efficiency of at least 95% or PAPR |
| Greater than 25 f/cc | PAPR with tight-fitting full facepiece or a supplied air respirator in continuous flow mode |
| When individual workers request respiratory protection as a matter of personal comfort or choice where exposures are "reliably" below 0.5 f/cc | A NIOSH certified respirator, such as a single use particulate respirator with a filter efficiency of at least 95%. |

[†]The 95% filter efficiency recommendation is based on NIOSH respirator selection logic sequence for exposure to particulates. Selection of filter efficiency (i.e. 95%, 99% or 99.97%) depends on how much filter leakage can be accepted. Higher filter efficiency means lower filter leakage. Other factors to consider are the NIOSH filter series N, R or P. (N) Not resistant to oil, (R) Resistant to oil and (P) oil Proof. These recommendations are not designed to limit informed choices, provided that respiratory protection decisions comply with 29 CFR 1910.134.

Other Information

-Concentrations based upon an eight hour time weighted average (TWA) as determined by air samples collected and analyzed pursuant to NIOSH method 7400 (B) for airborne fibers.

-The manufacturer recommends the use of a full face piece air purifying respirator equipped with an appropriate particulate filter cartridge during furnace tear out events and the removal of used RCF to control exposures to airborne fiber and the potential presence of crystalline silica. If exposure levels are known, the respiratory protection charge provided above may be applied.

-Potential exposure to other airborne contaminants should be evaluated by a qualified industrial hygienist for the selection of appropriate respiratory protection and air monitoring.

Skin Protection:

Wear gloves, head coverings and full body clothing as necessary to prevent skin irritation. Washable or disposable clothing may be used. If possible, do not take unwashed clothing home. If soiled work clothing must be taken home, employers should ensure employees are thoroughly trained on the best practices to minimize non-work dust exposure (e.g., vacuum clothes before leaving the work area, wash work clothing separately, rinse washer before washing other household clothes, etc.).

Eye Protection:

Wear safety glasses with side shields or other forms of eye protection in compliance with appropriate OSHA standards to prevent eye irritation. The use of contact lenses is not recommended, unless used in conjunction with appropriate eye protection. Do not touch eyes with soiled body parts or materials. If possible, have eye-washing facilities readily available where eye irritation can occur.

9. PHYSICAL AND CHEMICAL PROPERTIES

| | |
|---------------------------------|-----------------------------------|
| ODOR AND APPEARANCE: | White, odorless, fibrous material |
| CHEMICAL FAMILY: | Vitreous Aluminosilicate Fibers |
| BOILING POINT: | Not Applicable |
| WATER SOLUBILITY (%): | Not Soluble in Water |
| MELTING POINT: | 1760° C (3200° F) |
| SPECIFIC GRAVITY: | 2.50 – 2.75 |
| VAPOR PRESSURE: | Not Applicable |
| pH: | Not Applicable |
| VAPOR DENSITY (Air = 1): | Not Applicable |
| % VOLATILE: | Not Applicable |
| MOLECULAR FORMULA: | Not Applicable |

10. STABILITY AND REACTIVITY

| | |
|--|---|
| CHEMICAL STABILITY: | Stable under conditions of normal use. |
| INCOMPATIBILITY: | Soluble in hydrofluoric acid, phosphoric acid, and concentrated alkali. |
| CONDITIONS TO AVOID: | None. |
| HAZARDOUS DECOMPOSITION PRODUCTS: | None. |
| HAZARDOUS POLYMERIZATION: | Not Applicable. |

11. TOXICOLOGICAL INFORMATION

HEALTH DATA SUMMARY

Epidemiological studies of RCF production workers have indicated no increased incidence of respiratory disease nor other significant health effects. In animal studies, long-term, high-dose inhalation exposure resulted in the development of respiratory disease in rats and hamsters.

EPIDEMIOLOGY

In order to determine possible human health effects following RCF exposure, the University of Cincinnati in the United States and the Institute of Occupational Medicine (IOM) in Europe have conducted medical surveillance studies on RCF workers in U.S. and European manufacturing facilities. The University of Cincinnati study has been in progress for over 20-years, collecting data from respiratory questionnaires, lung function tests, chest X-rays, exposure monitoring, and worker mortality.

The results of this study of RCF plant workers exposed from 1953 to the present have shown (LeMasters *et al.*, 2003):

- No excess mortality related to all deaths, all cancers, or lung cancer
- No statistically significant increase in interstitial findings (fibrosis), and
- No mesotheliomas or increase in lung cancer

The initial cross-sectional spirometry studies in the U.S. (LeMasters *et al.* 1998) and Europe (Cowie *et al.* 2001) revealed lung function decrements in the RCF-exposed cohort that were associated with heavier historical exposures. Subsequently, longitudinal studies have revealed no RCF exposure related decrements in lung function associated with current exposure levels.

Through 1996, pleural plaques seen on chest X-rays in 2.7% of the workers. Pleural plaques are considered a marker of exposure and not disease. The prevalence of pleural plaques has remained relatively constant over time, perhaps as a result of lower current exposure levels.

Thus, this long term epidemiology study has demonstrated an absence of interstitial fibrosis, no increased mortality risk and no decrement in lung function associated with current exposures.

TOXICOLOGY

Early animal studies of RCF effects by intraperitoneal and intrapleural injections, as well as by inhalation, resulted in mostly negative results. In an effort to eliminate any questions posed by the results of these early studies, a definitive *Maximum Tolerated Dose Study* (MTD) by nose only, lifetime inhalation in rats and hamsters, was designed in the 1980s. The MTD study appeared to confirm that RCF was an animal carcinogen under certain test conditions, e.g., extremely high concentrations of approximately 200 f/cc inhaled directly into the lungs.

A later review of the MTD pathology indicated that the animals' lungs were likely "overloaded" because of large quantities of non-fibrous particles, and that this overload condition was likely responsible for the disease observed. In fact, evaluation of the aerosol samples used confirmed the presence of significant quantities of particulate matter.

In a subsequent multi-dose animal inhalation study at 25 f/cc, 75 f/cc, and 115 f/cc; a *no observed effect level* (NOEL) was found at 25 f/cc. This level is 50 times the RCFC recommended REG of 0.5 f/cc for humans.

12. ECOLOGICAL INFORMATION

No ecological concerns have been identified.

13. DISPOSAL CONSIDERATIONS

WASTE MANAGEMENT

To prevent waste materials from becoming airborne during waste storage, transportation and disposal, a covered container or plastic bagging is recommended.

DISPOSAL

RCF, as manufactured, is not classified as a hazardous waste according to Federal regulations (40 CFR 261). Any processing, use, alteration or chemical additions to the product, as purchased, may alter the disposal requirements. Under Federal regulations, it is the waste generator's responsibility to properly characterize a waste material, to determine if it is a "hazardous" waste. Check local, regional, state or provincial regulations to identify all applicable disposal requirements.

14. TRANSPORT INFORMATION

U.S. DEPARTMENT OF TRANSPORTATION (DOT)

| | | | |
|---------------|----------------|-----------------------------|----------------|
| Hazard Class: | Not Regulated | United Nations (UN) Number: | Not Applicable |
| Labels: | Not Applicable | North America (NA) Number: | Not Applicable |
| Placards: | Not Applicable | Bill of Lading: | Product Name |

INTERNATIONAL

Canadian TDG Hazard Class & PIN: Not regulated

Not classified as dangerous goods under ADR (road), RID (train) or IMDG (ship).

15. REGULATORY INFORMATION

UNITED STATES REGULATIONS

EPA: **Superfund Amendments and Reauthorization Act (SARA)** Title III - This product does not contain any substances reportable under Sections 302, 304, 313, (40 CFR 372). Sections 311 and 312 (40 CFR 370) apply (delayed hazard).
Toxic Substances Control Act (TSCA) - RCF has been assigned a CAS number; however, it is an "article" under TSCA and therefore exempt from listing on the TSCA inventory.
Comprehensive Environmental Response, Compensation and Liability Act (CERCLA) and the **Clean Air Act (CAA)** - RCF contains fibers with an average diameter greater than one micron and thus is not considered a hazardous air pollutant.

OSHA: Comply with **Hazard Communication Standards** 29 CFR 1910.1200 and 29 CFR 1926.59 and the **Respiratory Protection Standards** 29 CFR 1910.134 and 29 CFR 1926.103.
Ceramic fibers (airborne particles of respirable size) is listed in **Proposition 65, The**

California: **Safe Drinking Water and Toxic Enforcement Act of 1986** as a chemical known to the State of California to cause cancer.

Other States: RCF products are not known to be regulated by states other than California; however, state and local OSHA and EPA regulations may apply to these products. If in doubt, contact your local regulatory agency.

INTERNATIONAL REGULATIONS

Canada: **Canadian Workplace Hazardous Materials Information System (WHMIS)** – RCF is classified as Class D2A – Materials Causing Other Toxic Effects

Canadian Environmental Protection Act (CEPA) - All substances in this product are listed, as required, on the Domestic Substance List (DSL)

European Union: **European Directive 97/69/EC** classified RCF as a Category 2 carcinogen; that is it "should be regarded as if it is carcinogenic to man."

16. OTHER INFORMATION

RCF DEVITRIFICATION

As produced, all RCF fibers are vitreous (glassy) materials which do not contain crystalline silica. Continued exposure to elevated temperatures may cause these fibers to devitrify (become crystalline). The first crystalline formation (mullite) begins to occur at approximately 985° C (1805° F). Crystalline phase silica may begin to form at temperatures of approximately 1200° C (2192° F). When the glass RCF fibers devitrify, they form a mixed mineral crystalline silica containing dust. The crystalline silica is trapped in grain boundaries within a matrix predominately consisting of mullite. The occurrence and extent of crystalline phase formation is dependent on the duration and temperature of exposure, fiber chemistry and/or the presence of fluxing agents. The presence of crystalline phases can be confirmed only through laboratory analysis of the "hot face" fiber.

IARC's evaluation of crystalline silica states "Crystalline silica inhaled in the form of quartz or cristobalite from occupational sources is carcinogenic to humans (Group 1)" and additionally notes "carcinogenicity in humans was not detected in all industrial circumstances studied." IARC also studied mixed mineral crystalline silica containing dusts such as coal dusts (containing 5 – 15 % crystalline silica) and diatomaceous earth without seeing any evidence of disease. (IARC Monograph Vol. 68, 1997). NTP lists all polymorphs of crystalline silica amongst substances which may "reasonably be anticipated to be carcinogens".

IARC and NTP did not evaluate after-service RCF, which may contain various crystalline phases. However, an analysis of after-service RCF samples obtained pursuant to an exposure monitoring agreement with the USEPA, found that in the furnace conditions sampled, most did not contain detectable levels of crystalline silica. Other relevant RCF studies found that (1) simulated after-service RCF showed little, or no, activity where exposure was by inhalation or by intraperitoneal injection; and (2) after-service RCF was not cytotoxic to macrophage-like cells at concentrations up to 320 g/cm² - by comparison, pure quartz or cristobalite were significantly active at much lower levels (circa 20 g/cm²).

RCF AFTER-SERVICE REMOVAL

Respiratory protection should be provided in compliance with OSHA standards. During removal operations, a full face respirator is recommended to reduce inhalation exposure along with eye and respiratory tract irritation. A specific evaluation of workplace hazards and the identification of appropriate respiratory protection is best performed, on a case by case basis, by a qualified industrial hygiene professional.

PRODUCT STEWARDSHIP PROGRAM

The Refractory Ceramic Fibers Coalition (RCFC) and the U.S. Occupational Safety and Health Administration (OSHA) introduced a voluntary worker protection program entitled PSP HTW (High Temperature Wools), a comprehensive, multi-faceted risk management program designed to control and reduce workplace exposures to refractory ceramic fiber (RCF). For more information regarding PSP HTW, please refer to the RCFC web site: <http://www.rcfc.net>.



MSDS Prepared By: RISK MANAGEMENT DEPARTMENT

DISCLAIMER

The information presented herein is presented in good faith and believed to be accurate as of the effective date of this Material Safety Data Sheet. Employers may use this MSDS to supplement other information gathered by them in their efforts to assure the health and safety of their employees and the proper use of the product. This summary of the relevant data reflects professional judgment; employers should note that information perceived to be less relevant has not been included in this MSDS. Therefore, given the summary nature of this document, Thermcraft, Inc. does not extend any warranty (expressed or implied), assume any responsibility, or make any representation regarding the completeness of this information or its suitability for the purposes envisioned by the user.


DEFINITIONS

| | |
|--|--|
| ACGIH: | American Conference of Governmental Industrial Hygienists |
| ADR: | Carriage of Dangerous Goods by Road (International Regulation) |
| CAA: | Clean Air Act |
| CAS: | Chemical Abstracts Service |
| CERCLA: | Comprehensive Environmental Response, Compensation and Liability Act |
| DSL: | Domestic Substances List |
| EPA: | Environmental Protection Agency |
| EU: | European Union |
| f/cc: | Fibers per cubic centimeter |
| HEPA: | High Efficiency Particulate Air |
| HMIS: | Hazardous Materials Identification System |
| HTW: | High Temperature Wools |
| IARC: | International Agency for Research on Cancer |
| IATA: | International Air Transport Association |
| IMDG: | International Maritime Dangerous Goods Code |
| mg/m³: | Milligrams per cubic meter of air |
| mmpcf: | Million particles per cubic meter |
| NFPA: | National Fire Protection Association |
| NIOSH: | National Institute for Occupational Safety and Health |
| OSHA: | Occupational Safety and Health Administration |
| 29 CFR 1910.134 & 1926.103: | OSHA Respiratory Protection Standards |
| 29 CFR 1910.1200 & 1926.59: | OSHA Hazard Communication Standards |
| PEL: | Permissible Exposure Limit (OSHA) |
| PIN: | Product Identification Number |
| PNOC: | Particulates Not Otherwise Classified |
| PNOR: | Particulates Not Otherwise Regulated |
| PSP: | Product Stewardship Program |
| RCFC: | Refractory Ceramic Fibers Coalition |
| RCRA: | Resource Conservation and Recovery Act |
| REG: | Recommended Exposure Guideline (RCFC) |
| REL: | Recommended Exposure Limit (NIOSH) |
| RID: | Carriage of Dangerous Goods by Rail (International Regulations) |
| SARA: | Superfund Amendments and Reauthorization Act |
| SARA Title III: | Emergency Planning and Community Right to Know Act |
| SARA Section 302: | Extremely Hazardous Substances |
| SARA Section 304: | Emergency Release |
| SARA Section 311: | MSDS/List of Chemicals and Hazardous Inventory |
| SARA Section 312: | Emergency and Hazardous Inventory |
| SARA Section 313: | Toxic Chemicals and Release Reporting |
| STEL: | Short Term Exposure Limit |
| SVF: | Synthetic Vitreous Fiber |
| TDG: | Transportation of Dangerous Goods |
| TLV: | Threshold Limit Value (ACGIH) |
| TSCA: | Toxic Substances Control Act |
| TWA: | Time Weighted Average |
| WHMIS: | Workplace Hazardous Materials Information System (Canada) |



- VESTIBULE BLOCK BORE:
- SOLID _____
 - 3.00" _____
 - 3.50" _____
 - 4.00" _____
 - 4.50" _____
 - 5.00" _____
 - 5.50" _____
- *REF. DWG. XVB-8621*


EXPRESS-LINE SPLIT TUBE FURNACE
 XST-6-0-24-3V
 EXTERNAL DIMENSIONS (APPROX.): 21"H. X 17"W. X 30.38"L.
 HEATED CHAMBER DIMENSION: 6.00"ID. X 24"L.
 MAX. TEMP.: 1200° C/2192° F
 6800 TOTAL WATTS, 230 VOLTS, 29.6 AMPS, 1 PHASE, 60 HZ.
 ZONE CONFIGURATION:
 THREE ZONE IND. LENGTHS: (6-12-6)
 INSULATION: LIGHTWEIGHT CERAMIC FIBER
 SHELL: CARBON STEEL
 HEATERS: (4) FH-8256-E, (2) FH-8256-C
 PAINT: BEIGE POWDER COAT
 THERMOCOUPLE TYPE: (3) PLATINEL II (TC-3)
 (1) THERMOCOUPLE TO BE SUPPLIED PER ZONE
 LOCATED AT CENTER OF EACH ZONE
 VESTIBULE: STEPPED Ø8.44" ID X 3.00"THK. X Ø10.44" OD
 MOUNT: HORIZONTAL / VERTICAL (OPENS RIGHT - LEFT)
 10 FT. INTERCONNECTING POWER CABLES IN LIQUID TITE CONDUIT
 SHALL BE SUPPLIED W/ EACH FURNACE.



A-30 SHELL ASSY: A-7802

| LEGAL AGREEMENT OF DRAWING | | | ISSUES WITH DIMENSIONAL TOLERANCES ARE AS SHOWN | | | | REV | DESCRIPTION | DATE |
|----------------------------|----------|--------------|---|-----------|-----------|-----------|-----|-------------|------|
| APPROVAL | DATE | PRODUCT TYPE | ISSUES | REVISIONS | REVISIONS | REVISIONS | | | |
| DRW. JWJ | 06/02/09 | XX | 1-1 | 1-2 | 1-3 | 1-4 | | | |
| CHK. [] | | ORIGINALS | XXX | XXX | XXX | XXX | | | |
| APPROVED | | ANALYSIS | 1-1 | 1-2 | 1-3 | 1-4 | | | |
| CORPORATION/COMPANY | | | THERMOCRAFT INC. | | | | | | |
| THERMOCRAFT INC. | | | THERMOCRAFT INC. | | | | | | |

| | | | |
|---|-------------|--|---------------|
| | | P.O. Box 19057 3350 Overdale Road Houston, Texas, U.S.A. 77077 | |
| X-LINE SPLIT TUBE FURNACE DETAIL XST-6-0-24-3V | | | |
| JOB | PLANT SCALE | DRAWING NO. | REV. SHEET OF |
| | NTS | XST6-24-3V | - X-X |



WIRING CUT-LIST:

| ITEM No. | DESC. and SIZE | LENGTH (FT) | QTY. | TOTAL POWER: |
|----------|-------------------------|-------------|------|--------------|
| 20 | 1/2" SEAL TITE CONDUIT | 10 FT. | 1 | 6800 WATTS |
| 30 | 14 GA SRML POWER COND. | 10 FT. + | 4 | @ 230 VOLTS |
| -30 | 14 GA SRML POWER COND. | 10 FT. + | 2 | 29.6 AMPS |
| 40 | 14 GA SRML GROUND GREEN | 10 FT. + | 1 | 1 PHASE |
| | | | | 60 HZ. |

 DENOTES (1) HEATER COIL.

SPECIFICATIONS.
HEATER NUMBER:

FH-8256-E

(1) COIL PER HEATER
850 WATTS PER HEATER
@ 115 VOLTS
7.4 AMPS/COIL

SPECIFICATIONS.
HEATER NUMBER:


FH-8256-C

(1) COIL PER HEATER
1700 WATTS PER HEATER
@ 230 VOLTS
7.4 AMPS/COIL

⊙ DENOTES POWER CONNECTION

| LEGAL AGREEMENT OF DRAWING | APPROVAL | DATE |
|--|----------|--------------|
| DESIGNS AND/OR INFORMATION SHOWN ON THIS DRAWING ARE PROPRIETARY. THE RECIPIENT AGREES NOT TO DISCLOSE OR REPRODUCE THIS INFORMATION IN PART OR IN WHOLE WITHOUT EXPRESS WRITTEN CONSENT OF THERMOCRAFT INC. | DRN. | JWT 06/04/09 |
| | CHK. | |
| | APP'D | |
| | APP'D | |
| CORPORATION/COMPANY | | |
| * | | |


| LET | REVISION | DFTMN | DATE |
|-----|-------------------------------|-------|----------|
| A | REVISED 16 GA. TO 14 GA. SRML | JWT | 11/02/09 |

 **Thermcraft**
Incorporated P.O. Box 12037
3950 Overdale Road
Winston-Salem, N.C. 27107

WIRING DIAGRAM (THREE ZONE)
XST-6-0-24-3V

| JOB | PLOT SCALE | DRAWING NO. | REV | SHEET | OF |
|-----|------------|-------------|-----|-------|----|
| * | NTS | XST6-24V_3W | A | X-X | |

WARNING
High Leakage Current.
Earth Connection Essential
Before Connecting Supply



COMPONENTS

- CB - CIRCUIT BREAKER, SQUARE D QOU250
- SSR1,SSR2,SSR3 -CARLO GAVAZZI RM1A23D50
- CONTROLLER - EUROTHERM 2404/CC/VH/LH/ENG
- SW1 - ARCO 06WX0591
- FB1 - FUSE BLOCK, BUCHANAN 352
- FU1,FU2 - FUSE FNM 1.00
- P1,P2,P3 - TYPE K SNAP IN PLUG SPJ-K-F
- GND1 - GROUND BAR, SQUARE D PK4GTA
- DB1 - DISTRIBUTION BLOCK, SQ D LBA261104
- TB1 - TERMINAL BLOCK SQ D 9080GM6
- TB2 - TERMINAL BLOCK, SQ D 9080GM6

WIRING DETAILS

- RED - 110VAC-208VAC CONTROL CIRCUITS
- WHITE - 110VAC-208VAC GROUNDED AC CONTROL CIRCUIT CONDUCTORS
- BLACK - CONTROL CIRCUITS 208VAC-230VAC

THERMOCOUPLE WIRING

- SIZE - 22GA, THERMOPLASTIC OUTER LAYER TO 200F, COLOR BASED ON T/C TYPE.
- SIZE - 22GA, FIBERGLASS HEAT SHIELDING OUTER LAYER TO 900F, BASED ON T/C TYPE.

| LET | ZONE | REVISION | DFTM | DATE |
|-----|------|-----------------------|------|-------|
| A | | STANDARDIZE WIRE CODE | TB | 06/09 |

| APPROVAL | DATE |
|----------|-------|
| DRN. SAO | 03/08 |
| CHK. | |
| APP'D | |
| APP'D | |

| | | | | | | |
|--------|-----|---|-------------------------|----------|------------|---------|
| | | P.O. Box 12337 3050 Overseas Road Winston-Salem, N.C. 27107 | | | | |
| | | CONTROL WIRING FOR 3-1-40-230-E15SP-C2264-X | | | | |
| S-LINE | JOB | SCALE N/A | DRAWING NO. C2264E-X | REV 1 | SHEET 1 | OF 1 |

Models 2404/2408

PID Controllers

Installation and
Operation handbook

ENG



invensys

EUROTHERM

MODELS 2408 and 2404 PID CONTROLLERS

INSTALLATION AND OPERATION HANDBOOK

| Contents | Page |
|------------|---|
| Chapter 1 | INSTALLATION..... 1-1 |
| Chapter 2 | OPERATION..... 2-1 |
| Chapter 3 | ACCESS LEVELS..... 3-1 |
| Chapter 4 | TUNING..... 4-1 |
| Chapter 5 | PROGRAMMER OPERATION..... 5-1 |
| Chapter 6 | CONFIGURATION..... 6-1 |
| Chapter 7 | USER CALIBRATION..... 7-1 |
| Appendix A | UNDERSTANDING THE ORDERING CODE..... A-1 |
| Appendix B | SAFETY and EMC INFORMATION..... B-1 |
| Appendix C | TECHNICAL SPECIFICATION..... C-1 |
| Appendix D | LOAD CURRENT MONITORING AND DIAGNOSTICS..... D-1 |
| Appendix E | PROFIBUS COMMUNICATIONS..... E-1 |
| Appendix F | RoHS..... F-1 |

“This product is covered by one or more of the following US Patents:

5,484,206; Additional patents pending.

PDS and INSTANT ACCURACY are trademarks of Eurotherm.”

Issue 11 of this handbook applies to software version 4 and includes RoHS statement.

Enhancements to Software Version 4

The following enhancements have been added to software versions 4.

- Isolated Single Logic Output Module
- Transducer Power Supply Module to provide 5 or 10Vdc to an external transducer. (Not intended for melt pressure control)
- DeviceNet communications
- Linear over range limits are +5% of high instrument range and -5% of low instrument range for all process input ranges (i.e. 0-20mA, 4-20mA, 0-10V)
- Sensor break or input open circuit faults are detected on all analogue inputs (PV1.PV2 and remote input channels)
- PV2 alarm, full scale high and low limits default to maximum and minimum display limits
- Deviation alarms are not inverted when direct acting control is selected. Alarm behaviour when using reverse acting control is unchanged
- The PD track valve positioning parameter (Pd_{tr}) has been removed

Controllers Affected:-

| | |
|--|-----------------------|
| Standard controllers – which include programmers with up to 4 programs | Version 4.11 or later |
| Setpoint programming controllers with up to 20 programs | Version 4.61 or later |
| Profibus controllers – which include programmers with up to 4 programs | Version 4.32 or later |

- The 10Amp output relay in module 4 is not available on controllers supplied after Jan 04

Related Information

- DeviceNet Communications Handbook part no. HA027506 which includes the parameter address map.
- Profibus Communications Handbook part no. HA026290
- EMC (Electromagnetic Compatibility) Installation Guide, part no. HA025464

These are available on www.eurotherm.co.uk.

Chapter 1 INSTALLATION




Figure 1-1 2408 1/8 DIN controller




Figure 1-2 2404 1/4 DIN controller

Outline dimensions Model 2408





Figure 1-3
Outline dimensions of Model 2408 controller



Outline dimensions Model 2404




Figure 1-4 Outline dimensions Model 2404 controller

The electronic assembly of the controller plugs into a rigid plastic sleeve, which in turn fits into the standard DIN size panel cut-out shown in Figures 1-3 and 1-4.

INTRODUCTION

Models 2408 and 2404 are high stability, temperature or process controllers with self and adaptive tuning. They have a modular hardware construction which accepts up to three plug-in Input/Output modules and two interface modules to satisfy a wide range of control requirements. Two digital inputs and an optional alarm relay are included as part of the fixed hardware build.

The instruments are available as:

- standard controllers - which include a basic 8-segment programmer
Models 2408/CC and 2404/CC
- setpoint programming controllers: Models 2408/CP, P4, CM and
2404/CP, P4, CM
- motorised valve controllers - which include a basic 8-segment programmer
Models 2408/VC and 2404/VC
- setpoint programming motorised valve controllers: Models 2408/VP, V4, VM and
2404/VP, V4, VM

Before proceeding, please read the chapter called, *Safety and EMC Information*.

Controller labels

The labels on the sides of the controller identify the ordering code, the serial number, and the wiring connections.

Appendix A, *Understanding the Ordering Code*, explains the hardware and software configuration of your particular controller.

MECHANICAL INSTALLATION

To install the controller

1. Prepare the control panel cut-out to the size shown in Figure 1-3, or 1-4.
2. Insert the controller through the panel cut-out.
3. Spring the upper and lower panel retaining clips into place. Secure the controller in position by holding it level and pushing both retaining clips forward.

Note: If the panel retaining clips subsequently need removing, in order to extract the controller from the control panel, they can be unhooked from the side with either your fingers, or a screwdriver.

Unplugging and plugging-in the controller

If required, the controller can be unplugged from its sleeve by easing the latching ears outwards and pulling it forward out of the sleeve. When plugging the controller back into its sleeve, ensure that the latching ears click into place in order to secure the IP65 sealing.

NEW SLEEVE DESIGN MKIII

From Jan-03 an improved design of 1/8 DIN long sleeve is shipped with all new 2408 controllers and indicators. (The month and year of manufacture are shown in the last two pairs of digits of the instrument serial number).

Details

A new sealing gasket will be fitted onto the instrument bezel. This gasket replaces the gasket which was moulded into the front of the sleeve of all previous instruments.

The gasket previously moulded into the sleeve where it fits behind the panel is now supplied as a separate item.

Reasons for the Change

This change is to ensure that IP65 sealing is reliably achieved and less physical effort is required to insert the instrument into the new sleeve.

Recommendations


1. An instrument delivered after Jan 03 should be used with the sleeve supplied
2. If the instrument is required to replace one already in use, the existing sleeve should also be replaced
3. A new instrument can be fitted into an existing sleeve by carefully removing gasket but IP65 sealing will not be maintained
4. An existing instrument can be fitted into a new sleeve but IP65 sealing will not be maintained

It is, however, possible to achieve IP65 sealing for 3 and 4 above. A gasket kit is available by quoting Part No SUB24/GAS2408.

Then:-

5. To fit a new instrument in an older sleeve carefully remove gasket. Replace it with the thinner (1.25mm) gasket from the kit
6. To fit an existing instrument into a new sleeve fit the thicker (1.6mm) gasket from the kit between the instrument and the sleeve

The seal supplied as a separate item with a new instrument, should be placed over the sleeve prior to mounting it through the panel cut out as shown below:-



ELECTRICAL INSTALLATION

This section consists of five topics:

- Rear terminal layouts
- Fixed connections
- Plug-in module connections
- Typical wiring diagrams
- Motorised valve connections.

WARNING

You must ensure that the controller is correctly configured for your application. Incorrect configuration could result in damage to the process being controlled, and/or personal injury. It is your responsibility, as the installer, to ensure that the configuration is correct. The controller may either have been configured when ordered, or may need configuring now. See Chapter 6, Configuration.

Model 2408 rear terminal layout




Figure 1-5 Rear terminal layout – Model 2408

* The ground connection is provided as a return for internal EMC filters. It is not required for safety purposes, but must be connected in order to satisfy EMC requirements.

Sensor input connections

The connections for the various types of sensor input are shown below.




Fig 1-7 Sensor input connections

PLUG-IN MODULE CONNECTIONS

Module 1, 2 and 3

Module positions 1, 2 and 3 are plug-in modules. They can be either two terminal modules of the types shown in Figure 1-7, or four terminal modules of the types shown in Table 1-1.

The tables show the connections to each module and the functions that they can perform. Module 1 is normally used for heating and module 2 for cooling although the actual functions will depend upon how the controller has been configured.

PDS modes

Table 1-8 refers to PDS modes 1 and 2.

PDS stands for 'Pulse Density Signalling' Input/Output. This is a proprietary technique for bi-directional transmission of analogue and digital data over a simple 2-wire connection.

PDS 1 mode uses a logic output module to control a TE10S solid state relay and provides a load failure alarm.

PDS 2 mode uses a logic output module to control a TE10S solid state relay, provide load/SSR failure alarms, and read back the load current for display on the controller.

Two terminal modules

Note: Module 1 is connected to terminals 1A and 1B
 Module 2 is connected to terminals 2A and 2B
 Module 3 is connected to terminals 3A and 3B.





| Module type | Terminal identity | | | | Possible functions |
|--|---|---|--------|---|---|
| | A | B | C | D | |
| Relay: 2-pin (2A, 264 Vac max.) |  | | Unused | | Heating, cooling, alarm, program event, valve raise, or valve lower |
| Logic - non-isolated (18Vdc at 20mA) |  | | Unused | | Heating, cooling, PDSIO mode 1, PDSIO mode 2, program event |
| Triac (1A, 30 to 264Vac) |  | | Unused | | Heating, cooling, program event, valve raise, or valve lower |
| DC output: - non-isolated (10Vdc, 20mA max.) |  | | Unused | | Heating, or cooling, or retransmission of PV, setpoint, or control output |

Table 1-1 Two terminal module connections

Snubbers











The relay and triac modules have an internal 15nF/100Ω ‘snubber’ connected across their output, which is used to prolong contact life and to suppress interference when switching inductive loads, such as mechanical contactors and solenoid valves.

WARNING

When the relay contact is open, or the triac is off, the snubber circuit passes 0.6mA at 110Vac and 1.2mA at 240Vac. You must ensure that this current, passing through the snubber, will not hold on low power electrical loads. It is your responsibility as the installer to ensure that this does not happen. If the snubber circuit is not required, it can be removed from the relay module (BUT NOT THE TRIAC) by breaking the PCB track that runs crosswise, adjacent to the edge connectors of the module. This can be done by inserting the blade of a small screwdriver into one of the two slots that bound it, and twisting.

Four terminal modules

Note: Module 1 is connected to terminals 1A, 1B, 1C and 1D
 Module 2 is connected to terminals 2A, 2B, 2C and 2D
 Module 3 is connected to terminals 3A, 3B, 3C and 3D

| Module type | Terminal identity | | | | Possible functions |
|---|---|-----------|---|--------|---|
| | A | B | C | D | |
| Relay: changeover (2A, 264 Vac max.) |  | | | | Heating, cooling, alarm, or program event output |
| DC control: Isolated (10V, 20mA max.) | + | - | | | Heating, or cooling |
| 24Vdc transmitter supply * | + | - | | | To power process inputs |
| Potentiometer input 100Ω to 15KΩ * | | +0.5Vdc |  | 0V | Motorised Valve Position feedback |
| DC retransmission | + | - | | | Retrans. of setpoint, or process value |
| DC remote input or Process Value 2 (Module 3 only) | 0-10Vdc | RT source | ±100mV 0-20mA | COM | Remote Setpoint Second PV |
| Dual output modules | | | | | |
| Dual relay (2A, 264 Vac max.) |  | |  | | Heating + cooling Dual alarms Valve raise & lower |
| Dual Triac (1A, 30 to 264Vac) |  | |  | | Heating + cooling Valve raise & lower |
| Dual logic + relay (Logic is non-isolated) |  | |  | | Heating + cooling |
| Dual Logic + triac (Logic is non-isolated) |  | |  | | Heating + cooling |
| Triple logic input and output modules - see ratings on the next page | | | | | |
| Triple contact input | Input 1 | Input 2 | Input 3 | Common | |
| Triple logic input | Input 1 | Input 2 | Input 3 | Common | |
| Triple logic output | Output 1 | Output 2 | Output 3 | Common | Program events |


* Can be ordered fitted in module positions 2 & 3 only.

| Module type | Terminal identity | | | | Possible functions |
|-------------------------|-------------------|---|---|---|---|
| | A | B | C | D | |
| Isolated Logic Output | + | | | - | This is a fully isolated module which can be fitted in all three module slots. It may be used for heating, cooling or events outputs up to 18Vdc at 20mA. |
| Transducer Power Supply | + | - | | | This provides fully isolated 5 or 10Vdc to power external transmitters up to 20mA. It can be fitted in module slots 1 and 2. |

Table 1-2 Four terminal module connections

Connections for Process Value 2 in module position 3

The diagrams below show the connections for the various types of input. The input will have been configured in accordance with the ordering code.



Triple Logic Input and output ratings

- Triple logic input (current sinking)
 - OFF state: -3 to 5Vdc
 - ON state: 10.8 to 30Vdc(max), at 2 to 8mA
- Triple contact closure or open collector transistor input
 - Internally generated switching Vdc & mA: 15 to 19Vdc at 10 to 14mA
 - OFF state >28KΩ input resistance
 - OFF state voltage >14Vdc
 - ON state <100Ω resistance
 - ON state voltage <1.0Vdc
- Triple logic output (current sourcing)
 - OFF state output 0 to 0.7Vdc.
 - ON state output 12 to 13Vdc, at up to 8mA.

COMMUNICATION MODULES 1 AND 2

All 2408 and 2404 controllers can be fitted with up to two plug-in communications modules.

Only one of the two modules can be for serial communications and this will normally be installed in position COMMS 1 (although it is possible to install the serial communications module in position COMMS 2. Serial communications may be configured for either Modbus or EI bisynch protocol.

It is also possible to fit a PDS module in one or other of these positions.


Possible module types are shown in the table below.

| Communications module 1 | Terminal identity (COMMS 1) | | | | | |
|--------------------------------------|-----------------------------|----------|----------|--------|---------|---------|
| | HA | HB | HC | HD | HE | HF |
| 2-wire EIA-485 serial communications | – | – | – | Common | A (+) | B (–) |
| EIA-232 serial communications | – | – | – | Common | Rx | Tx |
| 4-wire EIA-485 serial communications | – | A' (Rx+) | B' (Rx–) | Common | A (Tx+) | B (Tx–) |
| PDS Setpoint retransmission | – | – | – | – | Signal | Common |

| Communications module 2 | Terminal identity (COMMS 2) | | |
|-----------------------------|-----------------------------|--------|--------|
| | JD | JE | JF |
| PDS Setpoint retransmission | – | Signal | Common |
| PDS Setpoint input | – | Signal | Common |

Table 1-3 Communication modules 1 and 2 connections

Wiring of 2-wire EIA-485 serial communications link



2-wire EIA-485 is a connection which allows up to 32 controllers to be multi-dropped from a single communications link over a distance of up to 1.2Km. To ensure reliable operation of the communications link, (without data corruption due to noise or line reflections) the connections between the controller should be made using a twisted pair of wires inside a screened cable with the connections terminated with resistors in the manner shown in this diagram. This diagram also shows the use of a KD485 converter to connect the EIA-485 link into a standard EIA-232 computer port.

Note:
 All resistors are 220 ohm 1/4W carbon composition.
 Local grounds are at equipotential. Where equipotential is not available wire into separate zones using a galvanic isolator.
 Use a repeater (KD845) for more than 32 units.

Figure 1-9 EIA-485 wiring

DeviceNet


Instruments fitted with software versions 4 onwards can be fitted with DeviceNet communications. The following shows the wiring connections for DeviceNet.

| Terminal Reference | CAN Label | Color Chip | Description |
|--------------------|-----------|------------|--|
| HA | V+ | Red | DeviceNet network power positive terminal. Connect the red wire of the DeviceNet cable here. If the DeviceNet network does not supply the power, connect to the positive terminal of an external 11-25 Vdc power supply. |
| HB | CAN_H | White | DeviceNet CAN_H data bus terminal. Connect the white wire of the DeviceNet cable here. |
| HC | SHIELD | None | Shield/Drain wire connection. Connect the DeviceNet cable shield here. To prevent ground loops, ground the DeviceNet network in only one location. |
| HD | CAN_L | Blue | DeviceNet CAN_L data bus terminal. Connect the blue wire of the DeviceNet cable here. |
| HE | V- | Black | DeviceNet network power negative terminal. Connect the black wire of the DeviceNet cable here. If the DeviceNet network does not supply the power, connect to the negative terminal of an external 11-25 Vdc power supply. |
| HF | | | Connect to instrument earth |

Note: Power taps are recommended to connect the DC power supply to the DeviceNet trunk line. Power taps include:

- A Schottky Diode to connect the power supply V+ and allows for multiple power supplies to be connected.
- 2 fuses or circuit breakers to protect the bus from excessive current which could damage the cable and connectors.
- The earth connection, HF, to be connected to the main supply earth terminal.


Example of Devicenet Wiring



To configure DeviceNet Communications see Chapter 6.

ProfiBus Wiring

Controllers supplied with model numbers 2408f and 2404f are fitted with ProfiBus communications modules fitted in the H slot. Further details of ProfiBus communications is given in Appendix E and the ProfiBus Communications handbook part number HA026290. This handbook can be downloaded from www.eurotherm.co.uk.



TYPICAL WIRING DIAGRAM




Fig 1-10 Typical wiring diagram, Model 2408 Controller

Safety requirements for permanently connected equipment state:

- A switch or circuit breaker shall be included in the building installation
- It shall be in close proximity to the equipment and within easy reach of the operator
- It shall be marked as the disconnecting device for the equipment.

Note: a single switch or circuit breaker can drive more than one instrument.

For logic drive capability see following chart:-

Logic Drive Fan Out

The logic outputs from the 2400 series controllers are capable of driving more than one solid state relay (SSR) in series or parallel. The following table shows the number of SSRs which can be driven depending on type of SSR. S = Series; P = Parallel.

| | Drive mA | SVDA | RVDA | TE10S | 425S | | |
|--------------|----------|----------|----------|----------|-----------|-----------|------------|
| | | Logic DC | Logic DC | Logic DC | Logic 10V | Logic 24V | Logic 20mA |
| Logic | 18V@20 | 4S 6P | 4S 3P | 3S 2P | 3S 3P | 1S 2P | 6S 1P |
| Triple logic | 12V@9 | 3S 3P | 2S 1P | 2S 1P | 2S 1P | 1 | 4S 1P |

| | 450 | | | TC1027 CE | TE200S | TC2000 CE | RS3D A |
|--------------|----------|------|-------------|-----------|----------|-----------|----------|
| | Standard | TTL | Multi-drive | Logic V | Logic DC | Logic DC | Logic DC |
| Logic | 2S 3P | 1S2P | 6S 1P | 3S 3P | 3S 3P | 3S 1P | 4S 2P |
| Triple logic | 1 | 1 | 4S 1P | 2S 1P | 2S 1P | 0 | 0 |

MOTORIZED VALVE CONNECTIONS

Motorised valves will normally be wired either to dual relay, or dual triac, output modules installed in the Module 1 position, or to single channel relay and triac outputs installed in Module positions 1 and 2. In the latter case, the convention is to configure output 1 as the raise output and output 2 as the lower output.

Depending on the configuration, control of the valve is achieved in one of three ways:

1. With no position feedback potentiometer.
2. With a feedback potentiometer used to monitor the valve's position. It does not influence the control.
3. With a feedback potentiometer, where the valve's position is controlled in response to the signal from it.




Fig 1-11 Motorised valve connections

Chapter 2 OPERATION

This chapter has nine topics:

- FRONT PANEL LAYOUTS
- BASIC OPERATION
- OPERATING MODES
- AUTOMATIC MODE
- MANUAL MODE
- PARAMETERS AND HOW TO ACCESS THEM
- NAVIGATION DIAGRAM
- PARAMETER TABLES
- ALARMS

FRONT PANEL LAYOUTS




Figure 2-1 Model 2408 front panel layout




Figure 2-2 Model 2404 front panel layout







| Button or indicator | Name | Explanation |
|---|--------------------|---|
| OP1 | Output 1 | When lit, it indicates that the output installed in module position 1 is on. This is normally the heating output on a temperature controller. |
| OP2 | Output 2 | When lit, it indicates that the output installed in module position 2 is on. This is normally the cooling output on a temperature controller. |
| SP2 | Setpoint 2 | When lit, this indicates that setpoint 2, (or a setpoint 3-16) has been selected. |
| REM | Remote setpoint | When lit, this indicates that a remote setpoint input has been selected. 'REM' will also flash when communications is active. |
|  | Auto/Manual button | <p>When pressed, this toggles between automatic and manual mode:</p> <ul style="list-style-type: none"> • If the controller is in automatic mode the AUTO light will be lit. • If the controller is in manual mode, the MAN light will be lit. <p>The Auto/Manual button can be disabled in configuration level.</p> |
|  | Run/Hold button | <ul style="list-style-type: none"> • Press once to start a program (RUN light on.) • Press again to hold a program (HOLD light on) • Press again to cancel hold and continue running (HOLD light off and RUN light ON) • Press and hold in for two seconds to reset a program (RUN and HOLD lights off) <p>The RUN light will flash at the end of a program. The HOLD light will flash during holdback or when a PDS retransmission output is open circuit.</p> |
|  | Page button | Press to select a new list of parameters. |
|  | Scroll button | Press to select a new parameter in a list. |
|  | Down button | Press to decrease a value in the lower readout. |
|  | Up button | Press to increase a value in lower readout. |

Figure 2-3 Controller buttons and indicators

BASIC OPERATION

Switch on the power to the controller. It runs through a self-test sequence for about three seconds and then shows the measured temperature, or process value, in the upper readout and the target value, called the *setpoint*, in the lower readout. This is called the **Home** display.








Figure 2-4 Home display

You can adjust the setpoint by pressing the  or  buttons. Two seconds after releasing either button, the display blinks to show that the controller has accepted the new value.

OP1 will light whenever output 1 is ON. This is normally the heating output when used as a temperature controller.

OP2 will light whenever output 2 is ON. This is normally the cooling output when used as a temperature controller.

Note: You can get back to this display at any time by pressing  and  together. Alternatively, you will always be returned to this display if no button is pressed for 45 seconds, or whenever the power is turned on.

Alarms

If the controller detects an alarm condition, it flashes an alarm message in the Home display. For a list of all the alarm messages, their meaning and what to do about them, see *Alarms* at the end of this chapter.

OPERATING MODES

The controller has two basic modes of operation:

- **Automatic mode** in which the output is automatically adjusted to maintain the temperature or process value at the setpoint.
- **Manual mode** in which you can adjust the output independently of the setpoint.


You toggle between the modes by pressing the AUTO/MAN button. The displays which appear in each of these modes are explained in this chapter.

Two other modes are also available:

- **Remote Setpoint mode**, in which the setpoint is generated from an external source. In this mode, the REM light will be on.
- **Programmer mode** which is explained in Chapter 5, *Programmer Operation*.

AUTOMATIC MODE

You will normally work with the controller in automatic mode. If the MAN light is on, press the AUTO/MAN button to select automatic mode. The AUTO light comes on.



The Home display

Check that the AUTO light is on.
The upper readout shows the measured temperature.
The lower readout shows the setpoint.

To adjust the setpoint up or down, press or .

(Note: If Setpoint Rate Limit has been enabled, then the lower readout will show the active setpoint. If or is pressed, it will change to show and allow adjustment of, the target setpoint.)

Press once.

Display units

A single press of will flash the display units for 0.5 seconds, after which you will be returned to the **Home** display.

Flashing of the display units may have been disabled in configuration in which case a single press will take you straight to the display shown below.

Press twice

% Output power demand


The % output power demand is displayed in the lower readout. This is a read-only value. You cannot adjust it. Press and together to return to the **Home** display.

Press

Pressing from the Output Power display may access further parameters. These may be in this scroll list if the 'Promote' feature has been used (see Chapter 3, *Edit Level*). When you reach the end of this scroll list, pressing will return you to the **Home** display.

MANUAL MODE

If the AUTO light is on, press the AUTO/MAN button to select manual mode. The MAN light comes on.



The Home display

Check that the MAN light is on.

The upper readout shows the measured temperature, or process value. The lower readout shows the % output.

To adjust the output, press or .

(Note: If Output Rate Limit has been enabled, then the lower readout will show the working output. If or is pressed, it will change to show and allow adjustment of, the target output.)

Press once.

Display units

A single press of flashes the display units for 0.5 seconds, after which you are returned to the Home display. Flashing of the display units may have been disabled in configuration, in which case a single press will take you straight to the display shown below.

Press twice.

Setpoint

To adjust the setpoint value, press or .

Press .

Pressing from the Output Power display may access further parameters. These may be in this scroll list if the 'Promote' feature has been used (see Chapter 3, *Edit Level*). When you reach the end of this scroll list, pressing will return you to the **Home** display.

PARAMETERS AND HOW TO ACCESS THEM

Parameters are settings, within the controller, that determine how the controller will operate. For example, alarm setpoints are parameters that set the points at which alarms will occur. For ease of access, the parameters are arranged in lists as shown in the navigation diagram on Pages 2-10 and 2-11. The lists are:

- | | | |
|-------------------------|----------------------|----------------------------|
| <i>Home list</i> | <i>PID list</i> | <i>Communications list</i> |
| <i>Run list</i> | <i>Motor list</i> | <i>Information list</i> |
| <i>Programming list</i> | <i>Setpoint list</i> | <i>Access list.</i> |
| <i>Alarm list</i> | <i>Input list</i> | |
| <i>Autotune list</i> | <i>Output list</i> | |

Each list has a 'List Header' display.

List header displays




Figure 2-5 Typical list header display

A list header can be recognised by the fact that it always shows 'L, 5E' in the lower readout. The upper readout is the name of the list. In the above example, 'AL' indicates that it is the Alarm list header. List header displays are read-only.

To step through the list headers, press . Depending upon how your controller has been configured, a single press may momentarily flash the display units. If this is the case, a double press will be necessary to take you to the first list header. Keep pressing to step through the list headers, eventually returning you to the Home display.

To step through the parameters within a particular list, press . When you reach the end of the list, you will return to the list header. From within a list you can return to the current list header at any time can by pressing . To step to the next list header, press once again.

Parameter names

In the navigation diagram, each box shows the display for a selected parameter. The Operator parameter tables, later in this chapter, list all the parameter names and their meanings.

The navigation diagram shows all the parameters that can, *potentially*, be present in the controller. In practice, a limited number of them appear, as a result of the particular configuration.

The shaded boxes in the diagram indicate parameters that are hidden in normal operation. To view all the available parameters, you must select Full access level. For more information about this, see Chapter 3, *Access Levels*.

Parameter displays




Figure 2-6 Typical parameter display

Parameter displays show the controller's current settings. The layout of parameter displays is always the same: the upper readout shows the parameter name and the lower readout its value. In the above example, the parameter name is *IFSL* (indicating *Alarm 1, full scale low*), and the parameter value is *10.0*.

To change the value of a parameter

First, select the required parameter.

To change the value, press either  or . During adjustment, single presses change the value by one digit.

Keeping the button pressed speeds up the rate of change.

Two seconds after releasing either button, the display blinks to show that the controller has accepted the new value.

NAVIGATION DIAGRAM (PART A) (The parameters that appear depend upon how the controller has been configured)




Figure 2-7a Navigation diagram (Part A)

NAVIGATION DIAGRAM (PART B)




Figure 2-7b Navigation diagram (Part B)

PARAMETER TABLES

| Name | Description |
|------|-------------|
|------|-------------|

| Home list | |
|---|--|
| Home | Measured value and Setpoint |
| OP | % Output level |
| SP | Target setpoint (if in Manual mode) |
| m-A | Auto-man select |
| AmPS | Heater current (With PDSIO mode 2) |
| C, d | Customer defined identification number |
| + Extra parameters, if the 'Promote' feature has been used (see Chapter 3, <i>Edit Level</i>). | |

| Program run list – Present only in setpoint programming controllers | |
|---|--|
| PrG | Active program number (Only on 4, or 20, program versions) |
| Stat | Program status (<i>OFF, run, hold, HbAc, End</i>) |
| PSP | Programmer setpoint |
| CYC | Number of cycles remaining in the program |
| SEG | Active segment number |
| SEYP | Active segment type |
| SEgt | Segment time remaining in the segment units |
| tGt | Target setpoint |
| rAtE | Ramp rate (if a rate segment) |
| PrGt | Program time remaining in hours |
| FRSt | Fast run through program (<i>no / YES</i>) |
| out.n | Event output states (<i>OFF / on</i>) (<i>not 8-segment programmer</i>) |
| SYnc | Segment synchronisation (<i>no / YES</i>) (<i>not 8-segment programmer</i>) |
| SEgd | Flash active segment type in the lower readout of the home display (<i>no / YES</i>) |

| Name | Description |
|------|-------------|
|------|-------------|

| | | | | | | | |
|--|--|------|------|------|------|------|---|
| Prog | Program edit list – Present only in setpoint programming controller. For a fuller explanation of these parameters refer to Chapter 5 | | | | | | |
| PrGn | Select program number (Only on 4, or 20, program versions) | | | | | | |
| Hb | Holdback type for the program as a whole (if configured)(OFF, Lo, Hi, or bAnd) | | | | | | |
| HbU | Holdback value (in display units) | | | | | | |
| rmPU | Ramp units (SEc, mi n, or Hour) [for both rmPr and rmPt type segments] | | | | | | |
| dwLU | Dwell units (SEc, mi n, or Hour) | | | | | | |
| CYCn | Number of program cycles (1 to 999, or 'cont') | | | | | | |
| SEGn | Segment number | | | | | | |
| TYPE | Segment type:(End) (rmPr =ramp rate) (rmPt =ramp time) (dwEl) (STEP) (cALL) | | | | | | |
| <i>The following parameters depend on the TYPE selected, as shown below.</i> | | | | | | | |
| | End | rmPr | rmPt | dwEl | STEP | cALL | |
| Hb | | | | | | | Holdback type: OFF, Lo, Hi, or bAnd |
| tGt | | ' | ' | | ' | | Target setpoint for a 'rmPr' or 'STEP' segment |
| rAtE | | ' | | | | | Ramp rate for a 'rmPr' segment |
| dur | | | ' | ' | | | 'dwEl' time / Time to target for a 'rmPt' segment |
| PrGn | | | | | | ' | cALLed Program number |
| cYCn | | | | | | ' | No. of cycles of cALLed program |
| outn | ' | ' | ' | ' | ' | | Event output: OFF/on (not 8-segment programmer) |
| SYnc | ' | ' | ' | ' | ' | | Segment synchronisation: no/YES (not 8-seg progr) |
| Endt | ' | | | | | | End of prog – dwEl, SEt, S OP |

| Name | Description |
|------|-------------|
|------|-------------|

| AL Alarm list | |
|----------------------|------------------------|
| 1--- | Alarm 1 setpoint value |
| 2--- | Alarm 2 setpoint value |
| 3--- | Alarm 3 setpoint value |
| 4--- | Alarm 4 setpoint value |

In place of dashes, the last three characters indicate the alarm type. See alarm types table:

| | |
|--------------|---------------------------------------|
| HY 1 | Alarm 1 Hysteresis (display units) |
| HY 2 | Alarm 2 Hysteresis (display units) |
| HY 3 | Alarm 3 Hysteresis (display units) |
| HY 4 | Alarm 4 Hysteresis (display units) |
| Lb t | Loop Break Time in minutes |
| d, AG | Enable Diagnostic alarms 'no' / 'YES' |

Alarm types table

| | |
|------------------------|----------------------------------|
| -FSL | PV Full scale low alarm |
| -FSH | PV Full scale high alarm |
| -dEv | PV Deviation band alarm |
| -dH_i | PV Deviation high alarm |
| -dLo | PV Deviation low alarm |
| -LCr | Load Current low alarm |
| -HCr | Load Current high alarm |
| -FL2 | Input 2 Full Scale low alarm |
| -FH2 | Input 2 Full Scale high alarm |
| -LOP | Working Output low alarm |
| -HOP | Working Output high alarm |
| -LSP | Working Setpoint low alarm |
| -HSP | Working Setpoint high alarm |
| 4rAt | Rate of change alarm (AL 4 only) |

| Autotune list | |
|----------------------|---|
| tunE | One-shot autotune enable |
| drA | Adaptive tune enable |
| drAt | Adaptive tune trigger level in display units. Range = 1 to 9999 |
| Adc | Automatic Droop Compensation (PD control only) |

| Name | Description |
|------|-------------|
|------|-------------|

| P₁ d PID list | |
|---------------------------------|--|
| GSP | If Gain Scheduling has been enabled (see Chapter 4), this parameter sets the PV below which 'P ₁ d. 1' is active and above which 'P ₁ d. 2' is active. |

| | |
|------------------------|---|
| SEt | 'P ₁ d. 1' or 'P ₁ d. 2' selected |
| Pb | Proportional Band (SEt 1) (in display units) |
| t_i | Integral Time in secs (SEt 1) |
| t_d | Derivative Time in secs (SEt 1) |
| rES | Manual Reset (%) (SEt 1) |
| Hcb | Cutback High (SEt 1) |
| Lcb | Cutback Low (SEt 1) |
| rELC | Relative Cool Gain (SEt 1) |
| Pb2 | Proportional Band (SEt 2) |
| t_i 2 | Integral Time in secs (SEt 2) |
| t_d 2 | Derivative Time in secs (SEt 2) |
| rES2 | Manual Reset (%) (SEt 2) |
| Hcb2 | Cutback High (SEt 2) |
| Lcb2 | Cutback Low (SEt 2) |
| rEL2 | Relative Cool Gain (SEt 2) |

The following three parameters are used for cascade control. If this facility is not being used, then they can be ignored.

| | |
|------------------------|---------------------------------|
| FFPb | SP, or PV, feedforward propband |
| FFt_r | Feedforward trim % |
| FFdu | PID feedforward limits ± % |

| Motor list - see Table 4-3 | |
|-----------------------------------|---------------------------------|
| t_m | Valve travel time in seconds |
| l n.t | Valve inertia time in secs |
| bAc.t | Valve backlash time in secs |
| mP.t | Minimum ON time of output pulse |
| Ubr | Valve sensor break strategy |

| Name | Description |
|------|-------------|
|------|-------------|

| SP | Setpoint list |
|-------|---|
| SSEL | Select SP 1 to SP 16, depending on configuration |
| L-r | Local (Loc) or remote (rmt) setpoint select |
| SP 1 | Setpoint one value |
| SP 2 | Setpoint two value |
| rmtSP | Remote setpoint value |
| rmtt | Remote setpoint trim |
| rRt | Ratio setpoint |
| Loc t | Local setpoint trim |
| SP L | Setpoint 1 low limit |
| SP H | Setpoint 1 high limit |
| SP2L | Setpoint 2 low limit |
| SP2H | Setpoint 2 high limit |
| SPrr | Setpoint Rate Limit |
| Hbty | Holdback Type for setpoint rate limit (OFF, Lo, Hi, or bAnd) |
| Hb | Holdback Value for setpoint rate limit in display units. (Hbty ≠ OFF) |

| , P | Input list |
|---------------------------------|--|
| F, Lt | IP1 filter time constant (0.0 - 999.9 seconds). |
| FLt2 | IP2 filter time constant (0.0 - 999.9 seconds). |
| Hi, J P Lo, J P | Transition of control between , P, 1 and , P, 2. (if configured) The transition region is set by the values of 'Lo, J P' and 'Hi, J P'. PV = , P, 1 below 'Lo, J P' PV = , P, 2 above 'Hi, J P' |
| F, 1 F, 2 | Derived function, (if configured) PV = (F, 1 x , P, 1) + (F, 2 x , P, 2). 'F, 1' and 'F, 2' are scalars with the range -9.99 to 10.00 |
| PU, P | Selects , P, 1 or , P, 2 |
| <i>Continued in next column</i> | |

| Name | Description |
|------|-------------|
|------|-------------|

| , P | Input list - continued |
|---|--|
| <i>The next 3 parameters appear if User Calibration has been enabled. (Refer to Chapter 7.) By default they are hidden when in Operator level. To prevent unauthorised adjustment, we recommend that they are only made available in Full access level.</i> | |
| CAL | 'FACT' - reinstates the factory calibration and disables User calibration. Next 2 parameters will not appear. 'USER' - reinstates any previously set User calibration. All parameters below now appear. |
| CAL 5 | Selected calibration point - 'none', , P 1L, , P 1H, , P 2L, , P 2H |
| Adj * | User calibration adjust, if CAL 5 = , P 1L, , P 1H, , P 2L, , P 2H |
| OFF 1 | IP1 calibration offset |
| OFF 2 | IP2 calibration offset |
| mU, 1 | IP1 measured value (at terminals) |
| mU, 2 | IP2 measured value (at terminals), if DC input in Module 3 position |
| CJC, 1 | IP1 cold junction temp. reading |
| CJC, 2 | IP2 cold junction temp. reading |
| L, 1 | IP1 linearised value |
| L, 2 | IP2 linearised value |
| PUSL | Shows the currently selected PV input - , P, 1 or , P, 2 |

** Do not make adjustments using the Adj parameter unless you wish to change the controller calibration.*

| Name | Description |
|------|-------------|
|------|-------------|

| oP | Output list |
|---|--|
| <i>Does not appear if Motorised Valve control configured.</i> | |
| OPLo | Low power limit (%) |
| OPHi | High power limit (%) |
| OPrr | Output Rate Limit (% per sec) |
| FOP | Forced output level (%) |
| CYCH | Heat cycle time (0.2S to 999.9S) |
| hYSH | Heat hysteresis (display units) |
| ontH | Heat output min. on-time (secs) Auto (0.05S), or 0.1 - 999.9S |
| CYCL | Cool cycle time (0.2S to 999.9S) |
| hYSL | Cool hysteresis (display units) |
| ontL | Cool output min. on-time (secs) Auto (0.05S), or 0.1 - 999.9S |
| HCdb | Heat/cool deadband (display units) |
| EndP | To set power level in end segment |
| SbOP | Sensor Break Output Power (%) |

| cmS | Comms list |
|-------------|------------------------|
| Addr | Communications Address |

| cmS | DeviceNet (additional parameters) |
|-------------|--|
| nwSt | Indicates network status |
| run | Network connected and operational |
| rdy | Network connected but not operational |
| offL | Network not connected |

| info | Information list |
|---------------------------------|--|
| diSP | Configure lower readout of Home display to show: UPoS Valve position Std Standard - display setpoint AmPS Load current in amps OP Output STAT Program status PrEt Program time remaining in hours L₂ Process value 2 rAt Ratio setpoint PrG Selected program number rSP Remote setpoint |
| LoGL | PV minimum |
| LoGH | PV maximum |
| LoGA | PV mean value |
| LoGt | Time PV above Threshold level |
| LoGw | PV Threshold for Timer Log |
| <i>Continued in next column</i> | |

| Name | Description |
|------|-------------|
|------|-------------|

| info | Information list - continued |
|-------------|--|
| rESL | Logging Reset - 'YES/no' <i>The following set of parameters is for diagnostic purposes.</i> |
| wOP | Working output |
| FFOP | Feedforward component of output |
| UD | PID output to motorised valve |



| ACCESS | Access List |
|---------------|--|
| codE | Access password |
| Goto | Goto level - OPER , FULL , Edt or conF |
| ConF | Configuration password |

ALARMS

Alarm annunciation

Alarms are flashed as messages in the Home display. A new alarm is displayed as a double flash followed by a pause, old (acknowledged) alarms as a single flash followed by a pause. If there is more than one alarm condition, the display cycles through all the relevant alarm messages. Table 2-1 and Table 2-2 list all of the possible alarm messages and their meanings.

Alarm acknowledgement and resetting

Pressing both  and  at the same time will acknowledge any new alarms and reset any latched alarms.

Alarm modes

Alarms will have been set up to operate in one of several modes, either:

- **Non-latching**, which means that the alarm will reset automatically when the Process Value is no longer in the alarm condition.
- **Latching**, which means that the alarm message will continue to flash even if the alarm condition no longer exists and will only clear when reset.
- **Blocking**, which means that the alarm will only become active after it has first entered a safe state on power-up.

Alarm types

There are **two** types of alarm: **Process alarms** and **Diagnostic alarms**.

Process alarms

These warn that there is a problem with the process which the controller is trying to control.

| Alarm Display | What it means |
|---------------|--------------------------|
| <u>F</u> SL* | PV Full Scale Low alarm |
| <u>F</u> SH* | PV Full Scale High alarm |
| <u>d</u> Eu* | PV Deviation Band alarm |
| <u>d</u> Hi * | PV Deviation High alarm |
| <u>d</u> Lo* | PV Deviation Low alarm |
| <u>L</u> Cr* | Load Current Low alarm |
| <u>H</u> Cr* | Load Current High alarm |

| Alarm Display | What it means |
|---------------|--|
| <u>F</u> L2* | Input 2 Full Scale Low alarm |
| <u>F</u> H2* | Input 2 Full Scale High alarm |
| <u>L</u> OP* | Working Output Low alarm |
| <u>H</u> OP* | Working Output High alarm |
| <u>L</u> SP* | Working Setpoint Low alarm |
| <u>H</u> SP* | Working Setpoint High alarm |
| <u>4</u> rAL | PV Rate of change alarm <i>Always assigned to Alarm 4</i> |

* In place of the dash, the first character will indicate the alarm number.

Table 2-1 Process alarms

Diagnostic alarms

These indicate that a fault exists in either the controller or the connected devices.

| Display shows | What it means | What to do about it |
|---------------|---|--|
| EEEr | <i>Electrically Erasable Memory Error:</i> The value of an operator, or configuration, parameter has been corrupted. | This fault will automatically take you into Configuration level. Check all of the configuration parameters before returning to Operator level. Once in Operator level, check all of the operator parameters before resuming normal operation. If the fault persists, or occurs frequently, contact your supplier |
| Sbr | <i>Sensor Break:</i> Input sensor is unreliable or the input signal is out of range. | Check that the sensor is correctly connected. |
| Lbr | <i>Loop Break</i> The feedback loop is open circuit. | Check that the heating and cooling circuits are working properly. |
| LdF | <i>Load failure</i> Indication that there is a fault in the heating circuit or the solid state relay. | This is an alarm generated by feedback from a TE10S solid state relay (SSR) operating in PDSIO mode 1 - see Chapter 1, <i>Electrical Installation</i> . It indicates either an open or short circuit SSR, blown fuse, missing supply or open circuit heater. |
| SSrF | <i>Solid state relay failure</i> Indication that there is a fault in the solid state relay. | This is an alarm generated by feedback from a TE10S solid state relay (SSR) operating in PDSIO mode 2 - see Chapter 1, <i>Electrical Installation</i> . It indicates either an open or short circuit condition in the SSR. |
| HtrF | <i>Heater failure</i> Indication that there is a fault in heating circuit. | This is an alarm generated by feedback from a TE10S solid state relay (SSR) operating in PDSIO mode 2 - see Chapter 1, <i>Electrical Installation</i> . It indicates either a blown fuse, missing supply, or open circuit heater. |
| CtOP | <u>C</u> urrent <u>T</u> ransformer <u>O</u> pen <u>C</u> ircuit | Indicates that the PDS input is open circuit. Mode 5 only |
| CtSh | <u>C</u> urrent <u>T</u> ransformer <u>S</u> hort <u>C</u> ircuit | Indicates that the PDS input is short circuit Mode 5 only |
| HwEr | <i>Hardware error</i> Indication that a module is of the wrong type, missing, or faulty. | Check that the correct modules are fitted. |

| | | |
|---------------|---|---|
| no I O | No I/O None of the expected I/O modules is fitted. | This error message normally occurs when pre-configuring a controller without installing any of the required I/O modules. |
| rmIF | Remote input failure. Either the PDSIO input, or the remote DC input, is open or short circuit | Check for open, or short circuit wiring on the PDSIO, or remote DC, input. |
| LLLL | Out of range low reading | Check the value of the input. |
| HHHH | Out of range high reading | Check the value of the input. |
| Err 1 | Error 1: ROM self-test fail | Return the controller for repair. |
| Err2 | Error 2: RAM self-test fail | Return the controller for repair. |
| Err3 | Error 3: Watchdog fail | Return the controller for repair. |
| Err4 | Error 4: Keyboard failure Stuck button, or a button was pressed during power up. | Switch the power off and then on, without touching any of the controller buttons. |
| Err5 | Error 5: Faulty internal communications. | Check printed circuit board interconnections. If the fault cannot be cleared, return the controller for repair. |
| Err6 | Digital filter chip faulty or loose board inside controller | Return the controller for repair. |
| Err7 | PV id failure/PSU failure | Return the controller for repair. |
| Err8 | Module 1 id error | Faulty or loose module or may be isolation problem |
| Err9 | Module 2 id error | Faulty or loose module or may be isolation problem |
| ErrA | Module 3 id error | Faulty or loose module or may be isolation problem |
| dCF | DC output fail | Return the controller for repair |
| tuEr | Tune error – shown If any one stage of the auto-tuning process exceeds two hours | Check response time of process: check that the sensor has not failed: check that the loop is not broken. Acknowledge by pressing 'page' key and 'scroll' key together |
| Pbr | Potentiometer break | Check that the feedback potentiometer is correctly connected or the pot is not open circuit |

Table 2-2 Diagnostic alarms

Chapter 3 ACCESS LEVELS

This chapter describes the different levels of access to the operating parameters within the controller.

There are three topics:

- THE DIFFERENT ACCESS LEVELS
- SELECTING AN ACCESS LEVEL
- EDIT LEVEL

THE DIFFERENT ACCESS LEVELS

There are four access levels:

- **Operator level**, which you will normally use to operate the controller.
- **Full level**, which is used to commission the controller.
- **Edit level**, which is used to set up the parameters that you want an operator to be able to see and adjust when in Operator level.
- **Configuration level**, which is used to set up the fundamental characteristics of the controller.


| Access level | Display shows | What you can do | Password Protection |
|---------------|---------------|---|---------------------|
| Operator | <i>OPER</i> | In this level, operators can view and adjust the value of parameters defined in Edit level (see below). | No |
| Full | <i>FULL</i> | In this level, all the parameters relevant to a particular configuration are visible. All alterable parameters may be adjusted. | Yes |
| Edit | <i>EDIT</i> | In this level, you can determine which parameters an operator is able to view and adjust in Operator level. You can hide, or reveal, complete lists, individual parameters within each list and you can make parameters read-only or alterable. (See <i>Edit level</i> at the end of this chapter). | Yes |
| Configuration | <i>CONF</i> | This special level allows access to set up the fundamental characteristics of the controller. | Yes |

Figure 3-1 Access levels

SELECTING AN ACCESS LEVEL

Access to Full, Edit or Configuration levels is protected by a password to prevent unauthorised access.

If you need to change the password, see Chapter 6, *Configuration*.



Access list header

Press until you reach the access list header 'ACC5'.

Press .

Password entry

The password is entered from the 'code' display.

Enter the password using or . Once the correct password has been entered, there is a two second delay after which the lower readout will change to show 'PASS' indicating that access is now unlocked.

The pass number is set to '1' when the controller is shipped from the factory.


Note: A special case exists if the password has been set to '0'. In this case access will be permanently unlocked and the lower readout will always show 'PASS'.

Press to proceed to the 'Goto' page.

(If an *incorrect* password has been entered and the controller is still 'locked' then pressing returns you to the 'ACC5' list header.)

Access to Read-only Configuration

From this display, pressing and together will take you into Read-Only Configuration without entering a password. This will allow you to view all of the configuration parameters, but not adjust them. If no button is pressed for ten seconds, you will be returned to the Home display. Alternatively, pressing and together takes you immediately back to the Home display.



Level selection

The 'Goto' display allows you to select the required access level.

Use and to select from the following display codes:

- OPER**: Operator level
- FULL**: Full level
- Edi t**: Edit level
- CONF**: Configuration level

Press

If you selected either 'OPER', 'FULL' or 'Edi t' level you will be returned to the 'ACCESS' list header in the level that you chose. If you selected 'CONF', you will get a display showing 'CONF' in the upper readout (see below).

Configuration password

When the 'CONF' display appears, you must enter the Configuration password in order to gain access to this level. Do this by repeating the password entry procedure described in the previous section.

The configuration password is set to '2' when the controller is shipped from the factory. If you need to change the configuration password, see Chapter 6, *Configuration*.

Press

Configuration level

The first display of configuration is shown. See Chapter 6, *Configuration*, for details of the configuration parameters.

For instructions on leaving configuration level, see Chapter 6, *Configuration*.

Returning to Operator Level

To return to operator level from either 'FULL' or 'Edi t' level, repeat entry of the password and select 'OPER' on the 'Goto' display.



In 'Edi t' level, the controller will automatically return to operator level if no button is pressed for 45 seconds.

EDIT LEVEL



Edit level is used to set which parameters you can view and adjust in Operator level. It also gives access to the ‘Promote’ feature, which allows you to select and add (‘Promote’) up to twelve parameters into the Home display list, thereby giving simple access to commonly used parameters.

Setting operator access to a parameter

First you must select **Edi t** level, as shown on the previous page.

Once in **Edi t** level, you select a list, or a parameter within a list, in the same way as you would in Operator, or Full, level – that is to say, you move from list header to list header by pressing , and from parameter to parameter within each list using .


However, in Edit level what is displayed is not the value of a selected parameter, but a code representing that parameter’s availability in Operator level.

When you have selected the required parameter, use  and  buttons to set its availability in Operator level.

There are four codes:

| | |
|--------------|---|
| ALt r | Makes a parameter alterable in Operator level. |
| PrO | Promotes a parameter into the Home display list. |
| rEAd | Makes a parameter, or list header, read-only (<i>it can be viewed but not altered</i>). |
| Hi dE | Hides a parameter, or list header. |

For example:



The parameter selected is Alarm 2, Full Scale Low

It will be alterable in Operator level

Hiding or revealing a complete list

To hide a complete list of parameters, all you have to do is hide the list header. If a list header is selected, only two selections are available: **rEAd** and **Hi dE**.

(It is not possible to hide the ‘**ACCs**’ list, which always displays the code: ‘**L, St**’.)

Promoting a parameter

Scroll through the lists to the required parameter and choose the ‘**PrO**’ code. The parameter is then automatically added (promoted) into the Home display list. (The parameter will also be accessible, as normal, from the standard lists.) A maximum of twelve parameters can be promoted. Promoted parameters are automatically ‘alterable’.

Please note, in the ‘**PrOGL, St**’, the parameters from segment number (**SEGn**) onwards *cannot* be promoted.

Chapter 4 TUNING

Before tuning, please read Chapter 2, *Operation*, to learn how to select and change a parameter.

This chapter has five topics:

- WHAT IS TUNING?
- AUTOMATIC TUNING
- MANUAL TUNING
- COMMISSIONING OF MOTORISED VALVE CONTROLLERS
- GAIN SCHEDULING

WHAT IS TUNING?

In tuning, you match the characteristics of the controller to those of the process being controlled in order to obtain good control. Good control means:

- Stable, ‘straight-line’ control of the temperature at setpoint without fluctuation
- No overshoot, or undershoot, of the temperature setpoint
- Quick response to deviations from the setpoint caused by external disturbances, thereby rapidly restoring the temperature to the setpoint value.

Tuning involves calculating and setting the value of the parameters listed in Table 4-1. These parameters appear in the ‘ P, I, D ’ list.

| Parameter | Code | Meaning or Function |
|--------------------|-------|---|
| Proportional band | Pb | The bandwidth, in display units, over which the output power is proportioned between minimum and maximum. |
| Integral time | t_i | Determines the time taken by the controller to remove steady-state error signals. |
| Derivative time | t_d | Determines how strongly the controller will react to the rate-of-change of the measured value. |
| High Cutback | Hcb | The number of display units, above setpoint, at which the controller will increase the output power, in order to prevent undershoot on cool down. |
| Low cutback | Lcb | The number of display units, below setpoint, at which the controller will cutback the output power, in order to prevent overshoot on heat up. |
| Relative cool gain | rEL | Only present if cooling has been configured and a module is fitted. Sets the cooling proportional band, which equals the Pb value divided by the rEL value. |

Table 4-1 Tuning parameters

AUTOMATIC TUNING

Two automatic tuning methods are provided in the 2408 and 2404:

- **A one-shot tuner**, which automatically sets up the initial values of the parameters listed in Table 4-1 on the previous page.
- **Adaptive tuning**, which continuously monitors the error from setpoint and modifies the PID values, if necessary.

One-shot Tuning

The ‘one-shot’ tuner works by switching the output on and off to induce an oscillation in the measured value. From the amplitude and period of the oscillation, it calculates the tuning parameter values.

If the process cannot tolerate full heating or cooling being applied during tuning, then the level of heating or cooling can be restricted by setting the heating and cooling power limits in the ‘**OP**’ list. However, the measured value *must* oscillate to some degree for the tuner to be able to calculate values.

A One-shot Tune can be performed at any time, but normally it is performed only once during the initial commissioning of the process. However, if the process under control subsequently becomes unstable (because its characteristics have changed), you can re-tune again for the new conditions.


It is best to start tuning with the process at ambient temperature. This allows the tuner to calculate more accurately the low cutback and high cutback values which restrict the amount of overshoot, or undershoot.

How to tune

1. Set the setpoint to the value at which you will normally operate the process.
2. In the ‘**ALUN**’ list, select ‘**TUNE**’ and set it to ‘**ON**’.
3. Press the Page and Scroll buttons together to return to the Home display. The display will flash ‘**TUNE**’ to indicate that tuning is in progress.
4. The controller induces an oscillation in the temperature by first turning the heating on, and then off. The first cycle is not complete until the measured value has reached the required setpoint.
5. After two cycles of oscillation the tuning is completed and the tuner switches itself off.
6. The controller then calculates the tuning parameters listed in Table 4-1 and resumes normal control action.

If you want ‘Proportional only’, ‘PD’, or ‘PI’ control, you should set the ‘**L1**’ or ‘**Ld**’ parameters to **OFF** before commencing the tuning cycle. The tuner will leave them off and will not calculate a value for them.

Typical automatic tuning cycle



Calculation of the cutback values

Low cutback and *High cutback* are values that restrict the amount of overshoot, or undershoot, that occurs during large step changes in temperature (for example, under start-up conditions).

If either low cutback, or high cutback, is set to 'Auto' the values are fixed at three times the proportional band, and are not changed during automatic tuning.

Adaptive tune

Adaptive tuning is a background algorithm, which continuously monitors the error from setpoint and analyses the control response during process disturbances. If the algorithm recognises an oscillatory, or under-damped, response it recalculates the P_b , t_i and t_d values.

Adaptive tune is triggered whenever the error from setpoint exceeds a trigger level. This trigger level is set in the parameter '*drA.t*', which is found in the Autotune list. The value is in display units. It is automatically set by the controller, but can also be manually re-adjusted.

Adaptive tune should be used with:

1. Processes whose characteristics change as a result of changes in the load, or setpoint.
2. Processes that cannot tolerate the oscillation induced by a One-shot tune.

Adaptive tune should not be used:

1. Where the process is subjected to regular external disturbances that could mislead the adaptive tuner.
2. On highly interactive multiloop applications. However, moderately interactive loops, such as multi-zone extruders, should not give a problem.

MANUAL TUNING

If for any reason automatic tuning gives unsatisfactory results, you can tune the controller manually. There are a number of standard methods for manual tuning. The one described here is the Ziegler-Nichols method.

With the process at its normal running temperature:

1. Set the Integral Time ' t_i ' and the Derivative Time ' t_d ' to **OFF**.
2. Set High Cutback and Low Cutback, ' Hcb ' and ' Lcb ', to **Auto**.
3. Ignore the fact that the temperature may not settle precisely at the setpoint.
4. If the temperature is stable, reduce the proportional band ' Pb ' so that the temperature just starts to oscillate. If the temperature is already oscillating, increase the proportional band until it just stops oscillating. Allow enough time between each adjustment for the loop to stabilise. Make a note of the proportional band value ' B ' and the period of oscillation ' T '.
5. Set the Pb , t_i , t_d parameter values according to the calculations given in Table 4-2.

| Type of control | Proportional band ' Pb ' | Integral time ' t_i ' | Derivative time ' t_d ' |
|-------------------|----------------------------|-------------------------|---------------------------|
| Proportional only | $2xB$ | OFF | OFF |
| P + I control | $2.2xB$ | $0.8xT$ | OFF |
| P + I + D control | $1.7xB$ | $0.5xT$ | $0.12xT$ |

Table 4-2 Tuning values

Setting the cutback values


The above procedure sets up the parameters for optimum steady state control. If unacceptable levels of overshoot or undershoot occur during start-up, or for large step changes in temperature, then manually set the cutback parameters 'Lcb' and 'Hcb'.

Proceed as follows:


1. Set the low and high cutback values to three proportional bandwidths (that is to say, $Lcb = Hcb = 3 \times Pb$).
2. Note the level of overshoot, or undershoot, that occurs for large temperature changes (see the diagrams below).

In example (a) increase 'Lcb' by the overshoot value. In example (b) reduce 'Lcb' by the undershoot value.

Example (a)



Example (b)



Where the temperature approaches setpoint from above, you can set 'Hcb' in a similar manner.

Integral action and manual reset

In a full three-term controller (that is, a PID controller), the integral term 'ti' automatically removes steady state errors from the setpoint. If the controller is set up to work in two-term mode (that is, PD mode), the integral term will be set to 'OFF'. Under these conditions the measured value may not settle precisely at setpoint. When the integral term is set to 'OFF' the parameter *manual reset* (code 'rES') appears in the 'P, DL, SE' in 'FULL' level. This parameter represents the value of the power output that will be delivered when the error is zero. You must set this value manually in order to remove the steady state error.

Automatic droop compensation (Adc)

The steady state error from the setpoint, which occurs when the integral term is set to 'OFF', is sometimes referred to as 'droop'. 'Adc' automatically calculates the manual reset value in order to remove this droop. To use this facility, you must first allow the temperature to stabilise. Then, in the autotune parameter list, you must set 'Adc' to 'CALC'. The controller will then calculate a new value for manual reset, and switch 'Adc' to 'MAN'.

'Adc' can be repeated as often as you require, but between each adjustment you must allow time for the temperature to stabilise.

Tune Error

If any one stage of the automatic tuning process is not completed within two hours a diagnostic alarm will occur. The display shows **TUEr** - Tune Error. This alarm could occur if:

1. The process to be tuned has a very slow response time
2. The sensor has failed or is incorrectly aligned
3. The loop is broken or not responding correctly

MOTORISED VALVE CONTROL

The 2408 and 2404 can be configured for motorised valve control as an alternative to the standard PID control algorithm. This algorithm is designed specifically for positioning motorised valves.

These are ordered pre-configured as Model numbers:

- 2408/VC and 2404/VC motorised valve controllers
- 2408/VP and 2404/VP motorised valve controllers with a single setpoint programmer
- 2408/V4 and 2404/V4 motorised valve controllers storing four setpoint programs.
- 2408/VM and 2404/VM motorised valve controllers storing twenty setpoint programs.

Figure 1-11 in Chapter 1 shows how to connect a motorised valve controller. The control is performed by delivering open, or close, pulses in response to the control demand signal.

The motorised valve algorithm can operate in one of three ways:

1. The so-called *boundless* mode, which does not require a position feedback potentiometer for control purposes; although one can be connected and used purely to display the valve's position.
2. Bounded, (or *position*), control mode, which requires a feedback potentiometer. This is closed-loop control determined by the valve's position.

The desired control mode is selected in the 'rNSt' list in configuration level.

The following parameter list will appear in the navigation diagram shown in Chapter 2, if your controller is configured for motorised valve control.

| Name | Description | Values | | |
|----------------------------|---|------------------|------------|------------------|
| mTr | Motor list | Min | Max | Default |
| t _m | Valve travel time in seconds. This is the time taken for the valve to travel from its fully closed position to its fully open position. | 0.1 | 240.0 | 30.0 |
| I _{nt} | Valve inertia time in seconds. This is the time taken for the valve to stop moving after the output pulse is switched off. | OFF | 20.0 | OFF |
| b _{act} | Valve backlash time in seconds. This is the minimum on-time required to reverse the direction of the valve. i.e. the time to overcome the mechanical backlash. | OFF | 20.0 | OFF |
| m _{P_t} | Output pulse minimum on-time, in seconds. | A _{uto} | 100.0 | A _{uto} |
| U _{br} | Valve sensor break strategy. | rEST, uP, dwn | | rEST |

Table 4-3 Motorised valve parameter list

COMMISSIONING THE MOTORISED VALVE CONTROLLER

The commissioning procedure is the same for both bounded and boundless control modes, except in bounded mode you must first calibrate the position feedback potentiometer, as described in the section below.

Proceed as follows:

1. Measure the time taken for the valve to be raised from its fully closed to its fully open position and enter this as the value in seconds into the ' t_m ' parameter.
2. Set all the other parameters to the default values shown in Table 4-3.

The controller can then be tuned using any of the automatic, or manual, tuning procedures described earlier in this chapter. As before, the tuning process, either automatic or manual, involves setting the values of the parameters in Table 4-1. The only difference with boundless control is that the derivative term ' t_d ', although present, will have no effect.

Adjusting the minimum on-time ' mP_t '

The default value of 0.2 seconds is satisfactory for most processes. If, however, after tuning the process, the valve activity is excessively high, with constant oscillation between raise and lower pulses, the minimum on-time can be increased.

The minimum on-time determines how accurately the valve can be positioned and therefore the control accuracy. The shorter the time, the more precise the control. However, if the time is set too short, process noise will cause an excessively busy valve.

Inertia and backlash settings

The default values are satisfactory for most processes, i.e. ' OFF '.




Inertia is the time taken for the valve to stop after the output pulse is turned off. If this causes a control problem, the inertia time needs to be determined and then entered into the parameter, ' t_{nL} '. The inertia time is subtracted from the raise and lower output pulse times, so that the valve moves the correct distance for each pulse.
























Backlash is the output pulse time required to reverse the direction of the valve, i.e. the time taken to overcome the mechanical backlash of the linkages. If the backlash is sufficient to cause a control problem, then the backlash time needs to be determined and then entered into the parameter, ' $BACK_t$ '.

The above two values are not part of the automatic tuning procedure and must be entered manually.

CALIBRATING THE POSITION FEEDBACK POTENTIOMETER

Before proceeding with the feedback potentiometer calibration, you should ensure, in configuration level, that module position 2 ($2A$), or 3 ($3A$), has its ' d ' indicating ' Pot_t ', (meaning *Potentiometer Input*). Continue to scroll down the module configuration list. ' $Func$ ' should be set to ' $UPoS$ ', ' URL_L ' must be set to ' 0 ' and ' URL_H ' to ' 100 '. Exit from configuration and you are now ready to calibrate the position feedback potentiometer. Proceed as follows.

1. In Operator level, press the AUTO/MAN button to put the controller in Manual mode.
2. Drive the valve to its fully open position using .
3. Press  until you get to ' $P-L, 5t$ '.
4. Press  to get to ' $PCAL-OFF$ '.


5. Press  or  to turn 'PCAL' to 'on'.
6. Press  and the upper readout indicates 'Pot'.
7. Press  or  to get to 'Pot-3A.H'. (*Assuming that the Potentiometer Input Module is in module position 3.*)
8. Press  to go to 'GO-no'.
9. Press  or  to see 'GO-YES', which starts the calibration procedure.
10. Calibration is complete when the display returns to 'GO-no'.
11. Press  and  together to return directly to the Operator level.
12. The controller should still be in Manual mode.
13. Drive the valve to its fully closed position using .
14. Press  until you get to 'P-L, St'.
15. Press  to get to 'PCAL-OFF'.
16. Press  or  to turn 'PCAL' to 'on'.
17. Press  and the upper readout indicates 'Pot'.
18. Press  or  to get to 'Pot-3A.LO'.
19. Press  to go to 'GO-no'.
20. Press  or  to see 'GO-YES', which starts the calibration procedure.
21. Calibration is complete when the display returns to 'GO-no'.
22. Press  and  together to return directly to the Operator level.
23. Press the AUTO/MAN button to place the controller in AUTO and the calibration of the position feedback potentiometer is now complete.

GAIN SCHEDULING

Gain scheduling is the automatic transfer of control between one set of PID values and another. In the case of the 2408 and 2404 controllers, this is done at a presettable process value. It is used for the more difficult to control processes which exhibit large changes in their response time or sensitivity at, for example, high and low temperatures, or when heating or cooling.


The 2408 and 2404 has two sets of PID values. You can select the active set from either a digital input, or from a parameter in the PID list, or you can transfer automatically in gain scheduling mode. The transfer is bumpless and will not disturb the process being controlled.

To use gain scheduling, follow the steps below:



Step 1: Enable in configuration level

Gain scheduling must first be enabled in Configuration level. Goto the *Inst Conf* list, select the parameter *GSch*, and set it to *YES*.



Step 2: Set the transfer point

Once gain scheduling has been enabled, the parameter *G.SP* will appear at the top of the *PID* list in *FULL* access level. This sets the value at which transfer occurs. *PID1* will be active when the process value is below this setting and *PID2* when the process value is above it. The best point of transfer depends on the characteristics of the process. Set a value between the control regions that exhibit the greatest change.

Step 3: Tuning

You must now set up the two sets of PID values. The values can be manually set, or automatically tuned as described earlier in this chapter. When tuning automatically you must tune twice, once above the switching point *G.SP* and again below the switching point. When tuning, if the process value is below the transfer point *G.SP* the calculated values will automatically be inserted into *PID1* set and if the process value is above *G.SP*, the calculated values will automatically be inserted into *PID2* set.

Chapter 5 PROGRAMMER OPERATION

This chapter deals with the setpoint programming option. All 2408 / 2404 instruments have a basic 8-segment programmer built-in as standard. This facility must be enabled by the user, as explained in the section, *Configuring the Programmer*.

Other programmer versions are listed below, and have 16-segments in each program.

16-segment programmer with:

| | |
|-------------------------|-----------------------------|
| a single program: | Models 2408/CP and 2404/CP. |
| four stored programs: | Models 2408/P4 and 2404/P4. |
| twenty stored programs: | Models 2408/CM and 2404/CM. |

16-segment Motorised Valve programmer with:

| | |
|-------------------------|-----------------------------|
| a single program: | Models 2408/VP and 2404/VP. |
| four stored programs: | Models 2408/V4 and 2404/V4. |
| twenty stored programs: | Models 2408/VM and 2404/VM. |

The 8-segment programmer differs from the other programmers in that it will not provide event outputs and program synchronisation. Otherwise they all operate in the same way.

There are eight topics:

- WHAT IS SETPOINT PROGRAMMING?
- PROGRAMMER STATES
- RUNNING A PROGRAM FROM THE RUN LIST
- RUNNING A PROGRAM USING THE RUN/HOLD BUTTON
- AUTOMATIC BEHAVIOUR
- CONFIGURING THE PROGRAMMER
- CONFIGURING DIGITAL INPUTS TO SELECT PROGRAM NUMBER
- CREATING A NEW PROGRAM, OR MODIFYING AN EXISTING PROGRAM.

To understand how to select and change parameters in this chapter you need to have read Chapter 2, *Operation* and Chapter 3, *Access Levels*.

WHAT IS SETPOINT PROGRAMMING?

Many applications need to vary temperature, or process value, with time. Such applications need a controller which varies a setpoint as a function of time; all 2408 and 2404 models can do this.

The setpoint is varied by using a *setpoint program*. Within each 2408 and 2404 controller, there is a software module called *the programmer*, which stores one, or more, such programs and drives the setpoint according to the selected program. The program is stored as a series of 'ramp' and 'dwell' segments, as shown below.




Fig 5-1 Setpoint profile

*(If the 8-segment programmer is being used, then the information in the next paragraph does **not** apply.)*
 In each segment you can define the state of up to eight (8) digital outputs, each of which can be used to trigger external events. These are called *event outputs* and can drive either relay, logic, or triac outputs, depending on the modules installed.

A program is executed either, once, repeated a set number of times, or repeated continuously. If repeated a set number of times, then the number of cycles must be specified as part of the program.

There are five different types of segment:






| | | |
|---------------------|---|--|
| <p>Ramp</p> |  | <p>The setpoint ramps linearly, from its current value to a new value, either at a set rate (called <i>ramp-rate programming</i>), or in a set time (called <i>time-to-target programming</i>). You must specify the ramp rate or the ramp time, and the target setpoint, when creating or modifying a program.</p> |
| <p>Dwell</p> |  | <p>The setpoint remains constant for a specified period.</p> |
| <p>Step</p> |  | <p>The setpoint steps instantaneously from its current value to a new value.</p> |
| <p>Call</p> |  | <p>The main program calls another program as a subroutine. The called program then drives the setpoint until it returns control to the main program. This facility is available on those controllers with 4, or 20, stored programs.</p> |
| <p>End</p> |  | <p>The program either ends in this segment, or repeats. You specify which is the case when you create, or modify, the program (see the final topic in this chapter). When the program ends, the programmer is put into either, a continuous Dwell state with all outputs staying unchanged, or the Reset state, or to a settable power level.</p> |

Table 5-1 Segment Types


PROGRAMMER STATES

The programs have five states: *Reset*, *Run*, *Hold*, *Holdback* and *End*.

| State | Description | Indication |
|-----------------|---|---|
| Reset | In Reset, the programmer is inactive and the controller behaves as a standard controller, with the setpoint determined by the value set in the lower readout. | Both the RUN and HOLD lights are OFF |
| Run | In Run, the programmer varies the setpoint according to the active program. | RUN light on |
| Hold | In Hold, the program is frozen at its current point. In this state you can make temporary changes to any program parameter (for example, a target setpoint, a dwell time, or the time remaining in the current segment). Such changes will only remain effective until the program is reset and run again, when they will be overwritten by the stored program values. Note: When a program is running, you <u>cannot</u> alter a cALLED program until it becomes active within that program. | HOLD light on |
| Holdback | Holdback indicates that the measured value is lagging the setpoint by more than a preset amount and that the program is in Hold, waiting for the process to catch up. See <i>Holdback</i> in the section on Automatic behaviour later this chapter. | HOLD light flashes |
| | A master controller can re-transmit a setpoint value to a number of slave units using PDSIO setpoint retransmission. Any of the slave units can generate a holdback signal which will also flash the HOLD light. Holdback will also occur if the PDSIO output is open circuit. This can be disabled in configuration by selecting the <i>PdS</i> output as <i>SP.nH</i> - 'setpoint retransmission without holdback' | HOLD light flashes |
| End | The program is complete. | RUN light flashes |

Table 5-2 Program States

RUNNING A PROGRAM FROM THE RUN LIST




The Run List

From the Home display, press until you reach the 'run' list header.



Press




Program number

This display only appears on programmers that can store more than one program. Use or to select the required program number, from 1 to 4, or 1 to 20, depending on the particular controller.

Alternatively, the program number can be selected remotely, using digital inputs on the rear terminals. See the section on *Configuring Digital Inputs to Select a Program Number* for information on how this is done.



Press



Status selection

Use or to select:

- **run:** Run program.
- **hold:** Hold program.
- **OFF:** Program reset.

After two seconds, the lower readout blinks and the chosen state is now active.

To return to the Home display press and together.

Other parameters

To access the other parameters in the 'run' list, continue to press . These parameters are shown in the 'Program run list' in Chapter 2, Parameter Tables. They show the current status of the active program.


Temporary changes

Temporary changes can be made to the parameters in this 'run' list, (for example a setpoint, ramp rate, or an unelapsed time), by first placing the programmer into 'hold'. Such changes remain active only for the duration of the segment; the segment parameters will revert to their original (stored) values whenever the segment is re-executed.

RUNNING A PROGRAM USING THE RUN/HOLD BUTTON

If you are using a 4, or 20, program version of the controller, you must first select the number of the program that you want to run. Do this in the ‘**run**’ list – see the previous topic, *Running a program from the Run list*.

Then:

| | | |
|---|------------------------------|---|
|  | <p>RUN / HOLD button</p> | <p>Press once to run a program (RUN light on) Press again to hold a program (HOLD light on) Press again to cancel hold and continue running (HOLD light off, RUN light on) Press and hold in for two seconds to reset a program (RUN and HOLD lights off).</p> |
|---|------------------------------|---|

Note: The RUN/HOLD button can be disabled, either when ordering the controller, or subsequently in configuration. This will force you to operate the programmer from the ‘**run**’ list all the time. The main advantage of this method is that it will reduce the chance of accidentally changing the state of a program.

AUTOMATIC BEHAVIOUR

The preceding topics explain how to operate the programmer manually.

The following topics cover aspects of its automatic behaviour: *Servo*, *Holdback* and *Power Failure*.

Servo

When a program is RUN, the setpoint can start either from the initial controller setpoint, or from the process value. Whichever it is, the starting point is called the ‘servo’ point and you set it up in configuration. When the program starts, the transition of the setpoint to its starting point is called ‘servoing’.

The normal method is to servo to the process value, because this will produce a smooth and bumpless start to the process. However, if you want to guarantee the time period of the first segment, you should set the controller to servo to its setpoint.

Holdback

As the setpoint ramps up, or down (or dwells), the measured value may lag behind, or deviate from, the setpoint by an undesirable amount. ‘Holdback’ is available to freeze the program at its current state, should this occur. The action of Holdback is the same as a deviation alarm. It can be enabled, or disabled. Holdback has **two** parameters - a *value* and a *type*.

If the error from the setpoint exceeds the set ‘holdback’ value, then the Holdback feature, if enabled, will automatically freeze the program at its current point and flash the HOLD light. When the error comes within the holdback value, the program will resume normal running.

There are *four* different Holdback types. The choice of type is made by setting a parameter when creating a program, and may be one of the following:–

‘**OFF**’ – **Disables Holdback** – therefore no action is taken.

- 'Lo' – **Deviation Low Holdback** holds the program back when the process variable deviates *below* the setpoint by more than the holdback value.
- 'Hi' – **Deviation High Holdback** holds the program back when the process variable deviates *above* the setpoint by more than the holdback value.
- 'Band' – **Deviation Band Holdback** is a combination of the two. It holds the program back when the process variable deviates *either above, or below*, the setpoint by more than the holdback value.

There is a single Holdback Value which applies to the whole program. However, the Holdback type and whether or not it is enabled, can be applied to the program as a whole, or individually in each segment.

Power failure

If power is lost and then restored, while a program is running, the behaviour of the programmer is determined by the setting of the parameter 'PwrF' *Power fail strategy* in Programmer configuration. This can have one of three settings:– *cont* (Continue), *rmPb* (Ramp from PV), or *rSEt* (Reset).

If 'cont' is selected, then when power is restored the program continues from where it was interrupted when power was lost. All parameters, such as the setpoint and time remaining in the active segment, will be restored to their power-down values. For applications that need to bring the measured process value to the setpoint as soon as possible, this is the best strategy.

If 'rmPb' is selected, then when power is restored the setpoint starts at ('servos to') the current measured value, and then ramps to the target setpoint of the active segment at the last ramp rate used by the program. This strategy provides a smoother recovery. The two diagrams below illustrate the respective responses, Fig 5-2 if power fails during a dwell segment and Fig 5-3 if it fails during a ramp segment.




Figure 5-2 Continue after a power fail




Figure 5-3 Ramp back after a power fail

If 'rSEt' is selected, then when power is restored the program terminates.




CONFIGURING THE PROGRAMMER

When first installing a programmer you should check that the configuration conforms to your requirement.


Configuration defines:

- the number of stored programs *(multi-programmer only)*
- the holdback strategy
- the power fail strategy
- the servo type
- if event outputs are available *(not 8-segment programmer)*
- if program synchronisation is available. *(not 8-segment programmer)*
- selection of program number using digital inputs *(multi-programmer only)*

To check, or change, the configuration, select Configuration level. See Chapter 6.



Programmer list header

After selecting Configuration mode, press  until the **PR OG** **CONF** header is displayed.

Press 

Number of programs

Use  or  to select:

- **nonE**: Disable built-in 8-segment programmer
- **!**: Enable built-in 8-segment programmer

For 16-segment programmers:

- **nonE**: no programs
- **!**: One stored program
- **4**: Four stored programs
- **20**: Twenty stored programs

Press 


Holdback Strategy

Use  or  to select:

- **SEG**: Holdback type to be set in each segment
- **PROG**: Holdback type to be set for the whole program

Press 

Continued on the next page.



Power fail strategy

Use or to select

- **cont:** Continue from last setpoint
- **rmPb:** Ramp from PV to setpoint at last ramp rate
- **rSEt:** Reset the program.

Press

Servo type

Use or to select:

- **to.PU:** Servo to PV
- **to.SP:** Servo to SP

Press

Event Outputs *(not in 8-segment programmer)*

Use or to select:

- **no:** Event outputs disabled
- **YES:** Event outputs enabled

Press

Synchronisation *(not in 8-segment programmer)*

Use or to select:

- **no:** Synchronisation disabled
- **YES:** Synchronisation enabled

Press to return the list header.


CONFIGURING DIGITAL INPUTS TO SELECT PROGRAM NUMBER


The program number can be selected by external BCD inputs from, for example, a thumbwheel switch.



The appropriate number of digital inputs must be installed in the controller and be configured for this function - see Chapter 6, *Configuration*.

To invoke this mode of operation, the parameter '*bcd*' in '*nSt-Conf*' must be set to '*PrOG*'.







Press  until you reach '*bcd*'.



Use the  or  buttons, to select '*PrOG*'.

CREATING A NEW PROGRAM, OR MODIFYING AN EXISTING ONE

The only difference between creating a new program, and modifying an existing one, is that a new program starts with all its segments set to *End* in the *TYPE* parameter. The procedure for both consists of setting up the parameters in the *PRoG* list of the Operator Navigation Diagram shown in Chapter 2. As explained earlier under ‘Programmer states’, temporary changes can be made to these parameters while in the *HOLD* state but permanent changes (to the stored values) can only be made when the programmer is in the *Reset* state. So, before modifying a stored program first make sure that it is in *Reset* and then follow the procedure below.



Program edit list

From the Home display press until you reach the *PRoG* *L, St* header.

Press

Program number

This display appears only on the multi-program controllers. Use or to select the number of the program which you wish to modify (from 1 to 4, or 1 to 20).

Press

Holdback type

[Only appears when Holdback has been selected for the whole program.]

Use or to select:

- *OFF*: Holdback disabled
- *Lo*: Deviation Low Holdback
- *Hi*: Deviation High Holdback
- *bAnd*: Deviation Band Holdback

Press




Holdback value

Note! The value set in this parameter is always for the whole program.

Use or to set the value.

Press

Continued on the next page.



Ramp units

Use or to select:

- SEc
- mi n
- Hour

Press

Dwell units

Use or to select:

- SEc
- mi n
- Hour

Press

Number of program cycles

Use or to set the number of program cycles required from 1 to 999, or 'cont' for continuous cycling.

Press

Segment number


Use or to select the number, from 1 to 16.

(1 to 8 in 8-segment programmers)

The parameters that follow 'SEG.n' set up the characteristics of the individually-selected segment number. By defining the characteristics of each segment of the program, you define the whole program.

Press

Continued on the next page.



Segment type

Select the segment type using or .

- *rmpR*: Ramp to a new setpoint at a set rate
- *rmpL*: Ramp to a new setpoint in a set time
- *dwEl*: Dwell for a set time
- *StEP*: Step to a new setpoint
- *cALL*: Call another program as a subroutine
(only available in multi-program controllers)
- *End*: Make this segment the end of the program.



Press

The parameters that follow 'TYPE' depend on the type of segment selected as shown in the table below. The function of each parameters follows the table.

| Parameter | Segment type selected | | | | | |
|-------------|-----------------------|-------------|-------------|-------------|-------------|------------|
| | <i>rmpR</i> | <i>rmpL</i> | <i>dwEl</i> | <i>StEP</i> | <i>cALL</i> | <i>End</i> |
| <i>Hb</i> | J | J | J | J | | |
| <i>tGt</i> | J | J | | J | | |
| <i>rAtE</i> | J | | | | | |
| <i>dur</i> | | J | J | | | |
| <i>PrGn</i> | | | | | J | |
| <i>cYcn</i> | | | | | J | |
| <i>outn</i> | J | J | J | J | | J |
| <i>SYnc</i> | J | J | J | J | | |
| <i>Endt</i> | | | | | | J |

Table 5-3 Parameters that follow segment type




Holdback type

Only appears when Holdback per segment has been selected.

Use or to select:

- *OFF*: Holdback disabled
- *Lo*: Deviation Low Holdback
- *Hi*: Deviation High Holdback
- *bAnd*: Deviation Band Holdback

Press







Target setpoint

Target setpoint for '*rmpR*', '*rmpL*' or '*StEP*' segments.

Set the target setpoint using or .

Press

Continued on the next page.



Ramp rate

Ramp rate for 'rMP_r' segments

Using or , set a value for the ramp rate, ranging from 0.0 to 999.9. The units are the ramp units (rMP_U) set earlier in this sequence.

Press

Duration time

Time for a 'dwEIt' segment, or time to target for a 'rMP_t' segment.

Set the time using or . You have set the units earlier in this sequence. ['dwL_U' defines the units for 'dwEIt' segments: 'rMP_U' defines the units for 'rMP_t' segments.]

Press

Called program number

Only appears for 'cALL' segments. *(multi-program controllers only)*

Set a called program number from 1 to 4, or from 1 to 20, using or .

Press


Number of cycles of the cALLED program

Only appears for 'cALL' segments. *(multi-program controllers only)*

Sets the number of cycles of the cALLED program from 1 to 999, using or .

Press

Continued on the next page.



Event output 1

(16-segment programmers only)

Appears in all segments, except 'CALL' segments.

Use or to set output 1:

- **OFF:** Off in the current segment
- **on:** On the current segment.

Press

Further event outputs

(16-segment programmers only)

Up to eight (8) event outputs may appear in this list where 'n' = event number.

Pressing will step through all the remaining event outputs.

Note: If you are not using all of the event outputs, you can step immediately to the next segment number by pressing .

Press

Synchronisation event output *(only appears if configured)*

Use or to select:

- **YES:** Synchronisation Enabled
- **no:** Synchronisation Disabled

Note: This event output, if used, occupies the position of 'outB'.



Press

End segment



Use or to select:

- **dwell:** An indefinite dwell
- **rSEt:** Reset.
- **S OP:** End Segment Output Power Level


Press



Power Value [End Segment]

Use  or  to set the power value in the range $\pm 100.0\%$. This power level is clipped by the parameters 'OP.Hi' and 'OP.Lo' before being applied to the process.

Note: In programmer/controller software versions 3.56 onwards this parameter has been replaced by a parameter **EndP** which appears at the end of the Output List, see Chapter 2

Press  to return to the PrOG-L,St header.

Chapter 6 CONFIGURATION

This chapter consists of six topics:

- SELECTING CONFIGURATION LEVEL
- LEAVING CONFIGURATION LEVEL
- SELECTING A CONFIGURATION PARAMETER
- CHANGING THE PASSWORDS
- NAVIGATION DIAGRAM
- CONFIGURATION PARAMETER TABLES.

In configuration level you set up the fundamental characteristics of the controller. These are:



- The type of control (e.g. reverse or direct acting)
- The Input type and range
- The Setpoint configuration
- The Alarms configuration
- The Programmer configuration
- The Digital input configuration
- The Alarm Relay configuration
- The Communications configuration
- The Modules 1, 2 & 3 configuration
- Calibration
- The Passwords.


WARNING

Configuration is protected by a password and should only be carried out by a qualified person, authorised to do so. Incorrect configuration could result in damage to the process being controlled and/or personal injury. It is the responsibility of the person commissioning the process to ensure that the configuration is correct.

SELECTING CONFIGURATION LEVEL



There are two alternative methods of selecting Configuration level:

- If you have already powered up, then follow the access instructions given in Chapter 3, *Access levels*.
- Alternatively, press  and  together when powering up the controller. This will take you directly to the 'CONF' password display.



Password entry



When the 'CONF' display appears, you must enter the Configuration password (which is a number) in order to gain access to Configuration level.

Enter the password using the  or  buttons. The configuration password is set to '2' when the controller is shipped from the factory.

Once the correct password has been entered, there is a two second delay, after which the lower readout will change to 'PASS', indicating that access is now unlocked.


Note: A special case exists if the password has been set to '0'. In this situation, access is permanently unlocked and the lower readout will always show 'PASS'.



Press  to enter configuration.


(If an incorrect password has been entered and the controller is still 'locked' then pressing  at this point will take you to the 'Err' display with 'no' in the lower readout. Simply press  to return to the 'CONF' display.)



You will obtain the first display of configuration.

LEAVING CONFIGURATION LEVEL

To leave the Configuration level and return to Operator level Press  until the 'E1, t' display appears.

Alternatively, pressing  and  together will take you directly to the 'E1, t' display.





Use  or  to select 'YES'. After a two-second delay, the display will blank and revert to the Home display in Operator level.

SELECTING A CONFIGURATION PARAMETER



The configuration parameters are arranged in lists as shown in the navigation diagram in Figure 6.1.

To step through the list headers, press the Page  button.

To step through the parameters within a particular list press the Scroll  button. When you reach the end of the list you will return to the list header.

You can return directly to the list header at any time by pressing the Page  button.

Parameter names

Each box in the navigation diagram shows the display for a particular parameter. The upper readout shows the name of the parameter and the lower readout its value. For a definition of each parameter, see the Configuration Parameter Tables at the end of this chapter. To change the value of a selected parameter, use the  and  buttons.

The navigation diagram shows all the lists headers and parameters that can, potentially, be present in the controller. In practice, those actually present will vary according to the particular configuration choices you make.

CHANGING THE PASSWORDS

There are TWO passwords. These are stored in the Password configuration list and can be selected and changed in the same manner as any other configuration parameter.

The password names are:

- 'A C C P' which protects access to Full level and Edit level
- 'C N F P' which protects access to Configuration level.

NAVIGATION DIAGRAM (PART A)





Fig 6.1a Navigation Diagram (Part A)

NAVIGATION DIAGRAM (PART B)

Alarm relay Comms 1 Comms 2 Module 1 Module 2 Module 3 Module 4⁽²⁾ Custom⁽³⁾
 Config Config Config Config⁽¹⁾ Config⁽¹⁾ Config⁽¹⁾ Config Config Config



Note:

1. Additional headers, carrying the suffixes **b** and **L**, will appear if dual-, or triple-, channel modules have been installed. The header denotes the labelling of the terminal to which the output function is connected.
2. Module 4 is the High Current Switch Module. This is only available in the Model 2404 controller on controllers manufactured before Jan-04.
3. 8-point custom linearisation. Only appears when either **3A** or **P-Conf** has 'nPt' = 'mUL', or 'mAL', or 'UL'.
4. The navigation diagram shows typical parameters, but is dependant upon the exact configuration of the instrument. The following sheets show the full list of parameters.

Fig 6.1b Navigation Diagram (Part B)

NAVIGATION DIAGRAM (PART C)




Fig 6.1c Navigation Diagram (Part C)

CONFIGURATION PARAMETER TABLES

| Name | Description | Values | Meaning |
|-------------|--|---------------------------------------|---|
| Inst | Instrument configuration | | |
| Ctrl | Control type | PID On/Off UP UP b | PID control On/off control Boundless motorised valve control - <i>no feedback required</i> Bounded motorised valve control - <i>feedback required</i> |
| Act | Control action | Reverse Direct | Reverse acting Direct acting |
| Cool | Type of cooling | Linear Oil H2O Fan On/Off | Linear Oil (50mS minimum on-time) Water (non-linear) Fan (0.5S minimum on-time) On/off cooling |
| Intd | Integral & derivative time units | Sec min | Seconds, OFF to 9999 Minutes, OFF to 999.9 |
| dtYP | Derivative type | PU Err | Operates on rate of change of PV Operates on rate of change of error |
| m-A | Front panel Auto/Man button | EnAb di SA | Enabled Disabled |
| r-h | Front panel Run/Hold button | EnAb di SA | Enabled Disabled |
| PwrF | Power feedback | on OFF | On Off |
| Fwdt | Feed forward type | nonE FEEd SPFF PUFF | None Normal feed forward Setpoint feed forward PV feed forward |
| PdEr | Manual/Auto transfer when using PD control | no YES | Non-bumpless transfer Bumpless transfer - (<i>Pre-loads Manual Reset value</i>) |
| Sbrt | Sensor break output | SbOP HoLd | Go to pre-set value Freeze output |
| FOP | Forced manual output | no trAc STEP | Bumpless Auto/Manual transfer Returns to the Manual value that was set when last in Manual mode Steps to forced output level. Value set in 'FOP' of 'oP-L, St' in Operator Level |
| bcd | BCD input function | nonE PROG SP | Not used Select program number Select setpoint number |
| Gsch | Gain schedule enable | no YES | Disabled Enabled |

| Name | Description | Values | Meaning |
|---------------|---------------------------------------|---|--|
| PU | Process value config | | |
| <i>unit</i> | Instrument units | <i>C</i> <i>F</i> <i>K</i> <i>none</i> | Celsius Fahrenheit Kelvin Display units blanked |
| <i>decP</i> | Decimal places in the displayed value | <i>none</i> <i>one</i> <i>two</i> | None One Two |
| <i>rangeL</i> | Range low | | Low range limit. Also setpoint limit for alarms and programmers |
| <i>rangeH</i> | Range high | | High range limit. Also setpoint limit for alarms and programmers |

Notes:**1. Pyrometer Emmisivity**

Controllers which are specifically supplied for pyrometer inputs (not Exergen K80), have the curve downloaded in the Custom Input. The parameter, *Emi 5*, Pyrometer Emmisivity, appears in the Input List on page 2-15. This parameter is also now correctly adjusted.

2. Range

If a decimal point was configured, negative display and setpoint ranges were limited to -99.9 in previous software versions. The range has been increased to -199.9 by combining the negative sign with the figure one. This allows Setpoints, Process Variables, Alarm Setpoints and Programmers to be set to -199.9.

| Name | Description | Values | Meaning |
|-------------|-------------------------------|---------------------------|--|
| SP | Setpoint configuration | | |
| <i>nSP</i> | Number of setpoints | 2, 4, 16 | Select number of setpoints available |
| <i>rmTr</i> | Remote Tracking | OFF ErAc | Disable Local setpoint tracks remote setpoint |
| <i>mTr</i> | Manual Track | OFF ErAc | Disable Local setpoint tracks PV when in manual |
| <i>PrTr</i> | Programmer Track | OFF ErAc | Disable Local setpoint tracks programmer SP |
| <i>rmPU</i> | Setpoint rate limit units | PSEc Pm, n PHr | Per second Per minute Per hour |
| <i>rmE</i> | Remote setpoint configuration | nonE SP LocE rmE | Disable Remote setpoint Remote setpoint + local trim Remote trim + local setpoint |

| AL | Alarm configuration | Values |
|---|---|---------------------------|
| <p>The controller contains four 'soft' alarms, which are configured in this list. Once configured, they can be attached to a physical output as described in the alarm relay configuration list, 'RR ConF'.</p> | | |
| AL1 | Alarm 1 Type | see Table A |
| Ltch | Latching | no/YES/Eunt/mAn* |
| bLoc | Blocking | no/YES |
| AL2 | Alarm 2 Type | see Table A |
| Ltch | Latching | no/YES/Eunt/mAn* |
| bLoc | Blocking | no/YES |
| AL3 | Alarm 3 Type | see Table A |
| Ltch | Latching | no/YES/Eunt/mAn* |
| bLoc | Blocking | no/YES |
| AL4 | Alarm 4 Type | see Table A |
| Ltch | Latching | no/YES/Eunt/mAn* |
| bLoc | Blocking (not if 'AL4' = 'rAL') | no/YES |
| Sbrt | Sensor break trip alarm latching type. Disable = process alarms inhibited when in sensor break Enable = process alarms shown when in sensor break | En Enable di S Disable |

| Table A - Alarm types | |
|-----------------------|----------------------------|
| Value | Alarm type |
| OFF | No alarm |
| FSL | PV Full scale low |
| FSH | PV Full scale high |
| dEu | PV Deviation band |
| dHi | PV Deviation high |
| dLo | PV Deviation low |
| LCr | Load Current low |
| HCr | Load Current high |
| FL2 | Input 2 Full Scale low |
| FH2 | Input 2 Full Scale high |
| LDP | Working Output low |
| HDP | Working Output high |
| LSP | Working Setpoint low |
| HSP | Working Setpoint high |
| rAL | PV Rate of change AL4 only |
| CTOP | CT open circuit |
| CTSh | CT short circuit |

*** Alarm Modes**

'no' means that the alarm will be non-latching.

'YES' means that the alarm will be latched, with automatic resetting. Automatic resetting means that if a reset is actioned before the alarm has cleared, then it will automatically reset when it clears.

'Eunt' means that the alarm is used to trip an external event. If this option is selected the front panel alarm message will not appear.

'mAn' means that the alarm will be latched, and can only be reset after it has first cleared (called 'manual reset mode').

The following parameters apply if the standard 8-segment programmer is to be configured.

| PFOG | Programmer configuration | Values | Meaning |
|-------------|--|-----------------------|---|
| PEYP | Programmer type | nonE 1 | Programmer disabled (<i>factory setting</i>) 8-segment programmer enabled |
| HbAc | Holdback | SEG Prog | Holdback is individually selectable in each segment. Holdback is applied across the whole Program. |
| PwrF | Power fail recovery | cont rampb rSet | Continue from last setpoint (SP) Ramp from PV to SP at last ramp rate Reset the program |
| SrvO | Starting setpoint of a program (Servo point) | toPV toSP | From the Process Value (PV) From the setpoint |

The following parameters apply if a 16-segment programmer is to be configured.

| PFOG | Programmer configuration | Values | Meaning |
|-------------|--|-----------------------|---|
| PEYP | Programmer type | nonE 1 4 20 | Programmer disabled Single program Four programs Twenty programs |
| HbAc | Holdback | SEG Prog | Holdback is individually selectable in each segment. Holdback is applied across the whole Program. |
| PwrF | Power fail recovery | cont rampb rSet | Continue from last setpoint (SP) Ramp from PV to SP at last ramp rate Reset the program |
| SrvO | Starting setpoint of a program (Servo point) | toPV toSP | From the Process Value (PV) From the setpoint |
| out | Programmable event outputs | no YES | Disabled Enabled |
| SYNc | Synchronisation of programs of several programmers | no YES | Disabled Enabled |

| Name | Description | Values | Meaning |
|---|---|----------------------------|--|
| RR | Alarm relay configuration | | |
| <i>i d</i> | Identity | <i>rELY</i> | Relay output |
| <i>Func</i> | Function | <i>nonE</i> <i>dl G</i> | No function Digital output |
| <i>SEnS</i> | Digital output sense | <i>nor</i> <i>inu</i> | Normal (<i>output energises when TRUE, e.g. program events</i>) Inverted (<i>output de-energises when TRUE, e.g. alarms</i>) |
| <p>The following digital events appear after 'SEnS'. Any one, or more, of the events can be combined on to the output (see Fig. 6-2) by selecting 'YES' in the lower readout.</p> | | | |
| <i>1 - -</i> | Alarm 1 active | <i>YES / no</i> | <p>(<i>- - -</i>) = alarm type (e.g. <i>FSL</i>). If an alarm has not been configured in '<i>AL Conf</i>' list, then display will differ:- e.g. Alarm 1 = '<i>AL 1</i>'.</p> |
| <i>2 - -</i> | Alarm 2 active | <i>YES / no</i> | |
| <i>3 - -</i> | Alarm 3 active | <i>YES / no</i> | |
| <i>4 - -</i> | Alarm 4 active | <i>YES / no</i> | |
| <i>mAn</i> | Controller in manual mode | <i>YES / no</i> | |
| <i>Sbr</i> | Sensor break | <i>YES / no</i> | |
| <i>SPAn</i> | PV out of range | <i>YES / no</i> | |
| <i>Lbr</i> | Loop break | <i>YES / no</i> | |
| <i>LdF</i> | Load failure alarm | <i>YES / no</i> | |
| <i>tunE</i> | Tuning in progress | <i>YES / no</i> | |
| <i>dcF</i> | Voltage output open circuit, or mA output open circuit | <i>YES / no</i> | |
| <i>rmEF</i> | PDS module measurement connection or remote input open circuit | <i>YES / no</i> | |
| <i>i P lF</i> | Input 1 failure | <i>YES / no</i> | |
| <i>newAL</i> | New Alarm has occurred | <i>YES / no</i> | |
| <i>End</i> | End of setpoint rate limit, or end of program | <i>YES / no</i> | |
| <i>SYnc</i> | Program Synchronisation active | <i>YES / no</i> | |
| <i>PrGn</i> | Programmer event output active, where 'n' = event number from 1 to 8. (<i>Not available with 8-segment programmer.</i>) | <i>YES / no</i> | |

Digital Events




Figure 6-2 Combining several digital events on to one output

| Name | Description | Values | Meaning |
|------------|----------------------------------|--|---|
| HR | Comms 1 module config | | |
| <i>i d</i> | Identity of the module installed | <i>cmS</i> <i>PdS</i> <i>PdS,</i> <i>dnEt</i> | EIA-232, or 2-wire EIA-485, or 4-wire EIA-485 comms PDS retransmission PDS input DeviceNet |

For '*d*' = '*cmS*' (Digital communications) use this parameter table:

| | | | |
|--|---|---|--|
| <i>Func</i> | Function | <i>mod</i> <i>Ei b,</i> | Modbus protocol Bisynch protocol |
| <i>bAud</i> | Baud Rate | <i>1200, 2400, 4800, 9600, 1920</i> (19,200) <i>125(K), 250(K), 500(K)</i> for DeviceNet | |
| <i>dELy</i> | Delay - quiet period, required by some comms adaptors | <i>no</i> <i>YES</i> | No delay Delay active - 10mS |
| <i>The following parameters only appear if the function chosen is Modbus protocol.</i> | | | |
| <i>PrEY</i> | Comms Parity | <i>nonE</i> <i>EuEn</i> <i>Odd</i> | No parity Even parity Odd parity |
| <i>rES</i> | Comms Resolution | <i>FuLL</i> <i>Int</i> | Full resolution Integer resolution |


For '*d*' = '*PdS*' (PDS retransmission output) use this parameter table:

| | | | |
|-------------|--|---|--|
| <i>Func</i> | Function <i>i.e. Retransmitted output</i> | <i>nonE</i> <i>SP.OP</i> <i>PV.OP</i> <i>OP.OP</i> <i>Er.OP</i> <i>SP.nH</i> | No PDS function PDS setpoint retransmission PDS PV retransmission PDS output power retransmission PDS error signal retransmission PDS setpoint retransmission - no holdback |
|-------------|--|---|--|

Output Scaling

| | | |
|--------------|--|--------------------------|
| <i>VAL.L</i> | | Retransmitted value low |
| <i>VAL.H</i> | | Retransmitted Value High |


| Name | Description | Values | Meaning |
|------|-------------|--------|---------|
|------|-------------|--------|---------|


| | | | |
|---|---|--------------|---------------------------------|
| For 'd' = 'PDS', (PDS setpoint input) use this parameter table: | | | |
| F_{unc} | Function | SP, P | PDS setpoint input |
| U_{RL}L |  | | Setpoint Displayed Value - Low |
| U_{RL}H | | | Setpoint Displayed Value - High |

Note: Having configured the module function as remote setpoint you must then specify the type of remote setpoint in the SP-conf list

| | | | |
|--|------------------------------|--|--|
| J_R | Comms 2 module config | | |
| Same as HA but is only available as PDS. | | | |


| Name | Description | Values | Meaning |
|-----------------------------|--|---|--|
| IA/b/c⁽¹⁾ | Module 1 configuration | | |
| d | Identity of module installed <i>(1) If a dual-, or triple-, channel module is installed then the list headers Ib and Ic also appear</i> | nonE rELY dcDP LoG LoGj SSr dc rE dc DP SG.SU | Module not fitted Relay output DC output isolated and non-isolated Logic/PDS output Logic input Triac output DC retransmission (isolated) Isolated DC output Transducer power supply |

| For 'd' = 'rELY', 'LoG', or 'SSr' use this parameter table: | | | |
|--|---|--|---|
| Func | Function <i>(Only Channels IA and Ic can be Heating, or Cooling). If a single logic output module is fitted (code LO) this function will need to be configured.</i> <i>(Only if 'd' = 'LoG')</i> <i>(Only if 'd' = 'LoG')</i> | nonE dlG HEAT COOL uP dwn SSr.1 SSr.2 | Function disabled Digital output function Heating output Cooling output Open motorised valve Close motorised valve PDS mode 1 heating PDS mode 2 heating |
| VAL.L | PID Demand Signal  | | % PID demand signal giving minimum output – 'Out.L' |
| VAL.H | | | % PID demand signal giving maximum output – 'Out.H' |
| Out.L | | | Minimum average power |
| Out.H | | | Maximum average power |
| SENS | Sense of output <i>(Only if 'Func' = 'dlG')</i> | nor inv | Normal (output energises when TRUE, e.g program events) Inverted (output de-energises when TRUE, e.g. alarms) |
| Notes: <ol style="list-style-type: none"> When 'SENS' appears, then further parameters are available. These are identical to those in the 'PARAMF' list on Page 6-14. If a Transducer Power Supply is fitted, the SENS parameter selects the output voltage. nor = 5V, inv = 10V A Transducer Power Supply does not provide any calibration facility and is simply a 5 or 10V power supply. To invert a PID output, the Val. H can be set below the Val.L | | | |

| Name | Description | Values | Meaning |
|--|--|--------|--|
| For 'd' = 'dC.OP', 'dC.rE', or 'dC.OP' use this parameter table: | | | |
| Func | Function | nonE | Function disabled |
| | | HEAT | Heating output |
| | | COOL | Cooling output |
| | | PV | Retransmission of PV |
| | | wSP | Retransmission of setpoint |
| | | Err | Retransmission of error signal |
| | | OP | Retransmission of OP power |
| VAL.L | %PID, or Retransmission Value  | | % PID, or Retrans'n Value, giving minimum output |
| VAL.H | | | % PID, or Retrans'n Value, giving maximum output |
| unit | | | volts = Volts, mA = milliamps |
| Out.L | | | Minimum electrical output |
| Out.H | | | Maximum electrical output |

For 'd' = 'LOG' (i.e logic input) use the 'LACONF' list on Page 6-13.

| 2A/b/C | Module 2 configuration | | |
|--|--|--------------|---|
| As per module 1 configuration, but excluding the 'SSr.1', 'SSr.2' functions. | | | |
| d | Identity of module installed. As per module 2 plus: | TPSU PotE | Transmitter power supply Potentiometer input |

| For 'd' = 'PotE' (i.e. potentiometer input module) use this parameter table: | | | |
|--|--|------|---|
| Func | Function | nonE | Function disabled |
| | | rSP | Remote Setpoint |
| | | Fwd | Feedforward input |
| | | rOPh | Remote OP power max. |
| | | rOPL | Remote OP power min. |
| | | UPoS | Motorised valve position |
| VAL.L | Displayed value  | | Displayed value low equivalent to 0% potentiometer position |
| VAL.H | | | |

| | | | |
|---|-------------------------------|--|--|
| 3A/b/C | Module 3 configuration | | |
| As per module 2 configuration, plus 'd' = 'dC, P' | | | |

For 'd' = 'dC, P' use this parameter table.
THIS INCLUDES THE SECOND PV FUNCTIONS

| | | | |
|-----------------------------------|----------------------------|--|---|
| F_{unc} | Function | nonE rSP F_{wd} rOP_h rOP_L H_i L_o F_{t_n} SEL t_{ran} | Function disabled Remote Setpoint Feedforward input Remote OP power max. Remote OP power min. PV = The highest of 'P. 1' or 'P. 2' PV = The lowest of 'P. 1, or 'P. 2' Derived function, where PV = (F. 1 x 'P. 1) + (F. 2 x 'P. 2). 'F. 1' and 'F. 2' are scalars which are found in 'P-L, S _t ' of Operator Level Select 'P. 1, or 'P. 2 via Comms, front panel buttons, or a digital input Transition of control between 'P. 1 and 'P. 2. The transition region is set by the values of 'L _o P' and 'H _i P', which are found in 'P-L, S _t ' of Operator Level. PV = 'P. 1 below 'L _o P' PV = 'P. 2 above 'H _i P' |
| i_nP_t | Input type | Refer to 'P [onF]' for all types, + the following: H_i I_n | High Impedance (range = 0 to 2 volt) |
| C_JC | Cold Junction Compensation | OFF Auto 0°C 45°C 50°C | No cold junction compensation Automatic internal compensation 0°C external reference 45°C external reference 50°C external reference |
| i_mP | Sensor Break Impedance | OFF Auto H_i H_i H_i | Disabled (applies to any input) Caution: If sensor break is disabled the controller will not detect open circuit faults Factory set Impedance of input > 15KΩ Impedance of input > 30KΩ |

Linear Input Scaling – The next four parameters only appear if a linear input is chosen.

| | | |
|-----------------------------------|--|----------------------|
| i_nP_L | | Input value low |
| i_nP_H | | Input value high |
| U_RL_L | | Displayed value low |
| U_RL_H | | Displayed value high |

| Name | Description | Values | Meaning |
|---|---|---|---|
| 4R | Module 4 configuration | | |
| Note: This option is not available on controllers from 01 Jan-04 | | | |
| Id | Identity of module installed | HCS | High Current Switch |
| Func | Function | nonE dIG HEAT COOL | Function disabled Digital output function Heating output Cooling output |
| URLL | <p>PID Demand Signal</p> | | % PID demand signal giving minimum output – ‘OutL’ |
| URLH | | | % PID demand signal giving maximum output – ‘OutH’ |
| OutL | | | Minimum electrical output |
| OutH | | | Maximum electrical output |
| SENS | Sense of output (Only if ‘Func’ = ‘dIG’) | nor inv | Normal (output energises when TRUE, e.g. program events) Inverted (output de-energises when TRUE, e.g. alarms) |
| <p>When ‘SENS’ appears, then further parameters are available. These are identical to those in the ‘RR Conf’ list on Page 6-14.</p> | | | |

| Custom | 8-point Custom Linearisation ⁽¹⁾ | |
|---------------|--|---------------------------------------|
| in 1 | <p>Displayed Value</p> | Custom input 1 |
| URL 1 | | Linearisation Value representing in 1 |
| in 8 | | Custom input 8 |
| URL B | | Linearisation Value representing in 8 |

Note:

1. Custom Linearisation is only available when ‘RR-Conf’ or ‘P- Conf’ list has ‘nP1’ set to ‘mUL’, or ‘mAL’, or ‘UL’.
2. The values and inputs must be continuously increasing or decreasing

| Name | Description | Values | Meaning | |
|---|--------------------|------------------------|-------------------------------------|---|
| CAL | Calibration | | | |
| <p><i>In this mode you can</i></p> <ol style="list-style-type: none"> 1. Calibrate the instrument using a mV source - <i>rCAL</i> or ref source cal. 2. Offset the calibration to account for errors in actual sensor measurement and a ref sensor - <i>ULCAL</i> or user calibration 3. Return to factory set calibration - <i>FALC</i> or factory set calibration. | | | | |
| <i>rCAL</i> | Calibration point | <i>nonE</i> | No calibration | Goto User calibration table- See also chapter 7 |
| | | <i>PU</i> | Calibrate main Process Value input. | |
| | | <i>PU2</i> | Calibrate DC input, or PV 2. | Go to DC Output Calibration table |
| | | <i>IAH₁</i> | Calibrate DC output high - Module 1 | |
| | | <i>IAL₁</i> | Calibrate DC output low - Module 1 | |
| | | <i>PAH₂</i> | Calibrate DC output high - Module 2 | |
| | | <i>PAL₂</i> | Calibrate DC output low - Module 2 | |
| | | <i>PAH₃</i> | Calibrate DC output high - Module 3 | |
| | | <i>PAL₃</i> | Calibrate DC output low - Module 3 | |

| INPUT CALIBRATION | | | |
|--|--|---------------|---------------------------------------|
| <i>For 'CAL' = 'PU', or 'PU2', the following parameters apply.</i> | | | |
| <i>PU</i> | PV Calibration Value | <i>IDLE</i> | Idle |
| | | <i>muL</i> | Select 0mV as the calibration point |
| | | <i>muH</i> | Select 50mV as the calibration point |
| | | <i>U 0</i> | Select 0Volt as the calibration point |
| | | <i>U 10</i> | Select 10V as the calibration point |
| | | <i>CJC</i> | Select 0°C CJC calibration point |
| | | <i>rEd</i> | Select 400Ω as the calibration point |
| | | <i>HI 0</i> | High impedance: 0Volt cal'n point |
| | | <i>HI 1.0</i> | High impedance: 1.0 Volt cal'n point |
| <i>GO</i> | Start calibration Select 'YES' with <input type="button" value="▲"/> or <input type="button" value="▼"/> Wait for calibration to complete. | <i>FALC</i> | Restore factory calibration |
| | | <i>no</i> | Waiting to calibrate PV point |
| | | <i>YES</i> | Start calibration |
| | | <i>buSY</i> | Busy calibrating |
| | | <i>donE</i> | PV input calibration completed |
| | | <i>FAI L</i> | Calibration failed |

Note. When a DC input module is installed for the first time, or there is a requirement to change one, then the microprocessor in the controller needs to read the factory calibration data stored in the module. Select 'FALC' as the calibration value. Step to 'GO' and start calibration.

| DC Output Calibration | | | |
|--|-------------------------|--------------------------|--|
| <i>The following parameters apply to DC output modules ie for rCAL = IAH to JALD</i> | | | |
| cALH | Output Calibration High | <input type="checkbox"/> | <input type="checkbox"/> = Factory set calibration. Trim value until output = 9V, or 18mA |
| cALL | Output Calibration Low | <input type="checkbox"/> | <input type="checkbox"/> = Factory set calibration. Trim value until output = 1V, or 2mA |

| User calibration | | |
|-------------------------|------------------------------------|---|
| UCAL | User calibration enable | Yes/no |
| PE1L | Low calibration point for Input 1 | The factory calibration point at which the low point offset was performed. |
| PE1H | High calibration point for Input 1 | The factory calibration point at which the high point offset was performed. |
| OF1L | Offset Low for Input 1 | Calculated offset, in display units. |
| OF1H | Offset High for Input 1 | Calculated offset, in display units. |
| PE2L | Low calibration point for Input 2 | The factory calibration point at which the low point offset was performed. |
| PE2H | High calibration point for Input 2 | The factory calibration point at which the high point offset was performed. |
| OF2L | Offset Low for Input 2 | Calculated offset, in display units. |
| OF2H | Offset High for Input 2 | Calculated offset, in display units. |

| Name | Description | Values | Meaning |
|-------------|-------------------------------|---------------|----------------|
| PASS | Password configuration | | |
| ACEP | FuLL or Edit level password | | |
| cnFP | Configuration level password | | |









Note:- When passwords are changed please make a note of the new numbers

| | | | |
|-------------|---------------------------|--------|--|
| EXIT | Exit configuration | no/YES | |
|-------------|---------------------------|--------|--|

CONFIGURATION EXAMPLES















Transducer Power Supply









To configure the choice of output voltage:-

| Do This | The Display You Should See | Additional Notes |
|--|---|--|
| 1. Press  as many times as necessary to select the slot position in which the transducer power supply is fitted |  | The transducer power supply can be fitted in slot positions 1 and 2. The display will show <i>IA</i> or <i>IB</i> accordingly |
| 2. Press  to read the identity of the module |  | This is read only where: <i>SG.SU</i> = Transducer Power Supply |
| 3. Press  (twice) to read 'SEnS' 4. Press  and  to select ' <i>nu</i> ' or ' <i>nr</i> ' |  | <i>nu</i> = 10Vdc <i>nr</i> = 5Vdc The Transducer Power supply uses existing software written for digital modules. A list of parameters follow which are not applicable to this module. |

DeviceNet

To configure Function, Baud Rate, Resolution and Node Address:-

| Do This | The Display You Should See | Additional Notes |
|---|---|---|
| 1. Press  as many times as necessary to select 'HA' |  | This is the position in which the DeviceNet module is fitted |
| 2. Press  to read 'id' |  | If the module is present id = 'cm5' (digital communications) or 'none' if the module is not present |
| 3. Press  to read 'Func' |  | If the DeviceNet module is fitted 'Func' = 'dnEt' and will be read only |
| 4. Press  to read 'bAud' 5. Press  and  to select the baud rate |  | Baud rate can be set to 125(K), 250(K) or 500(K) |
| 6. Press  to read 'rES' 7. Press  and  to select 'FULL' or 'nt' |  | FULL - the decimal point position is implied, eg 100.1 is transmitted as 1001. 'nt' - rounded to the nearest integer value |

| | | |
|---|---|---|
| Node Address is set up in Operator or Full Access level. Select either of these levels, then:- | | |
| <p>8. Press  as many times as necessary to select 'cm5'</p> |  | |
| <p>9. Press  to read 'Addr'</p> <p>10. Press  and  to select the address</p> |  | <p>Valid addresses are from 0 - 63</p> |
| <p>11. Press  to read 'nw.5t'</p> |  | <p>Indicates the network status:-</p> <p>'run' = network connected and operational</p> <p>'rdy' = network connected but not operational</p> <p>'OFFL' = network not connected</p> |

Chapter 7 USER CALIBRATION

This chapter has five topics:

- WHAT IS THE PURPOSE OF USER CALIBRATION?
- USER CALIBRATION ENABLE
- OFFSET CALIBRATION
- TWO POINT CALIBRATION
- CALIBRATION POINTS AND CALIBRATION OFFSETS

To understand how to select and change parameters in this chapter you will need to have read Chapter 2 - *Operation*, Chapter 3- *Access Levels* and Chapter 6 - *Configuration*.

WHAT IS THE PURPOSE OF USER CALIBRATION?

The basic calibration of the controller is highly stable and set for life. User calibration allows you to offset the 'permanent' factory calibration to either:


1. Calibrate the controller to the your reference standards.
2. Match the calibration of the controller to that of a particular transducer or sensor input.
3. Calibrate the controller to suit the characteristics of a particular installation.
4. Remove long term drift in the factory set calibration.

User calibration works by introducing a single point, or two-point, offset onto the factory set calibration.

USER CALIBRATION ENABLE

The User calibration facility must first be enabled in configuration level by setting the parameter 'UCAL' in the input conf list to 'YES'. This will make the User calibration parameters visible in Operator 'FULL' level.

Select configuration level as shown in Chapter 6, *Configuration*.



The Calibration Configuration List

Press until you reach the 'CAL-CONF' list.

Press until you reach 'UCAL'.

User Calibration Enable

Use or to select:

- YES: Calibration enable
- no: Calibration disabled


Press and together to go to the EXIT display.

Exit configuration

Use or to select 'YES' to return to Operator level.

OFFSET CALIBRATION


Offset calibration is used to apply a single fixed offset over the full display range of the controller.



To calibrate, proceed as follows:

1. Connect the input of the controller to the source device to which you wish to calibrate.
2. Set the source to the desired calibration value.
3. The controller will display the current measurement of the value.
4. If the displayed value is correct, then the controller is correctly calibrated and no further action is necessary. If it is incorrect, then follow the steps shown below.

Select 'FULL' access level, as described in Chapter 3.




Input list header

Press until you reach the input list header.



Press until you reach the 'CAL' display.



Calibration type

- **FACT:** Factory Calibration
- **USER:** User Calibration


Use or to select 'FACT'.

Selecting 'FACT' reinstates the factory calibration and allows the application of a single fixed offset.




Press .

*continued
on the next page*



See table on the right for additional parameters.



Set Offset 1

Use or to set the offset value of Process Value 1 (PV1).

The offset value is in display units.

Press .

Set Offset 2

Use or to set the offset value of Process Value 2 (PV2), *if configured*.

The offset value is in display units.

Press .

The table below shows the parameters which appear after 'OFS.2'. These are all read only values and are for information.

Press to step through them.


| | |
|-------|---|
| mU.1 | IP1 measured value (at terminals) |
| mU.2 | IP2 measured value (at terminals), if DC input in Module 3 position |
| CJC.1 | IP1 Cold Junction Compensation |
| CJC.2 | IP2 Cold Junction Compensation |
| L.1 | IP1 Linearised Value |
| L.2 | IP2 Linearised Value |
| PUSL | Shows the currently selected input |

If you do not want to look at these parameters, then press and this returns you to the 'P-L, SE' header.

To protect the calibration against unauthorised adjustment, return to Operator level and make sure that the calibration parameters are hidden. Parameters are hidden using the 'Edit' facility described in Chapter 3, *Access Levels*.


TWO-POINT CALIBRATION

The previous section described how to apply a offset, or trim, calibration, which applies a fixed offset over the full display range of the controller. A two-point calibration is used to calibrate the controller at two points and applies a straight line between them. Any readings above, or below, the two calibration points will be an extension of this straight line. For this reason it is best to calibrate with the two points as far apart as possible.



Proceed as follows:

1. Decide upon the low and high points at which you wish to calibrate.
2. Perform a two point calibration in the manner described below.



Input list header

Press until you reach the input list header, 'PL St'.

Press until you reach the 'CAL' display.

Calibration type




- **FACT:** Factory Calibration
- **USER:** User Calibration

Use or to select 'USER'.

Selecting 'USER' enables two-point calibration.

[If two-point calibration is unsatisfactory, select 'FACT' to return to the factory set calibration.]

Press



Select Low-point Calibration

This is the Calibration Status display. This display shows that no input is selected for calibration.

- none: No selection
- , P L: Input 1 (PV1) calibration low-point selected
- , P H: Input 1 (PV1) calibration high-point selected
- , P 2L: Input 2 (PV2) calibration low-point selected
- , P 2H: Input 2 (PV2) calibration high-point selected

Use to select the parameter for the Low Calibration point of Input 1, ' , P L '.

Press .

Adjust low-point calibration

This is the display for adjusting the Low Calibration point of Input 1. The lower readout is a live reading of the process value, which changes as the input changes.

Make sure that the calibration source is connected to the terminals of Input 1, switched on and feeding a signal to the controller. It should be set to the desired low-point calibration value. If the lower readout does not show this value, then use to adjust the reading to the required value.

Press to return to the ' , P -L, St ' header.


To perform the High-point Calibration, repeat the above procedure, selecting ' , P H ' in the 'CAL.S' display for adjustment.

Press three times.

Calibration type

'USER' was selected for the Low-point Calibration, and has remained selected.

Press .



Select High-point Calibration

This is the Calibration Status display, again.

Use to select the parameter for the High-point Calibration of Input 1, 'P1H'.

Press

Adjust High-point Calibration

This is the display for adjusting the High Calibration point of Input 1. The lower readout is a live reading of the process value, which changes as the input changes.

Feed the desired high-point calibration signal to the controller, from the calibration source. If the lower readout does not show this value, then use to adjust the reading to the required value.

Press to return to the 'P-L, St' header.

To protect the calibration against unauthorised adjustment return to Operator level and make sure that the calibration parameters are hidden. Parameters are hidden using the 'Edt' facility described in Chapter 3.



To perform a User Calibration on Input 2, proceed as with Input 1 above, except that when 'CAL5-none' appears, press until 'CAL5-P2L' is obtained, then proceed as with Input 1. Repeat the procedure for 'P2H'.

CALIBRATION POINTS AND CALIBRATION OFFSETS

If you wish to see the points at which the User calibration was performed and the value of the offsets introduced, then these are shown in Configuration, in 'CAL-CONF'.

The parameters are:

| Name | Parameter description | Meaning |
|------|------------------------------------|---|
| PE1L | Low calibration point for Input 1 | The factory calibration point at which the low point offset was performed. |
| PE1H | High calibration point for Input 1 | The factory calibration point at which the high point offset was performed. |
| OF1L | Offset Low for Input 1 | Calculated offset, in display units. |
| OF1H | Offset High for Input 1 | Calculated offset, in display units. |
| PE2L | Low calibration point for Input 2 | The factory calibration point at which the low point offset was performed. |
| PE2H | High calibration point for Input 2 | The factory calibration point at which the high point offset was performed. |
| OF2L | Offset Low for Input 2 | Calculated offset, in display units. |
| OF2H | Offset High for Input 2 | Calculated offset, in display units. |


Note: The value of each of the parameters in the above table may also be altered by using the / buttons.

Appendix A

UNDERSTANDING THE ORDERING CODE

The 2408 and 2404 controllers have a modular hardware construction, which accepts up to three plug-in Input/Output modules and two communications modules to satisfy a wide range of control requirements. Two digital inputs and an optional alarm relay form part of the fixed hardware build.

The ordering code is in two parts. The hardware coding and an optional configuration coding. The hardware coding specifies the basic build of the controller and the plug-in modules that are fitted.



The controller may have been ordered with just the hardware build specified, or with configuration included. This is indicated by the ordering code on the side of the controller.

| Part 1A: Hardware coding | | | |
|--------------------------|----------|----------------|-----------------|
| Basic build | | | Plug-in modules |
| Model number | Function | Supply voltage | Module 1 |
| 2408 | CC | VH | LH |

▶ Continued next page

| Model Number | |
|----------------|--------------------|
| 2408 | 1/8 DIN Controller |
| 2404 | 1/4 DIN Controller |
| Profibus units | |
| 2408f | 1/8 DIN Controller |
| 2404f | 1/4 DIN Controller |

| Function | |
|-------------------------|-----------------------|
| Standard PID control | |
| CC | Controller |
| CG | 1 x 8 seg prog |
| CP | 1 x 16 seg prog |
| P4 | 4 x 16 seg prog |
| QM | 20 x 16 seg prog |
| | Note 1 |
| On/Off control | |
| NF | Controller only |
| NG | 1 x 8 seg prog |
| NP | 1 x 16 seg prog |
| N4 | 4 x 16 seg prog |
| NM | 20 x 16 seg prog |
| Motorised valve control | |
| VC | Valve positioner (VP) |
| VG | 1 x 8 seg prog |
| VP | 1 x 16 seg prog |
| V4 | 4 x 16 seg prog |
| VM | 20 x 16 seg prog |
| | Note 1 |

| Supply voltage | |
|----------------|----------------|
| VH | 85 to 264Vac |
| VL | 20 to 29Vac/dc |

* fitted unconfigured

| Module 1 | |
|--|----------------------------------|
| XX | Not fitted |
| Relay: | 2-pin |
| R2 | Fitted unconfigured |
| RH | PID heating |
| RU | Valve raise output |
| Relay: change-over | |
| R4 | Fitted unconfigured |
| YH | PID heating |
| RP | Valve raise (note 6) |
| <i>Or Alarm 1: select from table A</i> | |
| Logic: (Non-isolated) | |
| L2 | Fitted unconfigured |
| LH | Heating output |
| M1 | PDS heater break detect (note 2) |
| M2 | PDS current monitoring (note3) |
| Logic: (isolated) | |
| LO | Single logic output * |
| Triac | |
| T2 | Fitted unconfigured |
| TH | Heating output |
| TU | Valve raise output |
| DC control (isolated) | |
| D4 | Fitted unconfigured |
| H6 | 0-20mA PID heating |
| H7 | 4-20mA PID heating |
| H8 | 0-5V PID heating |
| H9 | 1-5V PID heating |
| HZ | 0-10V PID heating |
| Digital I/O (unconfigured) | |
| TK | Triple contact input |
| TL | Triple logic input |
| TP | Triple logic output |
| Dual relay | |
| RR | Fitted unconfigured |
| RD | PID heat + PID cool |
| RM | Valve raise and lower |
| Dual triac | |
| TT | Fitted unconfigured |
| TD | PID heat + PID cool |
| TM | Valve raise and lower |
| Logic + relay | |
| LR | Fitted unconfigured |
| LD | PID heat + PID cool |
| QC | Mode 2 + cool |
| Logic + triac | |
| LT | Fitted unconfigured |
| GD | PID heat + PID cool |
| QD | Mode 2 + cool |
| Transducer P5 | |
| G3 | 5Vdc |
| G5 | 10Vdc |

| Table A : Alarm relay functions | |
|---------------------------------|----------------|
| FH | High alarm |
| FL | Low alarm |
| DB | Deviation band |
| DL | Low dev. alarm |
| DH | High dev alarm |

| Table B : DC retransmission | |
|-----------------------------|---------------------|
| D6 | Fitted unconfigured |
| First character | |
| V- | PV retrans |
| S- | Setpoint retrans |
| O- | Output retrans |
| Z- | Error retrans |
| Second character | |
| -1 | 0-20mA |
| -2 | 4-20mA |
| -3 | 0-5V |
| -4 | 1-5V |
| -5 | 0-10V |

continued



| Part 1B: Hardware coding | | | | | | |
|--------------------------|----------|-------------|--|-----------------|---------|--------|
| Plug-in modules | | Alarm relay | | Plug-in modules | | Manual |
| Module 2 | Module 3 | | | Comms 1 | Comms 2 | |
| RC | FL | FH | | YM | TS | ENG |

| Module 2 | |
|--|---------------------------------|
| XX | Not fitted |
| Relay: 2-pin | |
| R2 | Fitted unconfigured |
| RC | Cooling output |
| RW | Valve lower output |
| Relay: change-over | |
| R4 | Fitted unconfigured |
| YC | Cooling Output |
| RL | Valve lower (note 6) |
| PO | Program event output 1 (note 7) |
| PE | Program END segment |
| <i>Or Alarm 2: select from table A</i> | |
| Dual relay | |
| RR | Fitted unconfigured |
| PP | Program events 1 & 2 (note 7) |
| Logic (non-isolated) | |
| L2 | Fitted unconfigured |
| LC | PID cooling |
| Logic (isolated) | |
| LO | Single logic output * |
| Triac | |
| T2 | Fitted unconfigured |
| TC | PID cooling |
| TW | Valve lower output |
| DC control isolated | |
| D4 | Fitted unconfigured |
| C6 | 0-20mA PID cooling |
| C7 | 4-20mA PID cooling |
| C8 | 0-5V PID cooling |
| C9 | 1-5V PID cooling |
| CZ | 0-10V PID cooling |
| Digital I/O (unconfigured) | |
| TK | Triple contact input |
| TL | Triple logic input |
| TP | Triple logic output |
| Power supply | |
| MS | 24Vdc transmitter |
| DC retran (isolated) | |
| <i>Select from table B</i> | |
| Potentiometer input | |
| VU | Fitted unconfigured |
| VS | Valve position feedback |
| VR | Setpoint input |
| Transducer PSU | |
| G3 | 5Vdc |
| G5 | 10Vdc |

| Module 3 | |
|---------------------------------------|------------------------------|
| XX | Not fitted |
| Relay: 2-pin | |
| R2 | Fitted unconfigured |
| Relay: change-over | |
| R4 | Fitted unconfigured |
| PO | Program event 4 (note 7) |
| PE | Program END output |
| <i>Or Alarm 3 select from table A</i> | |
| Logic (non-isolated) | |
| L2 | Fitted unconfigured |
| Logic (isolated) | |
| LO | Single logic output * |
| Triac | |
| T2 | Fitted unconfigured |
| Dual relay | |
| RR | Fitted unconfigured |
| PP | Program event 4 & 5 (note 7) |
| Digital I/O (unconfigured) | |
| TK | Triple contact input |
| TL | Triple logic input |
| TP | Triple logic output |
| Power supply | |
| MS | 24V transmitter |
| DC remote input | |
| D5 | Fitted unconfigured |
| W2 | 4 to 20mA setpoint |
| W5 | 0 to 10V setpoint |
| WP | Second PV input |
| DC retran (isolated) | |
| <i>Select from table B</i> | |
| Potentiometer input | |
| VU | Fitted unconfigured |
| VS | VP feedback |
| VR | Setpoint input |
| Transducer PSU | |
| G3 | 5Vdc |
| G5 | 10Vdc |

| Comms 1 | |
|------------------------|------------------------------|
| XX | None |
| 2-wire EIA-485 | |
| Y2 | Fitted unconfigured |
| YM | Modbus protocol |
| YE | EI Bisynch protocol (note 1) |
| RS-232 | |
| A2 | Fitted unconfigured |
| AM | Modbus protocol |
| AE | EI Bisynch protocol (note 1) |
| 4-wire RS-485 | |
| F2 | Fitted unconfigured |
| FM | Modbus protocol |
| FE | EI Bisynch protocol (note 1) |
| PDS output | |
| M7 | Fitted unconfigured |
| PT | PV retransmission |
| TS | Setpoint retrans |
| OT | Output retrans |
| Profibus module | |
| PB | High speed RS485 |
| DeviceNet | |
| DN | DeviceNet |

| Comms 2 | |
|-------------------|---------------------|
| XX | Not fitted |
| PDS input | |
| M6 | Fitted unconfigured |
| RS | Setpoint input |
| PDS output | |
| M7 | Fitted unconfigured |
| PT | PV retransmission |
| TS | Setpoint retrans |
| OT | Output retrans |

| Alarm relay | |
|------------------------------------|----------------------------|
| XX | Not fitted |
| Alarm 4 relay | |
| RF | Fitted unconfigured |
| <i>Table A alarm options plus:</i> | |
| RA | Rate of change |
| PDS alarms | |
| LF | Heater break detect |
| HF | Current monitor heater brk |
| SF | Current monitor SSR fail |
| PO | Program event 7 (note 7) |
| PE | Program END output |

| Manual | |
|--------|-----------|
| XXX | No manual |
| ENG | English |
| FRA | French |
| GER | German |
| NED | Dutch |
| SPA | Spanish |
| SWE | Swedish |
| ITA | Italian |

* fitted unconfigured

| Hardware coding | Part 2: Configuration | | | | Continued next page |
|-----------------|-----------------------|---------------------------|-----------|---------------|---------------------|
| | Sensor input | Range min | Range max | Display Units | |
| | K | See note 4 0 1000 | | C | ▶ |

| Sensor input | Range min & max | |
|-----------------------------------|-----------------|--------------|
| <i>Standard sensor inputs</i> | °C | °F |
| J J thermocouple | -210 to 1200 | -340 to 2192 |
| K K thermocouple | -200 to 1372 | -325 to 2500 |
| T T thermocouple | -200 to 400 | -325 to 750 |
| L L thermocouple | -200 to 900 | -325 to 650 |
| N N thermocouple | -250 to 1300 | -418 to 2370 |
| R Type R - Pt13%Ph/Pt | -50 to 1768 | -58 to 3200 |
| S Type S - Pt10%Rh/Pt | -50 to 1768 | -58 to 3200 |
| B Type B - Pt30%Rh/Pt6%Rh | 0 to 1820 | 32 to 3308 |
| P Platinel II | 0 to 1369 | 32 to 2496 |
| Z RTD/PT100 | -200 to 850 | -325 to 1562 |
| Process inputs | | |
| F +/- 100mV | 0 to 9999 | |
| Y 0-20 mA Linear | 0 to 9999 | |
| A 4-20 mA Linear | 0 to 9999 | |
| W 0-5V DC Linear | 0 to 9999 | |
| G 1-5V DC Linear | 0 to 9999 | |
| V 0-10V DC Linear | 0 to 9999 | |
| Factory downloaded input | | |
| C *Type C W5%Re/W26%Re (Hoskins)* | 0 to 2319 | 32 to 4200 |
| D Type D - W3%Re/W25%Re | 0 to 2399 | 32 to 4350 |
| E E thermocouple | -270 to 1000 | -450 to 1830 |
| 1 Ni/Ni18%Mo | 0 to 1399 | 32 to 2550 |
| 2 Pt20%Rh/Pt40%Rh | 0 to 1870 | 32 to 3398 |
| 3 W/W26%Re (Englehard) | 0 to 2000 | 32 to 3632 |
| 4 W/W26%Re (Hoskins) | 0 to 2010 | 32 to 3650 |
| 5 W5%Re/W26%Re (Englehard) | 10 to 2300 | 50 to 4172 |
| 6 W5%Re/W26%Re (Bucose) | 0 to 2000 | 32 to 3632 |
| 7 Pt10%Rh/Pt40%Rh | 200 to 1800 | 392 to 3272 |
| 8 Exergen K80 I.R. pyrometer | -45 to 650 | -50 to 1200 |

| Display Units | |
|---------------|--------------|
| C | Celcius |
| F | Fahrenheit |
| K | Kelvin |
| X | Linear input |

| continued | Part 2: Configuration | | | | | | |
|-----------|-----------------------|-----------------|---------|----------------|---------|---------|---------|
| | Digital input 1 | Digital input 2 | Control | Power feedback | Cooling | Buttons | Program |
| ▶ | AM | S2 | XX | XX | XX | MD | XX |

| Digital inputs 1 & 2 | | | | Options | |
|----------------------|----------------------------|----|---|------------------------------|---|
| XX | Disabled | AT | Adaptive tune enable | Control action | |
| AM | Manual select | FA | Select full access level | XX | Reverse acting (standard) |
| SR | Remote setpoint select | RB | Simulates UP button | DP | Direct acting PID control |
| S2 | Second setpoint select | LB | Simulates DOWN button | Power feedback | |
| EH | Integral hold | SB | Simulates SCROLL button | XX | Enabled on logic, relay & triac heating |
| AC | Alarm acknowledge | PB | Simulates PAGE button | PD | Feedback disabled |
| RP | Setpoint rate limit enable | B1 | Least sig. BCD dig. | Cooling options | |
| RN | Run program | B2 | 2nd BCD digit | XX | Linear cooling |
| HO | Hold program | B3 | 3rd BCD digit | CF | Fan cooling |
| RE | Reset program | B4 | 4th BCD digit | CW | Water cooling |
| RH | Run/hold program | B5 | 5th BCD digit | CL | Oil cooling |
| KL | Keylock | B6 | Most sig. BCD digit | CO | On/off cooling |
| NT | Run/Reset program | SY | Standby - ALL ops OFF | Front panel buttons | |
| TN | Reset/Run program | SG | Skip segment (without changing SP) | XX | Enabled |
| HB | Prog. holdback enable | SC | Program synch. | MD | Auto/man button disabled |
| P2 | PID2 select | PV | Select PV2 | MR | Auto/man & run/hold disabled |
| ST | One-shot tune enable | AG | Advance to end of segment (& step to target setpoint) | RD | Run/hold button disabled |
| | | M5 | CTX (mode 5) (input 2 only) | Programmer time units | |
| | | | | XX | Dwell & ramp in minutes |
| | | | | HD | Dwell time in hours |
| | | | | HR | Ramp rate in units/hour |

The example given in the coding is for 2408 PID controller, 85 to 264 Vac, logic heating, relay cooling, low alarm relay, high alarm relay, RS485 Modbus comms, PDSIO setpoint retransmission, type K thermocouple, 0 to 1000°C, Auto/manual select, second setpoint select, manual button disabled.

Notes:

1. Not available with profibus controllers
 2. PDS heater break detect will transmit the power demand to a TE10S solid state relay and read back a heater break alarm
 3. PDS current monitoring will transmit the power demand signal to a TE10S solid state relay and read back load current and open and short circuit alarms
 4. Setpoint limits: include the decimal position required in the displayed value. Up to one for temperature inputs, up to two for process inputs
 5. An external 1% current sense resistor is supplied as standard. If greater accuracy is required, a 0.1% 2.49 Ω can be ordered as part number SUB2K/249R.1
 6. Only available with Profibus controller
 7. Not available with 8 segment programmer
-
- **PDS** is a proprietary technique for bi-directional transmission of analogue and digital data between instruments.
 - Mode 1: provides logic heating to a TE10S (fitted with option PDS1) solid state relay with feedback of a general load fault alarm.
 - Mode 2: provides logic heating to a TE10S (fitted with option PDS2) solid state relay with feedback of load current and two alarms: solid state relay failure and heater circuit failure.
 - **Range min and Range max:** Thermocouple and RTD sensor inputs will always display over the full operating range shown in Sensor input table. For these inputs, the values entered here are the low and high setpoint limits. For process inputs, the values are the display scaling. corresponding to the minimum and maximum input values.

SAFETY and EMC INFORMATION

This controller is manufactured in the UK by Eurotherm Ltd.

Please read this section carefully before installing the controller

This controller is intended for industrial temperature and process control applications when it will meet the requirements of the European Directives on Safety and EMC. Use in other applications, or failure to observe the installation instructions of this handbook may impair the safety or EMC protection provided by the controller. It is the responsibility of the installer to ensure the safety and EMC of any particular installation.

GENERAL

The information contained in this manual is subject to change without notice. While every effort has been made to ensure the accuracy of the information, your supplier shall not be held liable for errors contained herein.

Safety

This controller complies with the European Low Voltage Directive 73/23/EEC, by the application of the safety standard EN 61010.

Electromagnetic compatibility

This controller conforms with the essential protection requirements of the EMC Directive 89/336/EEC, by the application of appropriate product specific international standards. This instrument satisfies the general requirements of the commercial and industrial environments defined in EN 61326. For more information on product compliance refer to the Technical Construction File.

Unpacking and storage

The packaging should contain an instrument mounted in its sleeve, two mounting brackets for panel installation and an Installation & Operating guide. Certain ranges are supplied with an input adapter.

If on receipt, the packaging or the instrument are damaged, do not install the product but contact your supplier. If the instrument is to be stored before use, protect from humidity and dust in an ambient temperature range of -20°C to $+70^{\circ}\text{C}$.

SERVICE AND REPAIR

This controller has no user serviceable parts. Contact your nearest Eurotherm agent for repair.

Caution: Charged capacitors

Before removing an instrument from its sleeve, disconnect the supply and wait at least two minutes to allow capacitors to discharge. Failure to observe this precaution will expose capacitors that may be charged with hazardous voltages. In any case, avoid touching the exposed electronics of an instrument when withdrawing it from the sleeve.

Electrostatic discharge precautions

When the controller is removed from its sleeve, some of the exposed electronic components are vulnerable to damage by electrostatic discharge from someone handling the controller. To avoid this, before handling the unplugged controller discharge yourself to ground.

Cleaning

Do not use water or water based products to clean labels or they will become illegible. Isopropyl alcohol may be used to clean labels. A mild soap solution may be used to clean other exterior surfaces of the product.

INSTALLATION SAFETY REQUIREMENTS

Safety Symbols

Various symbols are used on the instrument, they have the following meaning:



Caution, (refer to the accompanying documents)



Functional earth (ground) terminal

The functional earth connection is not required for safety purposes but to ground RFI filters.

Personnel

Installation must only be carried out by suitably qualified personnel.

Enclosure of live parts

To prevent hands or metal tools touching parts that may be electrically live, the controller must be installed in an enclosure.

Caution: Live sensors

All isolated inputs and outputs have reinforced insulation to provide protection against electric shock. The non-isolated dc, logic and PDSIO outputs are all electrically connected to the main process variable input, (thermocouple etc.). If the temperature sensor is connected directly to an electrical heating element then these non-isolated inputs and outputs will also be live. The controller is designed to operate under these conditions. However you must ensure that this will not damage other equipment connected to these inputs and outputs and that service personnel do not touch connections to these i/o while they are live. With a live sensor, all cables, connectors and switches for connecting the sensor and non-isolated inputs and outputs must be mains rated.

Wiring

It is important to connect the controller in accordance with the wiring data given in this handbook. Take particular care not to connect AC supplies to the low voltage sensor input or DC or logic inputs and output. Only use copper conductors for connections (except thermocouple inputs) and ensure that the wiring installations comply with all local wiring regulations. For example in the UK use the latest version of the IEE wiring regulations, (BS7671). In the USA use NEC Class 1 wiring methods.

Power Isolation

The installation must include a power isolating switch or circuit breaker. This device should be in close proximity to the controller, within easy reach of the operator and marked as the disconnecting device for the instrument.

Earth leakage current

Due to RFI Filtering there is an earth leakage current of less than 0.5mA. This may affect the design of an installation of multiple controllers protected by Residual Current Device, (RCD) or Ground Fault Detector, (GFD) type circuit breakers.

Overcurrent protection

To protect the internal PCB tracking within the controller against excess currents, the AC power supply to the controller and power outputs must be wired through the fuse or circuit breaker specified in the technical specification.

Voltage rating

The maximum continuous voltage applied between any of the following terminals must not exceed 264Vac:

- relay output to logic or dc sensor connections;
- any connection to ground.

The controller should not be wired to a three phase supply with an unearthed star connection. Under fault conditions such a supply could rise above 264Vac with respect to ground and the product would not be safe.

Conductive pollution

Electrically conductive pollution must be excluded from the cabinet in which the controller is mounted. For example, carbon dust is a form of electrically conductive pollution. To secure a suitable atmosphere, fit an air filter to the air intake of the cabinet. Where condensation is likely, for example at low temperatures, include a thermostatically controlled heater in the cabinet.

This product has been designed to conform to BSEN61010 installation category II, pollution degree 2. These are defined as follows:-

Installation Category II

The rated impulse voltage for equipment on nominal 230V supply is 2500V.

Pollution Degree 2

Normally only non conductive pollution occurs. Occasionally, however, a temporary conductivity caused by condensation shall be expected.

Over-temperature protection

When designing any control system it is essential to consider what will happen if any part of the system should fail. In temperature control applications the primary danger is that the heating will remain constantly on. Apart from spoiling the product, this could damage any process machinery being controlled, or even cause a fire.

Reasons why the heating might remain constantly on include:

- the temperature sensor becoming detached from the process;
- thermocouple wiring becoming short circuit;
- the controller failing with its heating output constantly on;
- an external valve or contactor sticking in the heating condition;
- the controller setpoint set too high.

Where damage or injury is possible, we recommend fitting a separate over-temperature protection unit, with an independent temperature sensor, which will isolate the heating circuit. Please note that the alarm relays within the controller will not give protection under all failure conditions.

Grounding of the temperature sensor shield

In some installations it is common practice to replace the temperature sensor while the controller is still powered up. Under these conditions, as additional protection against electric shock, we recommend that the shield of the temperature sensor is grounded. Do not rely on grounding through the framework of the machine.

INSTALLATION REQUIREMENTS FOR EMC

To ensure compliance with the European EMC directive certain installation precautions are necessary as follows:

- For general guidance refer to Eurotherm EMC Installation Guide, HA025464.
- When using relay or triac outputs it may be necessary to fit a filter suitable for suppressing the emissions. The filter requirements will depend on the type of load. For typical applications we recommend Schaffner FN321 or FN612.
- If the unit is used in table top equipment which is plugged into a standard power socket, then it is likely that compliance to the commercial and light industrial emissions standard is required. In this case to meet the conducted emissions requirement, a suitable mains filter should be installed. We recommend Schaffner types FN321 and FN612.

Routing of wires

To minimise the pick-up of electrical noise, the wiring for low voltage dc and particularly the sensor input should be routed away from high-current power cables. Where it is impractical to do this, use shielded cables with the shield grounded at both ends. In general keep cable lengths to a minimum.

TECHNICAL SPECIFICATION

Main Process Value Input and Second DC Input

| | |
|--------------------------------------|---|
| Low level range | $\pm 100\text{mV}$ |
| High level range | 0 to 10Vdc or 0-20mA with external 2.49 Ω current shunt. All configurable between limits |
| Sample Rate | 9Hz (110mS) |
| Resolution | <2 μV for low level range, <0.2mV for high level range, with default input filter time constant of 1.6 seconds. |
| Linearity | Better than 0.2 $^{\circ}\text{C}$ |
| Calibration accuracy | The greater of 0.25% of reading or $\pm 1^{\circ}\text{C}$ or $\pm 1\text{LSD}$ |
| User calibration | Low and high offsets can be applied |
| Input filter | Off to 999.9 secs Default 1.6 seconds. |
| Thermocouple types | Refer to the ordering code sensor input table |
| Cold junction compensation | >30 to 1 rejection of ambient temperature changes in automatic mode. Uses INSTANT ACCURACY TM cold junction sensing technology to eliminate warm up drift and to respond quickly to ambient temperature changes. |
| RTD/PT100 input | External references 0, 45, and 50 $^{\circ}\text{C}$ 3-wire, Pt100 DIN43750. Bulb current 0.3mA. Up to 22 Ω in each lead without error |
| Potentiometer input | 100 to 15Kohm |
| Analogue input functions | Process value, remote setpoint, setpoint trim, external power limit, feedforward input,, valve position feedback |
| Second process value input functions | Select min, select max, derived value, transfer to 2 nd PV |

Digital inputs

| | |
|----------------------------------|--|
| Isolated except for fixed inputs | digital inputs 1 & 2 |
| Contact closure inputs | Open circuit voltage: 24 to 30 Vdc Short circuit current: 24 to 29mA Off state: < 100 ohms input resistance On state: > 28Kohm input resistance |
| Logic inputs (current sinking) | Off state: -3 to 5Vdc @ <-0.4mA On state: 10.8 to 30Vdc @ 2.5mA |
| Digital input functions | Refer to the ordering code |

Digital Outputs

| | |
|-----------------------|---|
| Relay rating | Min: 12V, 100mAdc. Max:2A, 264Vac resistive |
| Single logic output | 18Vdc, 20mA. This output is not isolated from the main process value input |
| Triple logic output | 12Vdc, 8mA per channel (isolated) |
| Digital o/p functions | As per the ordering code |
| High current output | 10Amp, 264Vac resistive. This option is not available on controller from Jan-04 |
| Triac rating | 1A, 30 to 264Vac resistive (isolated) |

Analogue outputs

| | |
|---------------------------|---|
| Range | Scaleable between 0-20mA and 0-10Vdc (isolated) |
| Resolution | 1 part in 10,000 for analogue retransmission |
| Analogue output functions | Refer to ordering code |

Transmitter supply

| | |
|--------|-------------|
| Rating | 20mA, 24Vdc |
|--------|-------------|

Control functions

| | |
|---------------------|---|
| Control modes | On/Off, PID, or motorised valve control, with or without feedback potentiometer |
| Cooling algorithms | Linear, water (non-linear), fan (min on time), oil |
| Tuning | One shot (automatic tune of PID and overshoot inhibition parameters) and continuous adaptive tuning |
| Number of PID sets | Two |
| Auto/manual control | Bumpless transfer or forced manual output available |
| Setpoint rate limit | Display units per second, minutes or hour |

Alarms

| | |
|------------------|---|
| Number of alarms | Four |
| Alarm types | Absolute high or low. Deviation band, deviation high, deviation low. Rate of change |
| Alarm modes | Latching or non-latching. Blocking. Energised or de-energised in alarm |

Setpoint programming

| | |
|----------------------|-------------|
| Number of programs | 1, 4 or 20 |
| Segments per program | 16 |
| Event outputs | Up to eight |

Communications (all modules are isolated)

| | |
|-----------|--|
| Profibus | High speed, RS485. Up to 1.5Mb/s |
| Modbus ® | RS232,2-wire,RS 485 and 4 wire RS485 modules |
| Baud rate | 1200, 2400, 4800, 9600 and 19,200 baud |

PDS

| | |
|------------------------|--|
| Slave input (isolated) | Remote setpoint input with holdback to master |
| Master output | Isolated from main PV. Retransmission of setpoint, process value or output |

General

| | |
|---------------------|--|
| Display | Dual, 4 digit x 7 segment LED. Up to two decimal places |
| Supply | 85 to 264Vac, 48 to 62 Hz, 10 W max OR 24Vdc or ac -15%, +20%. 10W max |
| Operating ambient | 0 to 55°C and 5 to 90% RH non-condensing |
| Storage temperature | -10 to +70°C |
| Panel sealing | IP65 |
| Dimensions | 2408: 48mm wide x 96mm high x 150mm deep 2404: 96mm wide x 96mm high x 150mm deep |
| Weight | 250g |
| EMC standards | EN61326-1 generic standards for industrial environments |
| Safety standards | Meets EN61010, installation category II (voltage transients must not exceed 2.5kV), pollution degree 2 |
| Atmospheres | Not suitable for use above 2000m or in explosive or corrosive atmospheres. Electrically conductive pollution must be excluded from the cabinet in which this controller is mounted |

Appendix D LOAD CURRENT MONITORING AND DIAGNOSTICS

Current flowing in a system of electrical heating elements (the 'Load') can be displayed on the controller by using a TE10 SSR fitted with intelligent current transformer, PDCTX, or an SSR or contactor with an external PDCTX.

Load current monitoring and diagnostics may be used with any time proportioned output, fitted in module position 1A, and uses the logic output wires which drive the SSR to return signals back to the controller. These signals represent the RMS value of the load current during the ON period, or load related alarm conditions. It is not designed for analogue outputs i.e. phase angle control.

It is also designed for single phase operation only.

There are three modes of operation:-

1. Mode 1

Detects if there is a **break in the heater circuit**. This includes heater or SSR open circuit. A single **Load Failure** alarm message is displayed on the lower readout of the controller.

2. Mode 2

Provides the following:-

| | |
|--|---|
| Display of true RMS load current On the lower readout of the controller | Displays the true RMS current in the ON state to the load. |
| Low current alarm Analogous to Partial Load Failure (PLF) supplied in some SSRs | Provides advanced warning of failure of one or more heaters in parallel |
| High current alarm Activated when the heater exceeds a set limit | Typically used where element bunching may occur |
| SSR short circuit | This will apply full power to the heaters which could result in an over temperature condition. This alarm provides early warning. |
| Heater failure | Indicates open circuit load conditions |

3. Mode 5

Provides the same features as mode 2 with two additional alarms. This mode is for use with contactors or other devices which do not use the PDS logic output from the controller as the drive signal. For example, a time proportioning logic, relay or triac output to operate a contactor. Mode 5, therefore, requires an additional input to the controller to display the load conditions. It uses the LB digital input terminals for this, as shown in Figure D.2.

| | |
|--|--|
| Current Transformer Open Circuit | Alarm is shown if the PDS connection to PDCTX or SSR become disconnected |
| Current Transformer Short Circuit | Alarm is shown if the PDS connection from PDCTX or SSR are short circuited |

EXAMPLE WIRING DIAGRAM (FOR MODE 1 & 2 OPERATION)

Hardware Required

1. SSR type **TE10/PDS2** OR
2. Intelligent current transformer type **PD/CTX** + **contactor or zero voltage switching SSR** 2408 or 2404 controller configured for PDS mode 2 option using logic output. This module must be fitted in module position 1. (order code **M2**).




Figure D.1 Connections for Mode 1 & 2


WARNING!

Take care that the controller is correctly wired for the mode of operation which is configured. Failure to do so may be hazardous in some situations.

EXAMPLE WIRING DIAGRAM (FOR MODE 5 OPERATION)

Hardware Required

1. Intelligent current transformer type **PD/CTX + contactor**
2. 2408 or 2404 controller configured for PDS mode 5 option using logic, relay or triac output. This module must be fitted in module position 1. Digital input LB (order code **M5**) must be configured to accept PDCTX input as described in the configuration section of this appendix.



The controller will have the order code M5 in the Logic Input position.




Figure D.2 Example Wiring Connections For Contactor Operation (mode 5)

WARNING!





Take care that the controller is correctly wired for the mode of operation which is configured. Failure to do so may be hazardous in some situations.

OPERATION

To Read Load Current (modes 2 and 5 only)

| Do This | This Is The Display You Should See | Additional Notes |
|---|--|---|
| <p>From the 'nF0' list</p> <p>Press  until <i>AmPS</i> is shown in the upper display</p> |   | <p>Current will be displayed in the lower readout. See also 'Display Modes' below.</p> <p>It will revert to the HOME display after 45 seconds or 10 seconds if an alarm is present</p> <p>This display will be shown if:</p> <ol style="list-style-type: none"> I. The controller is unable to resolve the reading II. The controller is obtaining a reading III. The measurement has timed out i.e. current has not flowed for 15 seconds, in mode 2. |

To Display Load Current Continuously in the Lower Readout (modes 2 and 5 only)

| Do This | This Is The Display You Should See | Additional Notes |
|---|---|---|
| <p>From the 'HOME' display, Figure 1.4,</p> <p>Press  until <i>d, SP</i> is shown in the upper display</p> <p>Press  or  until <i>AmPS</i> is displayed in the lower display</p> |  | <p>Current will be displayed in the lower readout continuously when the controller reverts to the HOME display, see also 'Display Modes' below.</p> |

Display Modes

SSR RMS On State Current

This is the default state when high or low current alarms are configured. The load current displayed is the steady state true rms current measured during the ON period.


The minimum on times are:-

| | |
|--------|-----------|
| Mode 2 | 0.1second |
| Mode 5 | 3 seconds |

Meter Mode

Meter mode applies to mode 5 only. If low current alarms are **not** configured the current displayed is a filtered instantaneous RMS value. This behaves like a damped analogue meter. It may be used in applications where the current sensor is not linked to control, for example, telemetry, indication.







How Heater Alarms Are Displayed

| Do This | This Is The Display You Should See | Additional Notes |
|--|--|---|
| <p>If an alarm is present it will flash a four character mnemonic in the lower display</p> | <p>Actual Temperature → (PV)</p> <div style="text-align: center;">  <p>The image shows a digital display with 'HOME Display' at the top. Below it are two small boxes labeled 'OP1' and 'OP2'. The main display shows '20.0' in large digits, with 'ILCr' in smaller digits below it. At the bottom of the display are four icons: a document, a refresh/clock, an up arrow, and a down arrow.</p> </div> | <p>If more than one alarm is active, the display will alternate between the alarm messages and the default parameter in the lower display</p> |

The Alarm Messages are:-







| Mnemonic | Meaning | Description |
|---|-----------------------------------|---|
| <p>The following two messages are alarms which are produced as a result of failure within the process. In place of dashes the alarm number will appear i.e 1, 2, 3, or 4</p> | | |
| -LCr | Alarm number - Low Current | Used for partial load failure detection. To avoid nuisance tripping due to supply voltage variations set to a value at least 15% below the minimum normal operating current |
| -HCr | Alarm number - High Current | Used for load overcurrent protection. To avoid nuisance tripping due to supply voltage variations set to a value at least 15% above the maximum normal operating current. Note: This alarm is not intended to provide instantaneous safety protection from short circuit fault conditions |
| <p>The following message is a diagnostic alarm which appears for mode 1 operation only.</p> | | |
| LdF | Load Fail | This includes failure of the heater circuit or the SSR |
| <p>The following four messages are diagnostic alarms produced as a result of failure within the equipment or wiring connections. They appear for modes 2 and 5 operation only. They may be enabled using the d₁ AL parameter in the AL L₁ SE, see 'SHORT CIRCUIT SSR ALARM AND HEATER FAIL ALARM'</p> | | |
| HrF | Heater Fail | No current is being drawn while the controller output demand signal is on |
| SSrF | SSR Fail | The load is continuously on while the controller output demand signal is off |
| CTOP | Current Transformer Open Circuit | Indicates that the PDS input is open circuit. Mode 5 only |
| CTSh | Current Transformer Short Circuit | Indicates that the PDS input is short circuit Mode 5 only |

TO SET THE ALARM TRIP LEVELS

| Do This | This Is The Display You Should See | Additional Notes |
|--|--|--|
| From the HOME display press  until the AL L, St is displayed |  | To select the Alarm List header |
| Press  button until the desired alarm number is displayed Press  or  to adjust the alarm trip level |  1 2 3 or 4 indicates the alarm number; --- indicates the alarm type:- e.g. LLr or HCr | To select the diagnostic alarm parameter found under the Alarm List header The alarm trip level is set to 123 |

SHORT CIRCUIT SSR ALARM AND HEATER FAIL ALARM

These alarms exist as **Diagnostic Alarms** in the controller. To make the alarm active it is only necessary to turn on the diagnostic alarm feature in the Alarm List in the Operator Level

| Do This | This Is The Display You Should See | Reason |
|--|---|--|
| From the HOME display press  button until the AL L, St is displayed |  | This opens the list which contains the d, AG mnemonic |
| Press  until d, AG is displayed Press  or  to select YES |  | This activates the d, AG mnemonic to allow Diagnostic Alarms to be displayed in the lower readout of the HOME display |

RELAY OUTPUTS

The fixed relay output connected to terminals AA to AC in a 1/8 or 1/4 DIN controller is normally used for alarm purposes. In addition, any plug in module can be used for alarms provided they are not already being used for another purpose, such as control. Any one or more alarms can be attached to an output, which will operate when an alarm occurs. Contacts are rated at 2A 264Vac for operating external beacons or audible devices.













TO CONFIGURE PDS LOAD CURRENT DIAGNOSTICS

















Configuration of PDS load current diagnostics is in four parts:-

1. Configure the Logic Module for PDS Mode 1 or 2 operation. If the control device is a contactor or standard SSR, configure the LA digital input for mode 5 operation.
2. Configure the Low and High Current trip alarms.
3. Attach the alarms to operate an output relay.
4. Set up the Scaling Factor.









First enter Configuration Level. See Chapter 5

TO CONFIGURE THE LOGIC MODULE FOR PDS MODES 1 OR 2

| Do This | This Is The Display You Should See | Additional Notes |
|---|---|--|
| Press  until the 1A Conf is displayed |  | This opens the configuration list associated with module position 1A |
| Press  to show 1d |  | This shows the identity of the module The module identity is <u>logic</u> output |
| Press  to show Func Press  or  to show SSr 1 or SSr 2 as required. |  | This shows the <u>function</u> of module The module function is set to PDS mode 1 |
| Press  to show UALL Press  or  to show 00 |  | This is the lower PID demand level To set the minimum PID signal to 0% |

| | | |
|--|--|--|
| <p>Press  to show UAL.H)</p> <p>Press  or  to show 100.0</p> |  | <p>This is the upper PID demand level</p> <p>To set the maximum PID signal to 100%</p> |
| <p>Press  to show OUT.L</p> <p>Press  or  to show 0.0</p> |  <p>Warning! If OUT.L is set to any figure other than 0 the minimum output power will be limited to this level. You must ensure that this does not present an unsafe condition for the process</p> | <p>This is the minimum output power</p> <p>To set the min output power to 0</p> |
| <p>Press  to show OUT.H</p> <p>Press  or  to show 100.0</p> |  | <p>This is the maximum output power</p> <p>To set the max output power to 100</p> |
| <p>Press  to show SEN.S</p> <p>Press  or  to show nor</p> |  | <p>This sets the output signal to normal for heating control</p> |

TO CONFIGURE LOGIC INPUT B FOR PDS (MODE 5 ONLY)











| Do This | This Is The Display You Should See | Additional Notes |
|---|---|--|
| Press  button until the <i>Lb Conf</i> is displayed |  | |
| Press  to show <i>, d</i> |  | This identifies the LA input as logic and is read only |
| Press  to show <i>Func</i> Press  or  to select <i>AmPS</i> |  | To configure the input for the PDCTX. |

The system is designed to operate in either mode 2 or mode 5 configuration only. Selecting both simultaneously will disable the output. However, mode 1 and mode 5 can be used together.

TO CONFIGURE LOW AND HIGH CURRENT TRIP ALARMS

Alarm 1 will be configured as Load Current Low (LCr)







Alarm 2 will be configured as Load Current High (HCr)


| Do This | This Is The Display You Should See | Additional Notes |
|---|--|--|
| Press  button until the AL CONF is displayed |  | This opens the configuration list which contains the Alarms |
| Press  to show AL 1 (alarm 1) Press  or  to show L<u>C</u>r |  <p>After 0.5 sec the display will blink to show the alarm type has been accepted</p> | To select alarm 1 To make alarm 1 = <u>L</u> ow <u>C</u> urrent |
| Press  until AL 2 (alarm 2) appears Press  or  to show H<u>C</u>r |  <p>After 0.5 sec the display will blink to show the alarm type has been accepted</p> | To select alarm 2. To make alarm 2 = <u>H</u> igh <u>C</u> urrent |

Note:- The above alarms are known as **SOFT ALARMS** because they are indication only.

TO ATTACH SOFT ALARMS TO A RELAY OUTPUT

Any one alarm indicated above may be attached to an output (normally a relay). Alternatively any combination of alarms may be attached to operate a relay using the procedure below:-

| Do This | This Is The Display You Should See | Additional Notes |
|---|--|---|
| <p>Press "PAGE" key  as many times as necessary to AA Conf</p> |  | <p>To select the output which you want to operate when the alarm condition occurs. You may also choose 1A, 1B, 1C, 2A, 2B, 2C, 3A, 3B, 3C or 4A depending upon the controller and the number and type of modules fitted</p> |
| <p>Press  until 1--- is displayed</p> <p>Press  or  to select YES or</p> <p>Repeat the above step for every alarm to be attached to the output</p> |  <p>1--- denotes alarm 1 followed by three letters which denote the alarm type e.g. LCr</p> | <p>YES means that the selected output will activate when an alarm occurs in normal operation no means the output will not activate</p> |










THE SCALING FACTOR

The value of the current displayed on the controller is scaled using the scaling factor. This is found in the `, nSt Conf` list. It is set, by default, to 100 and assumes a single turn through the current transformer. If two turns are made through the current transformer it will be necessary to adjust the scaling factor to 50 to obtain the same reading.

Under normal conditions you should not need to change the scaling factor.

If, however, you wish to change the sensitivity of the current reading, for example, to read very low currents you may need to change the number of turns through the PDCTX and/or adjust the scaling factor to compensate. See also note 1 below.

TO ADJUST THE SCALING FACTOR

| Do This | This Is The Display You Should See | Additional Notes |
|---|---|------------------|
| Press  button until <code>, nSt Conf</code> is displayed |  | |
| Press  until <code>LCHi</code> is displayed |  | |
| Press  or  to change the scaling factor |  | |

Note 1:-

Minimum Resolvable Current

TE10 4A RMS. It is not possible to read currents lower than 4A when using a TE10.

PDCTX 4A RMS for a single turn through the PDCTX

Should you wish to read currents lower than 4A using a PDCTX it is necessary to increase the number of turns through the PDCTX and adjust the scaling factor to compensate.

For example: To read 1.0A wind 4 turns through the PDCTX and adjust the scaling factor to 25 as shown in the table below.

| Scalar = 100/N Where N = Turns through PDCTX | | | |
|--|--------|----|--------|
| N | Scalar | N | Scalar |
| 1 | 100 | 5 | 20 |
| 2 | 50 | 10 | 10 |
| 4 | 25 | | |

Maximum Resolvable Current

TE10 Determined by the maximum range of the SSR

PDCTX 100A (or 100 ampere turns)

Finally Exit configuration level. See Chapter 5.

Appendix E: Profibus Communications

Introduction

The 2408*f* and 2404*f* are special versions of the 2408 and 2404 controllers designed for Profibus-DP communications. The 'standard' 2408 or 2404 controllers cannot be upgraded to a 2408*f* or 2404*f* as the latter uses a different version of the microprocessor board.

Profibus-DP is available with either the 85 to 264Vac or 20-29Vac/dc supply

Apart from the restrictions listed below, the operation, functions and wiring of the 2404*f* and 2408*f* are identical to that of the standard 2408 and 2404 controllers.

- Modbus communications may be configured to replace Profibus-DP if required.
- This must be installed in module slot H.
- EI Bisynch protocol is not supported, therefore the IPSP instrument programming system cannot be used.
- The 20 programmer option is not available.
- The PDSIO input and output modules can only be installed in module slot J.

About Profibus-DP

Profibus-DP is an industry standard, open network used to connect simple devices in a machine or manufacturing plant. It is most often used to allow a central Programmable Logic Controller or PC based control system to use external 'slave' devices for I/O or specialised functions. One advantage is that these devices may be distributed around a machine, saving on the cost of point to point wiring. The 'open' nature of the network permits equipment from different manufacturers to be mixed easily so that best of breed equipment may be used. Additionally, the off-loading of specialised tasks such as PID temperature control lessens the processing load on the central PLC so that its other functions may be carried out more efficiently.

Profibus-DP is described in DIN 19245 Part 3, and is part of EN 50170.

The Profibus-DP network uses a high speed version of the RS485 standard, permitting baud rates of up to 12Mbaud. The 2408*f* and the 2404*f* support rates of up to 1.5 Mbaud in order to meet electrical isolation standards. A table of network speed against line length is given in the section on wiring below.

Up to 32 Profibus stations (nodes) may be wired to a single network segment. Use of RS485 repeaters allows a total of up to 127 stations.

Other variants of Profibus that exist are Profibus FMS, which is designed to allow higher level communication such as that between PLCs and SCADA systems, and Profibus PA, which has an optional low speed, intrinsically safe, physical medium and is designed for use in the Process Industry. The 2408*f* and 2404*f* controllers can be used on a combined DP and FMS network, sharing the same physical medium, but may only be used for PA when the intrinsically safe physical medium is not used.


Profibus-DP is a multimaster, master-slave, token passing network. The 2408f and the 2404f operate as intelligent slave units. More detailed information, including a detailed guide to products available, may be obtained from the various world wide Profibus user organisations. You will find contact information in trade magazines or by reference to <http://www.profibus.com> on the World Wide Web.

Technical Specification

| | |
|--------------------|--|
| Physical Medium | 2-wire RS485 |
| Network topology | Linear bus with active termination of the bus at both ends Stub lines permitted if < 6.6m in length |
| Protocol | Profibus-DP, intelligent slave |
| Baud rate | Up to 1.5Mb/s |
| Number of stations | 32 per network segment. Up to 127 with repeaters |

Electrical Connections

The diagram below is also shown in Chapter 1.



Cable Specifications

Either of the two cable types detailed below can be used. Please note that the cable types A and B, specified below, are NOT related to the wire numbers A and B in the above wiring diagram. Type A is recommended as it allows higher speed and longer cable length.

| | Type A cable | Type B cable |
|---------------------------|--|--|
| Characteristic Impedance: | 135 to 165Ω at a frequency of 3 to 20 MHz. | 135 to 165Ω at a frequency of > 100 kHz |
| Cable capacitance: | < 30 pF per Metre | typ. < 60 pF per Metre |
| Core diameter: | max. 0.34 mm ² , corresponds to AWG 22 | max. 0.22 mm ² , corresponds to AWG 24 |
| Cable type: | twisted pair cable. 1x2 or 2x2 or 1x4 lines | twisted pair cable. 1x2 or 2x2 or 1x4 lines |
| Resistance: | < 110 Ohm per km | - |
| Shielding: | Copper shielding braid or shielding braid and shielding foil | Copper shielding braid or shielding braid and shielding foil |

Maximum Line Length per Segment

| Baud rate (kbit/sec) | 9.6 | 19.2 | 93.75 | 187.5 | 500 | 1500 |
|----------------------|-------|-------|-------|-------|------|------|
| Type A cable | 1200m | 1200m | 1200m | 1000m | 400m | 200m |
| Type B cable | 1200m | 1200m | 1200m | 600m | 200m | - |

Belden B3079A meets cable A specifications, but there are other choices. For more information refer to the 'Profibus Product Guide' produced by the Profibus User Group.

Controller Configuration and Node Address

Having connected the controller to the network, it must be configured for Profibus communications and a node address assigned.

Configuration

In the *HA* list set *Func = Prof*.



Comms configuration list - *HA*

Refer to the main handbook for instructions on how to select configuration level and access the *HA* list



Identity of module

This should be a read-only parameter displaying *CMS*



Function

Set *Func = Prof* to select Profibus protocol




Resolution *FULL = Full, Int = Integer*

This is the only other parameter that appears in this list when *Prof* is selected as the function.

Note: The baud rate is automatically selected by the master.

Assigning a Node Address

Refer to the main handbook for instructions on how to select and change parameters.






Comms list

From the HOME display, press  until you reach the *CMS* list



Node address

Press  to display the node address. Press  or  to set the desired address. *0 - 126*



Comms Status

This is a read-only diagnostic display

rdy Ready to run

run Comms running

Network configuration

Having wired and configured the controller, the PLC or PC based supervisory package must be configured to set-up the parameters that it will be able to read and write to. This is known as ‘network configuration’

The network is configured by importing ‘GSD’ files into your Master Profibus network configuration software: Refer to the network configuration software documentation for details. ‘GSD’ is an acronym of a German phrase meaning ‘Device Database’.

GSD files for the 2408*f* and 2404*f* controllers are created using a Windows based configuration tool. This is separately supplied under ordering code PROF-ENG. A Communications Handbook (part number HA026290ENG), supplied with the configurator, gives all the required information

Two standard GSD files, are supplied on the disc:


- EURO2400.GSD standard parameter mapping
- EURD2400.GSD standard parameter mapping with ‘demand data’, which allows random read/write to any parameter within the controller.

It is possible to edit the above files or create new files using the Windows configurator. Details are given in the communications handbook.

The Master network configuration software uses the GSD files to produce a further file which is downloaded into your master PLC or PC supervisory package. Once the configuration file has been downloaded, you can set the network running. If all is well, the ‘REM’ beacon on the controller will start to flash, indicating that the data exchange is proceeding. The **STATE** parameter in the **cms** list will show **RUN**. You may then write to Profibus outputs, and read from Profibus inputs as required by your control strategy.

In case of problems, a troubleshooting section is provided on the next page.

Windows configurator



What does it do?

It creates a ‘GSD’ file which defines the inputs and outputs that the PLC or supervisory package will be able to talk to. The GSD file is imported into a Profibus Master configuration tool which in-turn produces a file that is downloaded into the PLC or supervisory package.

How do I use it?

Click on the tabs at the bottom of the device parameter window to select a parameter page. Then use the mouse to drag a required parameters into either the Profibus input or output lists.

How many parameters can I select?

Up to 117 per node, total of inputs and outputs.


What can I run it on?

Windows 3.1, Windows 95, or Windows NT.

Troubleshooting

No Communications:

- Check the wiring carefully, paying particular attention to the continuity of the A and B connections to the Master. Ensure that the correct terminals have been wired to.
- Access the *HA* list in configuration level and check that the function (*FUNC*) is set to *PROF*. If not, the controller is not configured for Profibus.
- Check that the Node Address (*Addr*) in the *cms* list is correct for the network configuration in use.
- Ensure that a Profibus Comms Module is installed in slot H of the 2404/8f. It can be identified by of the legend on the plug-in module casing, and its distinctive shape:



- Ensure that the network is correctly configured and the configuration has been transmitted correctly to the Profibus master.
- Verify the GSD file in use is correct by loading it into the master GSD Configuration tool. This will check the format.
- Verify that the maximum line length for the baud rate in use is not exceeded (see table above). Note that the 2404/8f is restricted to use at a maximum rate of 1.5 Mbaud.
- Ensure that the last device (not necessarily a 2404/8f) in the network segment is correctly terminated (see wiring diagram).
- Ensure that no devices other than those at the end of a segment have termination networks fitted.
- If possible, replace faulty device with a duplicate and retest.


Intermittent failure to communicate.

Intermittent flickering of status from *rdy* to *run*.

Diagnostic status changing but no alarms present in the controller.

- Verify wiring, paying particular attention to screening.
- The I/O data length may be too long. Some Profibus DP Master implementations can accept no more than 32 input and 32 output words per slave device. Verify by reference to documentation of the Master.
- Verify that the maximum line length for the baud rate in use is not exceeded (see cable specifications). Note that the 2404/8f is restricted to use at a maximum rate of 1.5 Mbaud.
- Ensure that the last device (not necessarily a 2404/8) in the network segment is correctly terminated (see wiring diagram).
- Ensure that no devices other than those at the end of a segment have termination networks fitted.
- Verify operation with a duplicate device if possible.

Appendix F RoHS

| Restriction of Hazardous Substances (RoHS) | | | | | | |
|---|--|---|------------|--------|------|-------|
| Product group | 2400 | | | | | |
| Table listing restricted substances | | | | | | |
| Chinese | | | | | | |
| 限制使用材料一览表 | | | | | | |
| 产品 2400 | 有毒有害物质或元素 | | | | | |
| | 铅 | 汞 | 镉 | 六价铬 | 多溴联苯 | 多溴二苯醚 |
| 印刷电路板组件 | X | O | O | O | O | O |
| 附属物 | O | O | O | O | O | O |
| 显示器 | X | O | O | O | O | O |
| 模块 | X | O | X | O | O | O |
| O | 表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T11363-2006标准规定的限量要求以下。 | | | | | |
| X | 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T11363-2006标准规定的限量要求。 | | | | | |
| English | | | | | | |
| Restricted Materials Table | | | | | | |
| Product 2400 | Toxic and hazardous substances and elements | | | | | |
| | Pb | Hg | Cd | Cr(VI) | PBB | PBDE |
| PCBA | X | O | O | O | O | O |
| Enclosure | O | O | O | O | O | O |
| Display | X | O | O | O | O | O |
| Modules | X | O | X | O | O | O |
| O | Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in SJ/T11363-2006. | | | | | |
| X | Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in SJ/T11363-2006. | | | | | |
| Approval | | | | | | |
| Name: | Position: | Signature: | Date: | | | |
| Martin Greenhalgh | Quality Manager |  | 09/11/2007 | | | |

IA029470U470 (CN23172) Issue 1 Feb 07

INTERNATIONAL SALES AND SERVICE

AUSTRALIA Sydney

Eurotherm Pty. Ltd.
Telephone (+61 2) 9838 0099
Fax (+61 2) 9838 9288
E-mail info.au@eurotherm.com

AUSTRIA Vienna

Eurotherm GmbH
Telephone (+43 1) 798 7601
Fax (+43 1) 798 7605
E-mail info.at@eurotherm.com

BELGIUM & LUXEMBOURG Moha

Eurotherm S.A/N.V.
Telephone (+32) 85 274080
Fax (+32) 85 274081
E-mail info.be@eurotherm.com

BRAZIL Campinas-SP

Eurotherm Ltda.
Telephone (+5519) 3707 5333
Fax (+5519) 3707 5345
E-mail info.br@eurotherm.com

DENMARK Copenhagen

Eurotherm Danmark AS
Telephone (+45 70) 234670
Fax (+45 70) 234660
E-mail info.dk@eurotherm.com

FINLAND Abo

Eurotherm Finland
Telephone (+358) 2250 6030
Fax (+358) 2250 3201
E-mail info.fi@eurotherm.com

FRANCE Lyon

Eurotherm Automation SA
Telephone (+33 478) 66 45 00
Fax (+33 478) 35 24 90
E-mail info.fr@eurotherm.com

GERMANY Limburg

Eurotherm Deutschland GmbH
Telephone (+49 6431) 2980
Fax (+49 6431) 298119
E-mail info.de@eurotherm.com

HONG KONG & CHINA

Eurotherm Limited North Point
Telephone (+85 2) 28733826
Fax (+85 2) 28700148
E-mail info.hk@eurotherm.com

Guangzhou Office

Telephone (+86 20) 8755 5099
Fax (+86 20) 8755 5831
E-mail info.cn@eurotherm.com

Beijing Office

Telephone (+86 10) 6567 8506
Fax (+86 10) 6567 8509
E-mail info.cn@eurotherm.com

Shanghai Office

Telephone (+86 21) 6145 1188
Fax (+86 21) 6145 1187
E-mail info.cn@eurotherm.com

INDIA Chennai

Eurotherm India Limited
Telephone (+91 44) 2496 1129
Fax (+91 44) 2496 1831
E-mail info.in@eurotherm.com

IRELAND Dublin

Eurotherm Ireland Limited
Telephone (+353 1) 4691800
Fax (+353 1) 4691300
E-mail info.ie@eurotherm.com

ITALY Como

Eurotherm S.r.l.
Telephone (+39 031) 975111
Fax (+39 031) 977512
E-mail info.it@eurotherm.com

KOREA Seoul

Eurotherm Korea Limited
Telephone (+82 31) 273 8507
Fax (+82 31) 273 8508
E-mail info.kr@eurotherm.com

NETHERLANDS Alphen a/d Rijn

Eurotherm B.V.
Telephone (+31 172) 411752
Fax (+31 172) 417260
E-mail info.nl@eurotherm.com

NORWAY Oslo

Eurotherm A/S
Telephone (+47 67) 592170
Fax (+47 67) 118301
E-mail info.no@eurotherm.com

POLAND Katowice

Eurotherm Sp Z o.o.
Telephone (+48 32) 2185100
Fax (+48 32) 2177171
E-mail info.pl@eurotherm.com

SPAIN Madrid

Eurotherm España SA
Telephone (+34 91) 6616001
Fax (+34 91) 6619093
E-mail info.es@eurotherm.com

SWEDEN Malmo

Eurotherm AB
Telephone (+46 40) 384500
Fax (+46 40) 384545
E-mail info.se@eurotherm.com

SWITZERLAND Wollerau

Eurotherm Produkte (Schweiz) AG
Telephone (+41 44) 787 1040
Fax (+41 44) 787 1044
E-mail info.ch@eurotherm.com

UNITED KINGDOM Worthing

Eurotherm Limited
Telephone (+44 1903) 268500
Fax (+44 1903) 265982
E-mail info.uk@eurotherm.com
Web www.eurotherm.co.uk

U.S.A Leesburg VA

Eurotherm Inc.
Telephone (+1 703) 443 0000
Fax (+1 703) 669 1300
E-mail info.us@eurotherm.com
Web www.eurotherm.com

ED54

Invensys, Eurotherm, the Eurotherm logo, Chessell, EurothermSuite, Mini8, Eycon, Eyris and Wonderwear are trademarks on Invensys plc, its subsidiaries and affiliates. All other brands may be trademarks of their respective owners.

© Copyright Eurotherm Limited 2007

All rights are strictly reserved. No part of this document may be reproduced, modified, or transmitted in any form by any means, nor may it be stored in a retrieval system other than for the purpose to act as an aid in operating the equipment to which the document relates, without the prior written permission of Eurotherm limited.

Eurotherm Limited pursues a policy of continuous development and product improvement. The specifications in this document may therefore be changed without notice. The information in this document is given in good faith, but is intended for guidance only. Eurotherm Limited will accept no responsibility for any losses arising from errors in this document.

